

8.25.13.4.2 SUBSCRIBE_DMA.TX

Subscribe configuration for tasks

8.25.13.4.2.1 SUBSCRIBE_DMA.TX.START

Address offset: 0x0D0

Subscribe configuration for task START

8.25.13.4.2.2 SUBSCRIBE_DMA.TX STOP

Address offset: 0x0D4

Subscribe configuration for task **STOP**

8.25.13.5 EVENTS CTS

Address offset: 0x100

CTS is activated (set low). Clear To Send.

8.25.13.6 EVENTS NCTS

Address offset: 0x104

CTS is deactivated (set high). Not Clear To Send.