

ID	Base address	Instance	TrustZone			Split access	Description
			Map	Att	DMA		
135	0x50087000 0x40087000	EGU10 : S EGU10 : NS	US	S	NA	No	Event generator unit EGU10
138	0x5008A000 0x4008A000	RADIO : S RADIO : NS	US	S	SA	No	2.4 GHz radio RADIO See pinout for GPIO options for DFE antenna switch control
192	0x500C0000	SPU20	HF	S	NA	No	System protection unit SPU20
194	0x500C2000 0x400C2000	DPPIC20 : S DPPIC20 : NS	US	S	NA	Yes	DPPI controller DPPIC20
195	0x500C3000 0x400C3000	PPIB20 : S PPIB20 : NS	US	S	NA	No	PPI bridge PPIB20
196	0x500C4000 0x400C4000	PPIB21 : S PPIB21 : NS	US	S	NA	No	PPI bridge PPIB21
197	0x500C5000 0x400C5000	PPIB22 : S PPIB22 : NS	US	S	NA	No	PPI bridge PPIB22
198	0x500C6000 0x400C6000	SPIM20 : S SPIM20 : NS	US	S	SA	No	SPI controller SPIM20
198	0x500C6000 0x400C6000	SPIS20 : S SPIS20 : NS	US	S	SA	No	SPI peripheral SPIS20
198	0x500C6000 0x400C6000	TWIM20 : S TWIM20 : NS	US	S	SA	No	Two-wire interface controller TWIM20
198	0x500C6000 0x400C6000	TWIS20 : S TWIS20 : NS	US	S	SA	No	Two-wire interface target TWIS20
198	0x500C6000 0x400C6000	UARTE20 : S UARTE20 : NS	US	S	SA	No	Universal asynchronous receiver/transmitter UARTE20
199	0x500C7000 0x400C7000	SPIM21 : S SPIM21 : NS	US	S	SA	No	SPI controller SPIM21
199	0x500C7000 0x400C7000	SPIS21 : S SPIS21 : NS	US	S	SA	No	SPI peripheral SPIS21
199	0x500C7000 0x400C7000	TWIM21 : S TWIM21 : NS	US	S	SA	No	Two-wire interface controller TWIM21
199	0x500C7000 0x400C7000	TWIS21 : S TWIS21 : NS	US	S	SA	No	Two-wire interface target TWIS21
199	0x500C7000 0x400C7000	UARTE21 : S UARTE21 : NS	US	S	SA	No	Universal asynchronous receiver/transmitter UARTE21
200	0x500C8000 0x400C8000	SPIM22 : S SPIM22 : NS	US	S	SA	No	SPI controller SPIM22
200	0x500C8000 0x400C8000	SPIS22 : S SPIS22 : NS	US	S	SA	No	SPI peripheral SPIS22
200	0x500C8000 0x400C8000	TWIM22 : S TWIM22 : NS	US	S	SA	No	Two-wire interface controller TWIM22
200	0x500C8000 0x400C8000	TWIS22 : S TWIS22 : NS	US	S	SA	No	Two-wire interface target TWIS22
200	0x500C8000 0x400C8000	UARTE22 : S UARTE22 : NS	US	S	SA	No	Universal asynchronous receiver/transmitter UARTE22
201	0x500C9000 0x400C9000	EGU20 : S EGU20 : NS	US	S	NA	No	Event generator unit EGU20
202	0x500CA000 0x400CA000	TIMER20 : S TIMER20 : NS	US	S	NA	No	Timer TIMER20
203	0x500CB000 0x400CB000	TIMER21 : S TIMER21 : NS	US	S	NA	No	Timer TIMER21
204	0x500CC000 0x400CC000	TIMER22 : S TIMER22 : NS	US	S	NA	No	Timer TIMER22