

#### 7.8.1.6.4 INTEN

Address offset: 0x300

## Enable or disable interrupt

### **7.8.1.6.5 INTENSET**

Address offset: 0x304

## Enable interrupt