

5.4.3.33 LFCLK.RUN

Address offset: 0x448

Indicates that LFCLKSTART task was triggered

5.4.3.34 LFCLK.STAT

Address offset: 0x44C

Copy of LFCLK.SRCCOPY register, set when LFCLKSTARTED event is triggered.

5.4.3.35 LFCLK.SRCCOPY

Address offset: 0x450

Copy of LFCLK.SRC register, set when LFCLKSTART task is triggered