

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID	A																															
<b>Reset 0x00000000</b>																																
ID	R/W	Field	Value ID																													
A	W	TASKS_STOP	Stop RADIO																													
Trigger																																
1																																

## 8.17.14.5 TASKS\_DISABLE

Address offset: 0x010

Disable RADIO

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID	A																															
<b>Reset 0x00000000</b>																																
ID	R/W	Field	Value ID																													
A	W	TASKS_DISABLE	Disable RADIO																													
Trigger																																
1																																

## 8.17.14.6 TASKS\_RSSISTART

Address offset: 0x014

Start the RSSI and take one single sample of the receive signal strength

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID	A																															
<b>Reset 0x00000000</b>																																
ID	R/W	Field	Value ID																													
A	W	TASKS_RSSISTART	Start the RSSI and take one single sample of the receive signal strength																													
Trigger																																
1																																

## 8.17.14.7 TASKS\_BCSTART

Address offset: 0x018

Start the bit counter

Bit number	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ID	A																															
<b>Reset 0x00000000</b>																																
ID	R/W	Field	Value ID																													
A	W	TASKS_BCSTART	Start the bit counter																													
Trigger																																
1																																

## 8.17.14.8 TASKS\_BCSTOP

Address offset: 0x01C

Stop the bit counter