

Override DATARATE setting in MODE register with the contents of the RATEOVERRIDE register for any ongoing encryption/decryption

#### **8.4.7.4 SUBSCRIBE\_START**

Address offset: 0x080

## Subscribe configuration for task START

#### 8.4.7.5 SUBSCRIBE STOP

Address offset: 0x084

## Subscribe configuration for task STOP

#### 8.4.7.6 SUBSCRIBE RATEOVERRIDE

Address offset: 0x088

Subscribe configuration for task RATEOVERRIDE