

5.4.3.27 INTPEND

Address offset: 0x30C

Pending interrupts

5.4.3.28 XO.RUN

Address offset: 0x408

Indicates that XOSTART task was triggered