Bit number				31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
ID				M L K J I H G F E D C B A
Reset 0x00000000				**0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0**
ID	R/W	Field	Value ID	Value	Description
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
D	RW W1C	DMARXEND			Write '1' to disable interrupt for event DMARXEND
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
E	RW W1C	DMARXREADY			Write '1' to disable interrupt for event DMARXREADY
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
F	RW W1C	DMARXBUSERROR			Write '1' to disable interrupt for event DMARXBUSERROR When this event is generated, the address which caused the error can be read from the BUSERRORADDRESS register.
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
G-J	RW W1C	DMARXMATCH[i] (i=0..3)			Write '1' to disable interrupt for event DMARXMATCH[i]
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
K	RW W1C	DMATXEND			Write '1' to disable interrupt for event DMATXEND
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
L	RW W1C	DMATXREADY			Write '1' to disable interrupt for event DMATXREADY
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
M	RW W1C	DMATXBUSERROR			Write '1' to disable interrupt for event DMATXBUSERROR When this event is generated, the address which caused the error can be read from the BUSERRORADDRESS register.
			Clear	1	Disable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled

8.19.8.22 ENABLE

Address offset: 0x500

Enable SPIM