Physical Layer and Networking Media

Hardware devices that are used to connect computers, printers, fax machines and other electronic devices to a network are called network devices. These devices transfer data in a fast, secure and correct way over same or different networks. Network devices may be inter-network or intra-network. Following are some of the key networking devices:

Repeater 7 A repeater is a networking device which operates at the physical layer. It is job is to regenerate the signal over the same network before the signal becomes too weak or corrupted so as to extend the length to which the signal can be transmitted over the same network. Repeaters do not amplify the signals. When the signal becomes weak, they copy the signal bit by bit and regenerate it at the original strength. It is a two port device.

PP Hub. A hub is basically a multipoint repeater. A hub connects multiple wires comming from different branches. Hubs cannot filter data, so data packets are sent to all connected devices. There are two types of hub: active hub and passive hub.

clean, boost and active hub have their own power supply and can network. Active hubs are used to extend along with the between nodes. Passive hubs have power supply from active signals onto the network. Passive hubs can't clean, boost and relay the extend the distance between nodes.

and a design that can boost its efficiency and performance. A switch is a data link layer device. The switch can perform error checking before forewarding data that that have errors and forward good packets selectively to

IV) Bridge A bridge operates at data link layer. A bridge 48 a repeater, with add on the functionality of filtering content by reading the MAC addresses of source and destination. It is also used for interconnecting two LANs working on the same protocal. It has a single input and single output port, thus making 4t a 2 port device.

There are two types of bridges: transparent bridges and source routing bridges. In transparent bridge the stations are completely unwunaware whether a bridge 18 bridge, routing operation is performed by source routing frame specifies which route to follow.

Packets based on their IP addresses. Router 48 mainly a network layer device. Routers normally connect LANs and WANs together and have a dynamically updating routing table packets. Router divide broadcast domains of hosts connected through 4t.

@ Different Types of Transmission Medias:

signal 18 carried from one system to another. Mainly there are two types of transmission medias: Wired and wireless.

O Wired transmission medias: It is also referred as guided media or bounded media. Signal being transmitted are directed and confined in a narrow pathway by using physical links. It comparatively shorter distances.

Times

Twisted pair cable: It consists of 2 seperately insulted conductor wires wound about each other. Grenerally, several such pairs are bundled together in a protective sheath. They are the most widely used Transmission Media. Twisted pair cable is futher of following two types:

Unshelded Twisted Pair (UTP): Thes type of cable has the ability to block anterference and does not depend on a physical shield for this purpose. It is used for delephonic applications. Following are the advantages of UTP:

> Least expensive

-> High speed capacity

Hemitations:

-> hower capacity and performance in comparison to STP.

-> Short distance transmission due to attenuation.

Shielded Twisted Pair (STP):-This type of cable consists of a special gacket to block external interference. It is used in fast-data-rate Ethernet and in voice and data channels

Advantages

Better performance at a higher data rate in comparision to UTP.

-> Eliminates crosstalk.

-> Comparatively faster.

Disadvantages

-> Expensive

-> Comparatively difficult to install and manufacture.

982 Coaxial Cable: It has an outer plastic covering containing 2 parallel conductors each having a seperate insulted protection cover. Coaxial cable transmits information in two modes: Baseband mode and Broadband and mode. Cable TVs and analog television networks widely use Coaxial cables.

Advantages High Bandwidth.

-> Better noise immunity.

-> Easy to Install and expand

Disadvantage -> Single cable failure can disrupt the entire network. Optical Fibre Cable: It uses the concept of reflection of light almough a core made up of glass or plastic. The core is surrounded by a less dense glass or plastic covering called the cladding. It is used for transmission of large volume of data. The cable can be unidirectional or bidirectional.

Advantages

-> Increased capacity and bandwidth.

-> hight weight.

These signal attenuation.

-> Immunity to electromagnetic interference

-> Resistance to corrosive materials.

Disadvantages

-> Difficult to install and maintain

-> High cost

-> fragile

6. Wireless / Unguided Media:

It is also referred to as wireless or unbounded transmission media. No physical medium is required for the transmission of electromagnetic signals.

ries! Signal 98 broad casted through air.

Thess Secure.

-> Used for clarger distances.

There are three major types of unquided media:

Radiowaves - These are easy to generate and can penetrate through buildings. The sending and receiving antennas need not to be aligned. Frequency range: 3KHz-1GHz. AM and FM radios and cordless phones use Radiowaves for transmission.

Mcrowaves > It is a line of sight transmission i.e, the sending and receiving antennas need to be properly aligned to each other. The distance covered by the signal is directly proportional to the height of the antena. Frequency Range: 16xHz - 300 GHz. These are majorly used for mobile phone communication and television distribution.

@ Crowt, Message & Packet Switching:-

Whenever we are dealing with a large network or say a very long-distance data transmission has to take place, this can't be done directly without any external hardware support. Hence, we must have a dedicated path for our data packets to traverse. Since there are so many choices for which path to take, so we have to select a particular path. This selecting of the path on which our data packets will be transmitted as known as Switching. We can categorize and sub-categorize the switching techniques as below.

1). Circuit Switching:—The circuit switching technique establishes a dedicated path or channel between the sender and receiver for data transmission, and once a dedicated until and unless the connection between the two data transmission point terminates.

manner an which a telephonic network operates when we call someone, then a dedicated communication remains open tell we disconnect the phone call.

perform multiplexing multiple signals into a single

• Frequency Division Multiplexing (FDM) -> We use FDM when multiple data signals are combined for simultaneous data transmission. through a shared communication channel. It divides total bandwidth into a series of non-overlapping frequency sub-bands, where each sub-band carries a different signal for data transmission. Radio transmission and optical fiber transmission to share multiple independent signals is its example.

Time Division. Multiplexing (TDM) - It divides the data transmission into time frames. It transmitts and receives andependent signals over a common communication channel through synchronized switches. at each end of the transmission line. This technique is widely used for long-distance communication links and also supports heavy data traffic loads from both the ends.

Infrared + Infrared waves are used for very short distance communication. They cannot penetrate through obstacles. This prevents interference between systems. Frequency Range: 300 GHz - 400 THz. It is used in TV remotes, wireless mouse, keyboard, printer etc.

Ethernet Cable Standards: Aso called twisted pair cables of Ethernet capper twisted pair cables are broadly classified into two: Unshielded Twisted Pair (UTP) cable, and Sheilded Twisted Pair (STP) cable, thes cables are used for different shielding techniques to limit any signal from the cable or wire to escape and to reduce, electromagnetic interface from outside environment.

1) UTP I These two are already discussed.

B. Fiber Cable Standards:

Feber cable standards are mainly of two types: multimode and singlemode, which are as follows:-

IFC/ISO 11801	Multimode OM1, OM2, OM3, OM4	Singlemoo	
IEC 60793-2 ITU-T	(A16), (A1a), (A1a.2), (A1a.3). G.651, G.651, G.651, G.651	-50	-50 (B1.2) G1.652.D
TIA-492	AAAA AAAB AAAC AAAD	CAAA	CAAB.

Advantages:

-> Establishment of a dedicated channel.

> Improves data transmission rate.

-> Improves data loss.

-> Improves delay on the data flow.

Disadvantages:-

> Establishing a dedicated channel sometimes takes a very long duration of time.

The amount of bandwidth required is more for establishing a dedicated channel.

2). Message Switching: This technique was developed to act as an alternative to circuit switching. In this technique data is transmitted in form of messages which consist of entire data to be shared. Unlike circuit switching there's no dedicated path between the sender and the receiver, hence they are connected through several intermediate nodes which helps and ensures proper data transfer. They have 2 important characteristics:

Store & forward > Each node must have a storage capacity, because a message will only be delivered if the next node and the link between them are available to connect otherwise it will be stored and efinitely. A store and forward switch are available and the next node is ready to accept the data. This was earlier used in telegraph message switching centres.

Message delivery the entire information as compiled anto a source to destination. To successfully reach it destination at the routing information and Advantages:

> Stores the message when the next node as not available.

→ Data channels are shared by network devices.

→ Manages traffic efficiently by assigning priorities.

Disadvantages:

-> Storing of message causes delays,

-> The whole network require a large storage capacity.

The packet switching:

The packet switching technique transmits data through the network by breaking it down into several data packets for more efficient transfer and it also utilizes multiple vacant resources, these network devices direct or route the data packets to the destination where the receiving device then collects all of them and ressembles to get the proper orientation of message.

Connectionless Packet Switching: This technique consists of multiple data packets, each data packet is individually routed, means every single data packet contains complete routing information in this header section. This kind of packet switching technique is also known as Datagram switching. In this type of packet switching the data-packets are first assembled and then sequentially numbered. Now they are ready to travel across a predefined route sequentially. The information about the address is not required here, because all the data packets are sent in sequence. This technique is also known as Virtual Circuit switching.

Advantages:

> Highly efficient

-> faster

-> Cost-effective.

> Digital

-> Rebable

ISON stands for Integrated Services Digital Newsork. It 115 circuit-switched telephone network system, but it also provides access to packet switch networks that allows digital transmission of voice, and data. This results in potentially better voice and data quality than an analog phone can provide!

It provides a packet-switched connection for data Increments of 64 kelobots. It provided a maximum of 128 kilobots bandwidth in both upstream and downstream directions. A greater data rate was achieved through channel bonding.

ISON Interfaces:-

1). Basic Rate Interface (BRI) - There are two data-bearing channels ('B' channels) and one signaling channel (D' channel) an BRI to anitate connections. The B channels operate at a maximum of 64 Kbps while the D channel operates at maximum of 16 kbps. The two channels are andependent of eachother.

98). Primary Rate Interface (PRI) -> Primary Rate Interface service consists of a D channel and either 23 or 30 B channels depending on the country you are in. PRI is not supported on the issues. A digital pipe with 23 B channels and one 64 kbps D channel is present in PRI. PRI requires a digital pipe of 1.544 Mbps.

919 Broadband-ISDN (B-ISDN) -> Narrowband ISDN has been designed to operate over the current communications Infrastructure, which is heavely dependent on the copper cable however B-ISDN releas mainly on the evolution of fiber optics. According to CCITT, B-ISDN 4s best described as "a service regulting transmission channels capable of supporting rates greater than the primary rate."

The ISDN works based on the standards defined by ITU-T (formally CCITT). The Telecommunication Standardization Sector (ITU-T) coordinates standards for telecommunications on behalf of the International Telecommunication Union (ITU) and is based on Greneva, Switzerland. The various principles of ISDN as per ITU-T recommendation are:

To support switched and non-switched applications.

To support voice and non-switched applications.

Reliance on 64-klops connections.

Intelligence on 64-klops connections.

Layered protocal architecture.

Variety of configurations.