

B76 Front brake light switch
B77 Rear brake light switch
E60 License plate lamp
P36 Brake/tail light



Turn signal relay
Turn signal indicator lamp
Turn signal, front left
Turn signal, front right
Turn signal, rear left
Turn signal, rear right
Light switch, horn button, high beam flasher button, turn signal switch



B33 Radiator fan temperature switch


B35 Oil pressure sensor

F4 Fuse F8 Fuse

M14 Radiator fan

P27 Oil pressure warning lamp

X293 Connector for accessory ground (terminal 31) ACC 2 (not assigned)
 X294 Connector for accessory plus (terminal 15) ACC 2 (not assigned)




A11 Engine electronics control unit

B80 Throttle grip

F2 Fuse

M20 Evaporate emission control valve

M21 Secondary air system valve
M51 Injection valve, cylinder 1
M60 Throttle valve actuator
R51/1 Ignition coil 1, (cylinder 1)
R51/2 Ignition coil 2, (cylinder 1)



A11	Engine electronics control unit
B12	Intake air temperature sensor
B21	Coolant temperature sensor, cylinder 1
D00	Object of the condition in

B38 Clutch switch

B51 Lambda sensor (cylinder 1)
P10 Combination instrument

