Search this site

Embedded Files

Skip to main content

Skip to navigation

CabinetSense Wiki

- Home
- 32mm System
- Build History
- Closet Systems
- CNC
- Common Attributes
- Component Library
- Components
- Construction Templates
- Cutlist Plus Integration
- Dynamic User Components
- Elevation and Plan Dimensions
- Frequently Asked Questions
- Known Issues

Menus

- CabinetSense Menu
- CNC Menu

Component Menu

- Align
- Apply Construction Profile
- Change Door/Drawer Front/Panels
- Change Height
- Change Palette
- Change Reveals
- Choose New Drawer System
- Choose New Handle
- Component Options
- Create Connector
- Equalize Door and Drawer Front Heights
- . 🗐
- Hide/Unhide
- Horizontal Cabinet Openings
- Make Unique
- Private Laver
- Reconnect
- Redraw
- Resize
- Toggle Closet Backs
- Toggle Door Opening
- Toggle Number of Doors
- I ransform
- Vertical Cabinet Openings
- Document Menu
- Help Menu
- Profiles Menu
- Scene Menu
- Toolbars
- Plugins, Programs, and Links
- Scene and Layer Managemen
- Shop and Submittal Drawings
- Sketchup Tutorials
- Tips and Tricks

- Troubleshooting
- Tutorials
- Videos

CabinetSense Wiki

Align

CabinetSense maintains an Alignment indicator on every component in your model. When a components alignment is on, CabinetSense will align it according to the individual rules set for that component. When off, CabinetSense will bypass aligning this component, and it will prevent other components from aligning to it as well.

Usage

single component

Page updated Report abuse