Skip to navigation

CabinetSense Wiki

- Home
- 32mm System
- Build History
- Closet Systems
- CNC
- Common Attributes
- Component Library
- Components
- Construction Templates
- Cutlist Plus Integration
- Dynamic User Components
- Elevation and Plan Dimensions
- Frequently Asked Questions
- Known Issues

Menus

- CabinetSense Menu
- CNC Menu
- Component Menu

Document Menu

- Add Inside Dimensions
- Add Outside Dimensions
- Change Prefix
- Clear Dimensions
- Clear Part Numbers
- Dimension Preferences
- Find Part Number
- Renumber Parts
- Send to Lavour
- Show Part Numbers
- · Help Menu
- Profiles Menu
- Scene Menu
- Toolbars
- Plugins, Programs, and Links
- Scene and Laver Management
- Shop and Submittal Drawings
- Sketchup Lutorials
- Tips and Tricks
- Troubleshooting
- Tutorials
- Videos

CabinetSense Wiki

Change Prefix


The Change Prefix request allows you to change some or all of your comonents part number prefix.

CabinetSense will handle multiple prefixes in you model separately with each prefix being assigned numbers starting from 1 (one). You may consider using this when:

- you have multiple rooms in your model and you would like to have separate numbering for each room.
- You have an island that you wish to number separately from the main run of cabinets.


Usage: One or more components must be selected.

... Example ...




... requesting a new prefix for the Island ...

(notice that the 3 island cabinets have been selected)




... Change Prefix Dialog is presented ...

(We have entered "2" as the new prefix)



... after requesting to show part numbers ...



Page updated Report abuse