Search this site

Embedded Files

Skip to main content

Skip to navigation

CabinetSense Wiki

- Home
- 32mm System
- Build History
- Closet Systems
- CNC
- Common Attributes
- Component Library
- Components
- Construction Templates
- Cutlist Plus Integration
- Dynamic User Components
- Elevation and Plan Dimensions
- Frequently Asked Questions
- Known Issues

Menus

- CabinetSense Menu
- CNC Menu

Component Menu

- Align
- Apply Construction Profile
- Change Door/Drawer Front/Panels
- Change Height
- Change Palette
- Change Reveals
- Choose New Drawer System
- Choose New Handle
- Component Options
- Create Connector
- Equalize Door and Drawer Front Heights
- . 🗐
- Hide/Unhide
- Horizontal Cabinet Openings
- Make Unique
- Private Laver
- Reconnect
- Redraw
- Resize
- Toggle Closet Backs
- Toggle Door Opening
- Toggle Number of Doors
- I ransform
- Vertical Cabinet Openings
- Document Menu
- Help Menu
- Profiles Menu
- Scene Menu
- Toolbars
- Plugins, Programs, and Links
- Scene and Layer Managemen
- Shop and Submittal Drawings
- Sketchup Tutorials
- Tips and Tricks

- Troubleshooting
- Tutorials
- Videos

CabinetSense Wiki

Private Layer

This operation moves the selected component between the public and private layer for the scene that you are on.

Items on the private layer are only viewable on the scene that the layer belongs to. Items that are public are visible on all scenes in the model.

Usage:

• Single Component

Page updated Report abuse