Skip to navigation

## CabinetSense Wiki

- Home
- 32mm System
- Build History
- Closet Systems
- · CNC
- Common Attributes
- Component Library
- Components
- Construction Templates
- Cutlist Plus Integration
- Dynamic User Components
- Elevation and Plan Dimensions
- Frequently Asked Questions
- Known Issues
- Menus
- Plugins, Programs, and Links
- Scene and Layer Management
- Shop and Submittal Drawings
- Sketchup Tutorials

Tips and Tricks

- Bifold Doors Graphical Only
- Combined Components
- Placing Cutters
- **Pullout Drawer**
- Using Hidden Walls
- Troubleshooting
- Tutorials
- Videos

## CabinetSense Wiki

Using Hidden Walls

If you have ever wanted to draw cabinets that don't align to visible walls, here is a tip that might be what your looking for:

- Start by drawing the walls you want represented in your drawings
- Turn off alignment for the walls you do not want cabinets to align to
- Draw a wall where you do want cabinets aligned. This will become the hidden wall.
- Right click on the wall to hide and select unlock.
- · Right click again and select hide
- Now update your scenes. For every scene the wall is visible right click it, hide it, and update the scene.
- Now you can bring in cabinets and they will align to the hidden wall

Hint: if you want to see the wall while you are designing you can turn on hidden geometry in the view menu Here is a video showing this process:

Page updated Report abuse