

## For USB Interface Only, Windows OS

- 1. Open Device Manager. (Windows Control Panel->System->Device Manager)
- 2. Right click the device(USB Serial Port recognized) and select **Properties**.




3. Select the Port Settings tab. Then select Advanced.





4. Adjust Latency Timer to 1ms for better real-time performance. Select OK.



Robotous, Co. Head office & Factory

2<sup>nd</sup> F, NEX-Center SKnTechnopark 124, Sagimakgol-Ro, Jungwon-gu, Seongnam-si, Gyeonggi-do, KOREA Tel:82-31-776-2644 Fax:82-31-782-3277 www.robotous.com | support@robotous.com

