Topnet Connection Troubleshooting Guide.

Read the modem lights first. The PON light shows the fibre link and the LOS light shows a loss of signal. Steady green PON with no LOS means the fibre is fine and the fault is elsewhere. A red or blinking LOS light means the fibre signal is lost, which is a line fault and needs a technician.

No internet, lights normal. Restart the modem by unplugging it for 30 seconds and waiting 3 minutes for it to re-synchronise. If devices connect to Wi-Fi but have no internet, connect a computer directly to the modem with an ethernet cable: if that works, the problem is the Wi-Fi, not the line.

Slow speeds. Test speed on a wired connection before reporting it, as Wi-Fi speed depends on distance, walls and interference. Move the modem away from walls, mirrors and other electronics, keep it off the floor, and use the 5 GHz band for devices close to it and the 2.4 GHz band for those further away. Streaming, downloads and other devices on the same line share the bandwidth.

Wi-Fi keeps dropping. Change the Wi-Fi channel in the modem interface, which is reached at 192.168.1.1 with the credentials printed on the modem label. Neighbouring networks on the same channel are the most common cause in apartment buildings.

Intermittent drops at the same time each day. This usually indicates congestion or a faulty cable. Note the times and report them, as the pattern helps the technician find the cause.

Before calling support. Note the modem light pattern, whether a wired connection also fails, when the problem started, and whether it affects all devices. This lets support skip the basics and diagnose faster.