Test mode and testing methods:

Deep sleep:

1.Reset board 2.Enter the command "tickless" in the command line.

DTIM:

- 1.Reset board
- 2. Connect wifi, and got ip.
- DTIM = 1: Enter the command "tickless 1" in the command line.
- DTIM = 3: Enter the command "tickless 3" in the command line.
- DTIM = 10: Enter the command "tickless 10" in the command line.

Benchmark:

Mode	uA
Deep sleep	50
DTIM = 1	770
DTIM = 3	348
DTIM = 10	156