

CREATE A WORK PERMIT REQUEST



QUICK REFERENCE GUIDE (QRG)


Helpful Hints

- Permit Request identifies any potential upcoming work that will require a safe work permit. Allows the Maintenance, Construction, and Turnaround groups to plan and prepare for the work.
- A Permit Request is considered incomplete until all required rescue plan, confined space, and forms have been
 obtained and approved. Once a Permit Request has been validated as complete it can be submitted as a Safe
 Work Permit.
- A Permit Request can span multiple days, with a new Work Permit being generated each day/shift.

Procedure



- 1. On the navigation pane, click on the Safe Work Permit icon Safe Work to navigate to the Permits screen.
- 2. Click on the **Permit Requests** tab Permit Requests (located on the top of your screen) to select it.
- 3. Click on the **New** button volume to open a new Permit Request. Complete the fields as required.





CREATE A WORK PERMIT REQUEST



QUICK REFERENCE GUIDE (QRG)

- a) **Select** the **Trade** (i.e. occupation) that will be completing the work.
- b) **Select** who the work is **Requested By** (i.e. Maintenance, Construction, Turnaround, Outage). This will be used to help users categorize and filter what Permit Request/Work Permits to view in the grid.
- c) Select the Permit Type (i.e. Hazardous Cold Work, Hot Work, Vehicle Entry).
- d) Click the Browse button to select the Functional Location of where the work will be occurring.
- e) Enter the Requested Start and End Date/Time of the permit.



Permit Request can span multiple days with OLT generating a Work Permit each day.

Depending on which shift the Work Permit should be generated for, select either the Day and/or Night checkboxes. Selecting both will cause OLT to generate two Work Permits, one for each shift.

f) For the Form Requirements section Select any forms that will need additional approvals (i.e. High Energy, Critical Lift, Excavation, etc.) prior to submission.



Any forms set to "Required" must be changed to "Approved" once the all approvals have been received otherwise the Permit Request cannot be submitted as a Work Permit.

- g) Enter the scope of work in the Task Description text box.
- 4. Click on the Validate button to verify the form to identify/address any error(s) or warning(s) found.



All **Errors** • must be correct before the **Permit Request** can be saved. Any **Warnings** • must be addressed before the form will be considered complete and ready for submission as a **Work Permit**.

5. Click on Save & Close to save your work and close the Permit Request window.