

QUICK REFERENCE GUIDE (QRG): VIEW EDIT HISTORY OF A LAB ALERT DEFINITION IN THE OLT



Purpose of this QRG

To teach you how to view the edit history of a Lab Alert Definition in the OLT

Intended Audience for this QRG

All roles (Oil Sands) in the OLT

Purpose of Lab Alert Definitions in the OLT

• To describe the schedule, in the OLT, by which lab samples need to be taken and evaluated

Prerequisites

- You must have access to the OLT software application
- You must have a role in the OLT (Oil Sands) to complete the procedure described below

Helpful Hints

- An audit trail containing the user name, time and date, and details of any changes made will be included in the item's edit history
- The "View History' function in the OLT is primarily intended for information/auditing purposes

Procedure



- 1. On the navigation pane, click Lab Alerts icon
- to navigate to the Lab Alerts screen.
- 2. Click Lab Alerts Definitions tab (located on the top of your screen)

 Lab Alert Definitions
 to navigate to the Lab Alerts Definitions screen.
- 3. Click in Lab Alerts Definition display grid to select/highlight the Lab Alert Definition you wish to view the history for.
- 4. Click History button (located on the middle of your screen) to navigate to the Lab Alert Definition Historical View screen.
- 5. In the top portion of the window, select the user and/or time of changes you're interested in.
- 6. View the details of the selected user's changes for that time in the bottom portion of the window.
- 7. Click Close button to close the Lab Alert Definition Historical View screen once you are finished viewing.

Last updated: May 10, 2011 Page 1 of 1