



VEGETABLE PEELER

USER MANUAL

Thank you for choosing AMNEXA.
Read this manual carefully before use and
keep it for future reference.



PREMIUM QUALITY

Built for durability,
precision & effortless
peeling.



PRODUCT OVERVIEW

The AMNEXA Vegetable Peeler is designed for quick,
efficient and effortless peeling of vegetables and fruits.
Its sharp stainless steel blade ensures smooth peeling
with minimal wastage.

FEATURES



ULTRA SHARP BLADE

Precision stainless steel blade for smooth
and effortless peeling.



PREMIUM STAINLESS STEEL

Rust-resistant, durable and built to last.



ERGONOMIC HANDLE

Comfortable grip for better control
and ease of use.



EASY TO CLEAN

Dishwasher safe and easy to rinse
under running water.



HANGING LOOP

Convenient storage with built-in
hanging loop.

HOW TO USE



- 1 Hold the peeler firmly
by the handle.



- 2 Place the blade on the surface
of the vegetable or fruit.
Gently pull or push in the
direction of the blade.



- 3 Repeat as needed for a
clean and smooth peel.



TIP: Best results when used with
fresh and firm vegetables or fruits.

CARE & CLEANING



Rinse under running water immediately after use.



Use mild dish soap and a soft sponge to clean.



Dishwasher safe (top rack recommended).



Dry thoroughly before storing.

SAFETY PRECAUTIONS



- Keep out of reach of children.
- Handle with care. Blade is very sharp.
- Do not touch the blade edge.
- Use only for its intended purpose.
- Store in a dry place.



**BUILT TO LAST.
MADE TO PERFORM.**

Thank you for choosing AMNEXA.



CUSTOMER SUPPORT

We are here to help!

☎ 05944369294

✉ info@amnexa.in

🌐 www.amnexa.in



SCAN FOR MORE

Scan the QR code to view
detailed usage guide,
care instructions and
more.