Holy City Audio Forum

Former Home of SpinCAD Designer

Skip to content

Search…   Search

Advanced search

[Moderator Control Panel]

Deleting a connection

Post a reply

Search this topic…   Search

2 posts • Page **1** of **1**

- Edit post (./posting.php?mode=edit&f=32&p=1602)
- Delete post (./posting.php?mode=delete&f=32&p=1602)
- Report this post (./report.php?f=32&p=1602)
- Information (./mcp.php?i=main&mode=post_details&f=32&p=1602&sid=020ce5cde84f10b251dd20b61e021a39)
- Reply with quote (./posting.php?mode=quote&f=32&p=1602)

Deleting a connection (#p1602)

by **Digital Larry** » Tue Jun 03, 2014 11:15 am

To delete a connection, right-click on the pin (circle) which is the "destination" of that connection.

Top

- Edit post (./posting.php?mode=edit&f=32&p=1604)
- Delete post (./posting.php?mode=delete&f=32&p=1604)
- Report this post (./report.php?f=32&p=1604)
- Warn user (./mcp.php?i=warn&mode=warn_post&f=32&p=1604&sid=020ce5cde84f10b251dd20b61e021a39)
- Information (./mcp.php?i=main&mode=post_details&f=32&p=1604&sid=020ce5cde84f10b251dd20b61e021a39)
- Reply with quote (./posting.php?mode=quote&f=32&p=1604)

Re: Deleting a connection (#p1604)

by **disasterarea** » Tue Jun 03, 2014 2:13 pm

Yay! I've needed this OFTEN.

Top

Display posts from previous: All posts   Sort by   Post time   Ascending   Go

Post a reply

2 posts • Page **1** of **1**

Return to Installing and Using SpinCAD Designer

Jump to: Installing and Using SpinCAD Designer   Go

Quick-mod tools: Lock topic   Go

Who is online

Users browsing this forum: Digital Larry and 0 guests

Powered by phpBB® Forum Software © phpBB Group

Administration Control Panel