Holy City Audio Forum

Former Home of SpinCAD Designer

Skip to content

Search... Search

Advanced search

[Moderator Control Panel]

Overdrive

Post a reply

Search this topic... Search

2 posts • Page 1 of 1

- Edit post (./posting.php?mode=edit&f=31&p=1888)
- Delete post (./posting.php?mode=delete&f=31&p=1888)
- Report this post (./report.php?f=31&p=1888)
- Warn user (./mcp.php?i=warn&mode=warn_post&f=31&p=1888& sid=befaf904784df501ab581b011c284453)
- Information (./mcp.php?i=main&mode=post_details&f=31&p=1888& sid=befaf904784df501ab581b011c284453)
- Reply with quote (./posting.php?mode=quote&f=31&p=1888)

Overdrive (#p1888)

by Rebel_88 » Wed Oct 15, 2014 7:59 am

Hi I'm trying to build an overdrive, this is my frist attempt with **version 0.96 Build 837** Is it correct how i'm using the clip block?

Any suggestion to improove the sound or getting more sustain? I hope it is useful.

Attachments

Overdrive.rar (./download/file.php?id=86)

(3.01 KiB) Downloaded 14 times

Top

- Edit post (./posting.php?mode=edit&f=31&p=1889)
- Delete post (./posting.php?mode=delete&f=31&p=1889)
- Report this post (./report.php?f=31&p=1889)
- <u>Information (./mcp.php?i=main&mode=post_details&f=31&p=1889&</u> sid=befaf904784df501ab581b011c284453)
- Reply with quote (./posting.php?mode=quote&f=31&p=1889)

Re: Overdrive (#p1889)

by Digital Larry » Wed Oct 15, 2014 9:20 am

The Clip block is mostly intended for saturating control signals when using a single control for two things at once. For example, using the clip control with gain = 2 on a control signal would make that control go to 1.0 when the pot was only halfway up. It might work for audio but I haven't tried it. My initial suggestion though is to take the clipping stages out. They slam directly into the limit, whereas the overdrive does so gradually, resulting in a less harsh sound. If you want a harsh sound use the Distortion block instead, or just the Gain Boost.

I'd start by going into the **Overdrive** control panel and turning up the input gain and # of stages.

If you are still not getting any grit then put a Gain Boost in front of the Overdrive.

1 of 2 11/26/2019, 7:10 AM

These level sensitive blocks depend a lot on the signal level going into the FV-1, so it's not possible to construct a one-size-fits-all patch for them.

Also note that the **Minimum Reverb** block control input will probably start oscillations at about 0.4 - I'd recommend a scale/offset before the **Reverb Time** control input to keep this under control.

тор						
Display posts from previous:	All posts	Sort by	Post time	Ascending	Go	
Post a reply						
2 posts • Page 1 of 1						
Return to SpinCADBlocks						
Jump to: SpinCADBlocks		Go				
Quick-mod tools: Lock topic		Go				

Who is online

Users browsing this forum: Digital Larry and 0 guests Powered by phpBB® Forum Software © phpBB Group

Administration Control Panel

2 of 2