
What is Drostrossed Constate?
What is Prestressed Concrete?
The concrete gives excellent strength and enough durability for the structure. We also
know the usage of steel in concrete. There is no doubt!
But why do we need Prestressed Concrete ?
You may see the crack formation under the concrete element after completion of the
structure. It is happening due to the load applied on the concrete top surface after
hardened, as shown in the below picture.

What Is Meant By Prestressed Concrete? [Detailed Discussion]



Initially, the concrete element deforms at the mid-portion and, after a long run, the crack forms on the concrete.

We can rectify those issues for small scale structures using chemical mixtures. But It becomes difficult for large scale structures such as bridges, dams, and high rise buildings. The rectifying cost also becomes very expensive.

The prestressed concrete technology has been introduced to prevent those issues from happening on large structures.

What is meant by prestressed concrete?

High tensile stress-induced artificially on the reinforcement bars of concrete before the placement is called prestressed concrete. After completion of structure work, It helps the concrete to detain the shrinkage crack formation.



Principle of prestressed concrete

As above said, the steel reinforcement bars are stretched before the use of concrete. So when the load is applied to the concrete, it resists the formation of cracks on the concrete.

Prestressed steel technology is already in use for decades.



You may be aware of the wine wood barrels tied in peripheral by the steel band, which is already prestressed. The liquid stored in the barrel creates pressure to the surface, which the steel band resists and prevents the barrel from breaking.


Methods of Prestressing

The prestressed concrete is attained in two methods such as

- Pre tensioning
- Post-tensioning

Pre tensioning

Pre Tensioning is done by stressing the wires or strands in the concrete to a predetermined stress level before pouring the concrete in place. The steel tendons are tensioned using a rigid block at one end and a hydraulic jack at the other end, which is used for anchorage. Please refer to the below pic.




After completion of concrete pouring, the reinforcement bars are released when the concrete attains the hardened stage. Now the steel tries to shrink due to concrete stress. Since the steel has already been stressed out to its max, further movement of steel has been barred to avoid the cracks.

The concrete used for pre-tensioning should have a minimum 28 days compressive strength of 40 N/Sqmm as per IS 1343.

Post Tensioning

The post-tension has been done after the hardened state of concrete. The reinforcement is placed with the desired groove or hole throughout the concrete.



When the concrete attains sufficient strength, the tensioning of the steel bar would be done by a jacking device. After the tensioning, the gap in the groove will be grouted thoroughly to prevent steel corrosion.

When pre-tensioning is impossible for some cases like lack of heavy element transportation for large bridges to transport the heavy precast elements, post-tensioning methods will be used.


The concrete used for post-tension should have a minimum 28 days compressive strength 30 N/Sqmm as per IS 1343.

Application of prestressed concrete

- The prestressed concrete method is suitable for medium and long-span structures
 where the construction cost of tensioning is a small percentage out of the whole job.
- High mast towers, tall towers, railroads can be constructed by this method.
- It is used to build the marine structure and offshore projects.
- It is suitable for aircraft hangar construction.

Materials used in Prestressed Concrete

The material manipulating in prestressed concrete should have good quality and strength.



Concrete – High grade of concrete should be used in prestressing, impermeability, durability, and abrasion resistance. The concrete should possess high compressive strength.


The concrete ingredients should be free from dust and other marine impurities, which will affect the strength of concrete, and it may lead to the formation of shrinkage crack.

The proper water-cement ratio should be used to prepare the concrete and, if required, admixture can be used.

Lightweight aggregates – The lightweight aggregate density should range between 1450 to 1750 Kg/cum. So the self-weight of the structure is reduced, and also it reduces the usage of steel reinforcement.

But the main drawback of using lightweight aggregates is the loss of prestressing is high due to the higher elastic deformation.

High Tensile Steel – High tensile strength steel bars should be used in prestressed concrete. High tensile strength steel is manufactured by using wires, bars, or strands. The following combination of steels are used as reinforcement in prestressed concrete.



- Wires A single lengthy steel element.
- Strands A combination of more than two wires.
- Tendon A group of strands or wires.
- Cable A group of tendons.
- Bars It is the same as wire, but the bar's diameter is greater than the wire.

Advantages of Prestressed concrete

- It is economical for a long span structure.
- It increases the ability of the concrete for energy absorption against sudden impact load.
- It reduces the cycle of construction period in precast structure construction.
- Prestressed concrete resists the shear failure well compared to the regular concrete.
- By using prestressed concrete, the dead load will be reduced, and it will indirectly reduce the usage of steel.
- A smooth flat surface of the slab will provide a great aesthetic.

Difference between prestressed concrete and reinforced concrete

The prestressed concrete is different from the conventional reinforced concrete, and already we have discussed the difference between prestressed concrete and reinforced concrete.