

There are mainly two types of Basic Cellular System:

## LCircuit Switched:


In a circuit-switched system, each traffic channel is dedicated to a user until its cell is terminated.

2.Packet Switched:
In packet-switching, the packets are sent towards the destination irrespective of each other. Each packet has to find its own route to the destination. There is no predetermined path; the decision as to which node to hop to in the next step is taken only when a node is reached. Each packet finds its way using the information it carries, such as the source and destination IP addresses.

## **Analog Circuit-Switched System**

A basic analog cellular system consists of three subsystems: 1. A Mobile Unit

- 2. A Cell Site
- 3. A Mobile Telephone Switching Office (MTS0) with CONNECTIONS to link the three subsystems



## **Analog Circuit-Switched System**

