# PrimeTime® Distributed Multi-Scenario Analysis User Guide

Version C-2009.06, June 2009

SYNOPSYS®

# **Copyright Notice and Proprietary Information**

Copyright © 2009 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

#### **Right to Copy Documentation**

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

"This document is duplicated with the permission of Synopsys, Inc., for the exclusive use of	
and its employees. This is copy number	,,,

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### Registered Trademarks (®)

Synopsys, AMPS, Astro, Behavior Extracting Synthesis Technology, Cadabra, CATS, Certify, CHIPit, Design Compiler, DesignWare, Formality, HDL Analyst, HSIM, HSPICE, Identify, iN-Phase, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Physical Compiler, PrimeTime, SCOPE, Simply Better Results, SiVL, SNUG, SolvNet, Syndicated, Synplicity, Synplify Pro, Synthesis Constraints Optimization Environment, TetraMAX, the Synplicity logo, UMRBus, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

#### Trademarks (™)

AFGen, Apollo, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, BEST, Columbia, Columbia-CE, Confirma, Cosmos, CosmosLE, CosmosScope, CRITIC, CustomSim, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, DesignPower, DFTMAX, Direct Silicon Access, Discovery, Eclypse, Encore, EPIC, Galaxy, Galaxy Custom Designer, HANEX, HAPS, HapsTrak, HDL Compiler, Hercules, Hierarchical Optimization Technology, High-performance

ASIC Prototyping System, HSIM plus in invitable some plus in invitable some plus plus in invitable some plus plus in invitable some plus invitable some plus in invitable some plus in invitable some plus in invitable some plus invit

# Service Marks (<sup>SM</sup>)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license. ARM and AMBA are registered trademarks of ARM Limited. Saber is a registered trademark of SabreMark Limited Partnership and is used under license. All other product or company names may be trademarks of their respective owners.

	What's New in This Release	viii
	About This User Guide	viii
	Customer Support	×
1.	Distributed Multi-Scenario Analysis	
	Introduction	1-2
	Definition of Terms	1-2
	Multi-Scenario Flow Overview	1-4
	Before You Begin	1-4
	Setting Your Search Path	1-4
	.synopsys_pt.setup File	1-5
	Usage Flow	1-5
	Distributed Processing Setup	1-8
	Invoking PrimeTime for Distributed Processing	1-8
	Compute Resource Management	1-9
	Adding Distributed Hosts	1-9
	Creating a Distributed Farm	1-11
	License Resource Management	1-12
	Incremental License Handling	1-14
	License Spanning	1-15
	License Auto-Reduction	1-15
	Database Support	1-15
	Scenarios	1-16
	Removing Scenarios	1-17

1-18 1-18 1-18
1-20 1-22
1-23
1-23 1-23 1-24 1-24 1-25 1-26
1-29 1-30 1-30 1-30 1-32 1-33 1-35
1-40 1-41 1-41 1-42 1-42
1-42 1-43 1-43 1-44 1-44 1-44 1-45 1-45

	Command Output Redirection		
	Session Example		
	Activating CCS Timing Voltage Scaling		
	Limitations		
2.	Distributed Multi-Scenario Analysis Netlist Editing Support		
	Introduction		
	Editing the Netlist		
	Replacement Cell Lookup		
	Supporting ECO Commands		
Аp	pendix A. Master Command List		
	Configuration and Setup Commands		
	Process Setup Commands		
	License Setup Command		
	Analysis Focus Commands		
	Slave Context Commands		
	Distributed Multi-Scenario Analysis report_timing Options		
	Reporting Variables		
	Disallowed Commands		
Аp	pendix B. Procedure for Filing STARs for Multi-Scenario Analysis		
	Problems and Issues		
	Initial Problem Diagnosis		
	Diagnosing Large Test Cases		
	Diagnosing Small Test Cases		
	Transient Issues		
	Reproducible Issues		

Other Required Information	B-4
Hardware Setup and Loading Conditions	B-4
Multi-Scenario Environment	B-4
Your Environment	B-5
Appendix C. Differences Between Single-Core and Multi-Scenario Constraint Report	:s
Constraint Merging Operations	C-2
Printing Styles	C-3
Reporting Modes	C-5
Index	

# Preface

This preface includes the following sections:

- What's New in This Release
- About This User Guide
- Customer Support

#### What's New in This Release

Information about new features, enhancements, and changes, along with known problems and limitations and resolved Synopsys Technical Action Requests (STARs), is available in the *PrimeTime Release Notes* in SolvNet.

To see the PrimeTime Release Notes,

1. Go to the Download Center on SolvNet located at the following address:

https://solvnet.synopsys.com/DownloadCenter

If prompted, enter your user name and password. If you do not have a Synopsys user name and password, follow the instructions to register with SolvNet.

2. Select PrimeTime Suite, then select a release in the list that appears at the bottom.

#### **About This User Guide**

The *PrimeTime Distributed Multi-Scenario Analysis User Guide* describes how to setup a distributed multi-scenario analysis flow, explains compute and license resource management, describes the commands and variables used during the flow, and also explains the merged reporting features.

#### **Audience**

This user guide is for design engineers who use PrimeTime for static timing analysis.

#### **Related Publications**

For additional information about PrimeTime, see Documentation on the Web, which is available through SolvNet at the following address:

https://solvnet.synopsys.com/DocsOnWeb

You might also want to refer to the documentation for the following related Synopsys products:

- PrimeTime SI, PrimeTime PX, and PrimeTime VX
- Design Compiler
- Library Compiler

# **Conventions**

The following conventions are used in Synopsys documentation.

Convention	Description
Courier	Indicates command syntax.
Courier italic	Indicates a user-defined value in Synopsys syntax, such as <code>object_name</code> . (A user-defined value that is not Synopsys syntax, such as a user-defined value in a Verilog or VHDL statement, is indicated by regular text font italic.)
Courier bold	Indicates user input—text you type verbatim—in Synopsys syntax and examples. (User input that is not Synopsys syntax, such as a user name or password you enter in a GUI, is indicated by regular text font bold.)
[]	Denotes optional parameters, such as pin1 [pin2 pinN]
I	Indicates a choice among alternatives, such as low   medium   high (This example indicates that you can enter one of three possible values for an option: low, medium, or high.)
_	Connects terms that are read as a single term by the system, such as set_annotated_delay
Control-c	Indicates a keyboard combination, such as holding down the Control key and pressing c.
\	Indicates a continuation of a command line.
/	Indicates levels of directory structure.
Edit > Copy	Indicates a path to a menu command, such as opening the Edit menu and choosing Copy.

# **Customer Support**

Customer support is available through SolvNet online customer support and through contacting the Synopsys Technical Support Center.

# **Accessing SolvNet**

SolvNet includes an electronic knowledge base of technical articles and answers to frequently asked questions about Synopsys tools. SolvNet also gives you access to a wide range of Synopsys online services including software downloads, documentation on the Web, and "Enter a Call to the Support Center."

To access SolvNet, go to the SolvNet Web page at the following address:

#### https://solvnet.synopsys.com

If prompted, enter your user name and password. If you do not have a Synopsys user name and password, follow the instructions to register with SolvNet.

If you need help using SolvNet, click HELP in the top-right menu bar or in the footer.

# **Contacting the Synopsys Technical Support Center**

If you have problems, questions, or suggestions, you can contact the Synopsys Technical Support Center in the following ways:

- Open a call to your local support center from the Web by going to https://solvnet.synopsys.com (Synopsys user name and password required), and then clicking "Enter a Call to the Support Center."
- Send an e-mail message to your local support center.
  - E-mail support center@synopsys.com from within North America.
  - Find other local support center e-mail addresses at http://www.synopsys.com/Support/GlobalSupportCenters/Pages
- Telephone your local support center.
  - Call (800) 245-8005 from within the continental United States.
  - Call (650) 584-4200 from Canada.
  - Find other local support center telephone numbers at http://www.synopsys.com/Support/GlobalSupportCenters/Pages

# 1

# Distributed Multi-Scenario Analysis

You can have PrimeTime analyze several scenarios in parallel. The ability to process multiple scenarios in parallel is called distributed multi-scenario analysis. This chapter describes the distributed multi-scenario analysis capabilities, including the flow, setup, saving and restoring your session, and reporting.

- Introduction
- Multi-Scenario Flow Overview
- Distributed Processing Setup
- Distributed Analysis Process
- · Saving and Restoring Your Session
- Manipulating Variables
- Merged Reporting
- · Controlling Fault Handling
- · Messages and Log Files
- Session Example
- Activating CCS Timing Voltage Scaling
- Limitations

#### Introduction

Verifying a chip design typically requires several PrimeTime analysis runs to check correct operation under different operating conditions (such as extreme temperatures and operating voltages) and in different chip operating modes (for example, mission or test mode). A specific combination of operating condition and operating mode for a given chip design is called a scenario for that design. You can have PrimeTime analyze several scenarios in parallel, which is called distributed multi-scenario analysis.

You can have PrimeTime analyze several scenarios in parallel. The ability to process multiple scenarios in parallel is called distributed multi-scenario analysis.

Instead of analyzing each scenario separately, you can set up a master PrimeTime process that sets up, executes, and controls multiple slave processes, one for each scenario. You can distribute the processing of scenarios onto different hosts running in parallel, thus reducing the overall turnaround time to finish analysis of timing results from multiple scenarios. In addition, total runtime is reduced when you share common data between different scenarios.

A single script can control many scenarios, making it easier to set up and manage different sets of analyses. This capability does not use *multithreading* (breaking a single process into pieces that can be executed in parallel). Instead, it provides an efficient way to specify the analysis of different operating conditions and operating modes for a given design and to distribute those analyses onto different hosts. For descriptions of the distributed multi-scenario analysis commands, see Appendix A, "Master Command List.

#### **Definition of Terms**

The following terms are used to describe aspects of distributed processing:

#### baseline image

Image that is produced by combining the netlist image and the common data files for a scenario.

#### command focus

Current set of scenarios to which analysis commands are applied. The command focus can consist of all scenarios in the session or just a subset of those scenarios.

#### current image

Image that is automatically saved to disk when there are more scenarios than hosts and the slave process must switch to work on another scenario.

#### master

Manages the distribution of scenario analysis processes.

scenario

Specific combination of operating condition and operating mode.

session

Current set of scenarios selected for analysis.

slave

Started and controlled by the master to perform timing analysis for one scenario.

task


Self-contained piece of work defined by the master for a slave to execute.

Figure 1-1 shows the relationships between the configuration, scenarios, session, and command focus.

Figure 1-1 Configuration, Scenarios, Session, and Command Focus

Scenario A specified combination of operating condition and mode settings create\_scenario -name name \ -common\_data {scripts} \

-specific data {scripts}



current scenario {list}

in the session

current\_session {list}

A scenario describes the specific combination of operating condition and operating mode to use when analyzing the design specified by the configuration. There is no limit to the number of scenarios that you can create (subject to memory limitations of the master). Each scenario is created using the create\_scenario command. The command specifies the scenario name and the names of the scripts that apply the analysis conditions and mode settings for the scenario.

The scripts are divided into two groups: common-data scripts and specific-data scripts. The common-data scripts are shared between two or more scenarios, whereas the specific-data scripts are specific to the particular scenario and are not shared. This grouping helps the master process manage tasks and to share information between different scenarios, minimizing the amount of duplicated effort for different scenarios.

A session describes the set of scenarios you want to analyze in parallel. You can select the scenarios for the current session using the current\_session command. The current session can consist of all defined scenarios or just a subset of those scenarios.

The command focus is the set of scenarios affected by PrimeTime analysis commands entered at the PrimeTime prompt in the master process. The command focus can consist of all scenarios in the current session or just a subset of those scenarios. A subset of the scenarios in the current session can be specified using the current\_scenario command. By default all scenarios in the current session are in command focus, unless you change them.

#### **Multi-Scenario Flow Overview**

The following sections describe the basics of the multi-scenario flow.

# **Before You Begin**

Before you start your multi-scenario analysis, you must set the search path and create a .synopsys\_pt.setup file.

# **Setting Your Search Path**

In multi-scenario analysis, you can set the <code>search\_path</code> variable only at the master. When reading in the search path, the master resolves all relative paths in the context of the master. The master then automatically sets the fully resolved search path at the slave. For example, you might launch the master in the /remote1/test/ms directory, and set the <code>search\_path</code> variable with the following command:

```
set search_path ". .. ../scripts"
```

The master automatically sets the search path of the slave to the following:

```
/remotel/test/ms /remotel/test /remotel/ms/scripts
```

The recommended flow in multi-scenario analysis is to set the search path to specify the following:

Location of all files for your scenarios and configurations

 Location of all Tcl scripts and netlist, SDF, library, and parasitics files to be read in a slave context

Note:

For best results, avoid using relative paths in slave context scripts.

# .synopsys\_pt.setup File

The master and slaves both source the same set of .synopys\_pt.setup files in the following order:

1. PrimeTime install setup file at:

```
install_dir/admin/setup/.synopsys_pt.setup
```

2. Setup file in your home directory

```
~/.synopsys_pt.setup
```

3. Setup file in the master launch directory at:

```
$sh_launch_dir/.synopsys_pt.setup
```

You can use the  $pt\_shell\_mode$  variable to control whether commands are executed in the current pt\_shell mode. You can set the value of this variable to primetime,

```
primetime_master, or primetime_slave. For example,
```

```
.synopsys_pt.setup

if { $pt_shell_mode == "primetime_master" } {
    set multi_scenario_working_directory "./work"
}
```

# **Usage Flow**

To start PrimeTime in multi-scenario analysis mode, use the pt\_shell command with the -multi\_scenario option. From the pt\_shell prompt of the master PrimeTime process, you can initiate and control up to 256 slave processes (see "Limitations" on page 1-50). Figure 1-2 shows the sequence of steps in a typical multi-scenario analysis.

Start PrimeTime in multi-scenario mode Set the license usage limit 1 Repeat for each additional Add distributed computing resources (2) computing resource Create the distributed processing farm Slave processes started Repeat for each additional Create scenario scenario Select scenarios for session (5)Select scenarios in command focus (optional) 6 Remote execution of PrimeTime and merged Parallel processing of each (7)reporting commands scenario in command focus When parallel processing of scenarios is complete, (8)view analysis reports

Figure 1-2 Distributed Processing Usage Flow

A typical multi-scenario analysis has the following steps:

1. Specify the maximum number of PrimeTime or PrimeTime SI licenses for the slave processes to use by running the set\_multi\_scenario\_license\_limit command.

- 2. Add the slave hosts that are used as part of the distributed computing farm by running the add\_distributed\_hosts command. You can also add managed systems, such as LSF and GRD, to the distributed farm.
- 3. Optionally, you can configure the distributed environment by using the set\_distributed\_parameters command. For user configurations to take effect, you must issue the set\_distributed\_parameters command before the create\_distributed\_farm command. For more information, see the man page.
- 4. Create the distributed processing farm upon which the scenarios are executed by running the create\_distributed\_farm command.
  - You can use the <code>create\_distributed\_farm</code> command to dynamically manage and allocate your resources.
- 5. Create the scenarios with the create\_scenario command. Each create\_scenario command specifies a scenario name and the PrimeTime script files that apply the conditions for that scenario.

#### Note:

You must complete steps 1 through 4 before you can go to the next step. Otherwise, the current\_session command fails.

- 6. Select the scenarios for the session using the current\_session command. The command specifies a list of scenarios previously created with the create\_scenario command.
- 7. Optional—Change the scenarios in the current session that are in command focus, using the current\_scenario command. The command specifies a list of scenarios previously selected with the current\_session command. By default, all scenarios in the current session are in command focus.
- 8. Start processing in the scenarios by executing the remote\_execute or merged reporting command at the master.
- 9. When the processing of all scenarios by the slave processes is complete, you can view the analysis reports. You can find the reports generated by the remote\_execute command under the directory you specify for the multi\_scenario\_working\_directory variable, as described in "Distributed Processing Setup" on page 1-8. Alternatively, if you issue the remote\_execute command with the -verbose option, all information is displayed directly to the console at the master. All merged reporting commands output are displayed directly to the console at the master.
- 10.Use ECO commands to fix any timing violations.

#### Note:

You can use the distributed multi-scenario capability not only for timing analysis in PrimeTime and PrimeTime SI, but also for power analysis in PrimeTime PX. This dramatically reduces the turn-around time. For more information about using distributed multi-scenario in PrimeTime PX, see the Distributed Peak Power Analysis section in the *PrimeTime PX User Guide*.

# **Distributed Processing Setup**

For distributed processing of multiple scenarios, you must first invoke PrimeTime in distributed processing mode and define the scenarios. The scenarios are processed on a virtual distributed farm so you must specify the remote hosts to be part of the farm and create that distributed farm.

# **Invoking PrimeTime for Distributed Processing**

To invoke PrimeTime in distributed processing mode (master), use the -multi\_scenario option when you start pt\_shell:

```
% pt_shell -multi_scenario
```

PrimeTime starts up and displays the pt\_shell prompt just as in the single-core analysis mode. A multi-scenario analysis is carried out by one master PrimeTime process and multiple PrimeTime slave processes. The master and slave processes interact with each other using full-duplex network communications.

The master process generates analysis tasks and manages the distribution of those tasks to the slave processes. It does not perform timing analysis and does not hold any data other than the netlist and the multi-scenario data entered. The command set of the master is therefore restricted to commands for carrying out master functional capabilities. The following variable specifies the directory in which to store working files for distributed processing:

```
multi_scenario_working_directory
```

This variable should be set to the name of a directory that is write-accessible by you, the master process, and all slave processes. Typically, the slave processes are running on different hosts than the master, so the working directory needs to be network accessible, and therefore cannot be a local directory on the master. If you do not explicitly set this variable, the current working directory of the master is used.

#### Note:

You must set the multi\_scenario\_working\_directory variable before creating the distributed farm.

The multi\_scenario\_merged\_error\_log variable specifies the file in which to write all error, warning, and information messages issued by the slaves. Any error, warning, or information message that is issued by more than one slave is merged into a single entry in the merged error log. Each entry contains the scenario name from which the data originated. If a file is specified for this variable, it appears in the directory specified by the multi\_scenario\_working\_directory variable. For more information, see "Merged Error Log" on page 1-45. This variable limits the number of messages of a particular type written to the log on a per task basis. The default value is 100 (a maximum of 100 RC messages is written to the merged error log per task).

#### Note:

You must set the <code>multi\_scenario\_merged\_error\_log</code> variable before creating the distributed farm.

Upon startup, every PrimeTime process, both master and slave, looks for and executes the .synopsys\_pt.setup startup file just as in normal mode. Each process also writes its own separate log file. For more information, see "Log Files" on page 1-44.

# **Compute Resource Management**

You can dynamically manage your compute resources and allocate slave processes by adding hosts and creating farms. Managed computing resources allocate pooled computing resources as they become available. If an LSF, GRD or proprietary (generic) computing management capability is available for load balancing, you can allocate hosts from these systems to the virtual distributed farm used for processing scenarios.

The distributed processing mode supports the following hardware management architectures:

- LSF (Load Sharing Facility from Platform Computing, Inc.)
- GRD (Global Resource Director from Gridware, Inc.)
- Generic computing farm

Unmanaged computing resources are computed servers/workstations that are not load balanced, and are described as a Network Of Workstations. They can be added to the virtual distributed farm used for processing scenarios and are internally load balanced during multi-scenario analysis.

# **Adding Distributed Hosts**

You can allocate slave hosts to be used in the virtual farm using the add\_distributed\_hosts command. For example, suppose you have the following computing resources available for use:

• 20 processor 64-bit LSF farm

- 20 processor 32-bit GRD farm
- 8 processor 64-bit server/workstation
- 2 processor 32-bit server/workstation

If you want to add them all to the virtual distributed processing farm for multi-scenario analysis, you can specify this using the following syntax:

Each slave process invoked by the master is an ordinary invocation of PrimeTime except that only the master process can directly interact with these processes. It is not possible to manually launch a PrimeTime process in slave mode.

When the master begins the distributed multi-scenario analysis on the slaves, it generates tasks for the slave processes to execute. Any one task can apply to only one scenario and any one slave process can be configured for only one scenario at a time. If there are more scenarios than slave processes to host them, some slave processes have to swap out one scenario for another so that all tasks get executed.

The process of swapping out one scenario for another is an expensive, time-consuming operation. It is also important, however, to avoid overloading hosts by specifying more processes on a host than there are available CPUs in the host. If more processes are specified than there are CPUs available, a penalty is incurred for swapping in and out slave processes on a CPU. Therefore, the slave processes do not run concurrently.

For optimal system performance of the distributed multi-scenario mechanism, match the number of slave processes, the number of scenarios in command focus. and the number of available CPUs. Optimal system performance is achieved when every scenario is executed in its own slave process on its own CPU.

#### Note:

The add\_distributed\_hosts command allows you to specify the hosts you want to add to the virtual farm. Adding hosts to the farm, however, does not start any processes.

For more information about specifying processes, see the <code>add\_distributed\_hosts</code> man page.

# **Creating a Distributed Farm**

Generally, there is a time lag between when a remote host is launched and when it becomes available for use by the master process. This is especially noticeable when using managed resources, such as Load Sharing Facility (LSF) or Global Resource Director (GRD). Loading on the managed resource could incur long waiting times before the requested resources are made available.

To control the wait time for remote processes, use the <code>-timeout</code> and <code>-min\_hosts</code> options of the <code>create\_distributed\_farm</code> command. The <code>-timeout</code> option allows you to specify how long the <code>create\_distributed\_farm</code> command should wait for remote processes to become available. If you have not specified the <code>-timeout</code> option, a default time-out value of 21,600 seconds (6 hours) is used. The <code>-min\_hosts</code> option allows you to specify the minimum number of hosts needed to enable the <code>create\_distributed\_farm</code> command to return and allow execution to proceed.

The create\_distributed\_farm command completes when one of the following conditions is met:


- All remote host processes become available.
- If specified, the -min\_host minimum number of remote host processes becomes available.
- The time-out expires.

When the <code>create\_distributed\_farm</code> command returns, execution proceeds as long as at least one host is available. As additional remote processes become available during the analysis, they are dynamically made available for use to the analysis. If no remote processes were available when the <code>create\_distributed\_farm</code> command returns, an error is issued.

Although you can set the session to begin analysis when just one host is available, remember that the number of available hosts directly impacts the ability of PrimeTime to simultaneously analyze processes. When there is an imbalance between scenarios and hosts, expensive image swapping occurs until sufficient hosts become available for each scenario to occupy a remote host. If you set the <code>-min\_hosts</code> option to a low value or you set the <code>-timeout</code> option to a small value, an imbalance is likely and leads to image swapping until sufficient hosts become available. The <code>create\_distributed\_farm</code> command is limited to a maximum of 256 remote host processes.

When the <code>create\_distributed\_farm</code> command is called, the previously added hosts begin to transition through the states of their lifecycle that is shown in Figure 1-3.

Figure 1-3 Lifecycle States



# **License Resource Management**

By default, the master takes care of its own licensing regardless of the licenses required to perform multi-scenario analysis. After the master is launched, it acquires any needed PrimeTime licenses from the license pool in the same way as ordinary PrimeTime. The master then dynamically distributes the licenses to the slave processes. You must specify an upper limit for the number of licenses you want the master to use for the slave processes.

The set\_multi\_scenario\_license\_limit command sets the upper limit for the number of licenses of a particular feature the master can check out from the license pool to use for multi-scenario processing. Any licenses that the master checks out are made available for slave usage. For instance, five PrimeTime licenses allow one master and five slaves to operate concurrently.

Setting the limit on the number of licenses to use does not cause PrimeTime to check out any licenses from the central pool. The licenses are checked out after the slaves begin processing tasks. To specify that the licenses are checked out immediately, use the -force\_checkout option. For instance, in the following example, the limit on the number of PrimeTime licenses to use is set to five. The master process checks out no more than four additional licenses (but might check out fewer depending on the availability in the main licensing pool) making up to a maximum of five licenses available for slave usage:

```
pt_shell> set_multi_scenario_license_limit -feature
PrimeTime 5
```

If any analysis being performed involves crosstalk analysis, you must set the limit on the number of PrimeTime SI licenses to use during multi-scenario analysis. If the limit is not set before the analysis begins, the analysis proceeds just as in PrimeTime, without the crosstalk features. For example, the following command sets the limit on the number of PrimeTime SI licenses for slave usage to five. Since the master has not checked out a PrimeTime SI license, it checks out up to five PrimeTime SI licenses for slave usage during multi-scenario analysis:

```
pt_shell> set_multi_scenario_license_limit -feature
PrimeTime-SI 5
```

Since the master dynamically allocates licenses to the slave processes on an as-needed basis, a slave process uses a license only when it is actively executing a task. This is important in the context of maximizing the overall performance of the multi-scenario mechanism. Therefore, it is possible to have more slave processes added than licenses available for them to use. The master distributes tasks across all of the slave processes, and as each begins to execute a task, it checks out the appropriate licenses from the master for the duration of time it takes to execute the task. After the task is complete, the slave process returns the licenses to the master for other slave processes to use.

The benefit of this mechanism is that if you have more slave processes than licenses, you can maximize the multi-scenario system throughput by minimizing the expensive process involved in swapping out a scenario.

For optimal system performance of the distributed multi-scenario mechanism, match the license limit to the number of slave processes added. In this way, all slave processes can execute concurrently, thereby maximizing the system throughput.

#### Note:

You cannot specify fewer licenses than have already been allocated.

The license management capabilities enable you to do the following:

- Lower the license limit. Any licenses over the limit are returned to the license server pool.
   For more information, see "Incremental License Handling."
- License spanning is supported, so that it is possible to check out licenses of a single feature from multiple license servers. For more information, see "License Spanning" on page 1-15.
- Instruct the master to automatically reduce the number of licenses for features checked out to a minimum when those licenses are not needed by using dynamic license reduction. For more information, see "License Auto-Reduction" on page 1-15.

# **Incremental License Handling**

By default, the master does not allow you to reduce the licensing limit for a feature. With this configuration, when the master checks out licenses of a feature, they are not returned to the central license server until the master exits. You can configure the master to enable license reduction by enabling incremental license handling, which is not enabled by default. To enable incremental license handling, set the <code>SNPSLMD\_ENABLE\_INCREMENTAL\_LICENSE\_HANDLING</code> environmental variable to 1. The syntax is as follows:

```
setenv SNPSLMD_ENABLE_INCREMENTAL_LICENSE_HANDLING 1
```

If you do not set this environmental variable or set it to anything other than 1, the master is not able to check licenses back into the central license server until it exits. Changing the environmental variable from within the master session has no impact.

When you enable incremental license handling, you can use the set\_multi\_scenario\_license\_limit command to both increase and decrease the license upper limit of a feature. When the upper limit is being lowered, the upper limit is immediately reduced and the master checks in sufficient licenses of the feature to the central license server, if needed, to meet the new target limit. If no licenses have been checked out from the central license server or the number checked out is less than the new limit, the command lowers the upper limit.

#### Note:

There must always be a minimum of 1 license checked out for all features in use at all times. Therefore, you cannot use the <code>set\_multi\_scenario\_license\_limit</code> command to reduce the upper limit to 0.

# **License Spanning**

License spanning provides the ability to check out licenses of a single feature from multiple license servers. You can activate license spanning by enabling incremental license handling. Before the master is launched, set the <code>SNPSLMD\_ENABLE\_INCREMENTAL\_LICENSE\_HANDLING</code> environmental variable to 1. For more information about this variable, see the man page.

#### **License Auto-Reduction**

License auto-reduction instructs the master to automatically reduce the number of licenses for features checked out to a minimum level when those licenses are not being used to perform analysis work. You can enable or disable license auto-reduction at any time from within the master by setting the <code>enable\_license\_auto\_reduction</code> global variable to <code>true</code> to enable or <code>false</code> to disable. When auto-reduction is enabled, if a scenario task is completed and no additional scenarios are waiting for the license, the license is returned to the central license pool.

It is important to use this feature carefully because although it allows licenses to return to the central license server, there is no guarantee that subsequent analysis is able to reacquire those licenses for further use. If the master cannot reacquire the licenses or can only partially reacquire them, the level of concurrency in the distributed multi-scenario analysis is reduced. This can impact performance and time-to-results. Also, the time needed to repeatedly check in and check out the licenses themselves can significantly slow down interactive work, such as merged reporting or the execution of Tcl scripts or procedures that communicate heavily with the scenarios. In these cases, it might be desirable to enable auto-reduction during the initial timing update and then disable it during interactive work as follows:

```
# get all scenarios to update their timing
set enable_license_auto_reduction true
remote_execute {update_timing}

# generate merged reports
set enable_license_auto_reduction false
report_timing ...
report_qor ;# Tcl proc from SolvNet (Doc ID 008602)
dmsa_fix_hold ... ;# Tcl proc from SolvNet (Doc ID 018510)
```

# **Database Support**

File reading and support at the slave is supported without restriction. This means that support for the read\_ddc and read\_milkyway commands in distributed multi-scenario analysis is identical to the support for these commands in PrimeTime.

#### **Scenarios**

A scenario is a specific combination of operating condition and operating mode for a given configuration. You create a scenario with the <code>create\_scenario</code> command, as in the following example:

This command specifies a scenario name, the common-data script files, and the specific-data script files. The scripts associated with the scenario are divided into two categories: common data (shared by two or more scenarios) and specific data (not shared by any other scenarios). Common-data scripts are included in the baseline image generation process, whereas specific-data scripts are applied only to the specified scenario. Organizing scripts into categories allows the master to share design data between groups of scenarios where appropriate, thereby reducing the total runtime for all scenarios. The baseline image generation process is described in greater detail in the "Distributed Analysis Process" on page 1-20. For example, consider the scenarios illustrated in Figure 1-4. The figure shows the types of scripts that can be applied as common-data and specific-data scripts.




Figure 1-4 Multi-Scenario Setup Example

This design is to be analyzed at two process variation extremes, called slow and fast, and two operating modes, called read and write. Thus, there are four scenarios to be analyzed: slow-read, slow-write, fast-read, and fast-write. You can add more conditions and modes by creating several scenarios as indicated in the figure.

The <code>common\_all.pt</code> script reads in the design and applies constraints that are common to all scenarios. The <code>common\_s.pt</code> script is shared between some, but not all, scenarios. The <code>specificl.pt</code> script directly contributes to specifying conditions of an individual scenario and is not shared at all between different scenarios.

# **Removing Scenarios**

To remove a scenario previously created with the <code>create\_scenario</code> command, use the <code>remove\_scenario</code> command:

pt shell> remove scenario s1

#### **Current Session and Command Focus**

The current session is the set of scenarios to be analyzed and is established using the current session command, as in the following example:

```
pt shell> current session {s2 s3 s4}
```

The command lists the scenarios to be part of the current session, all of which must be valid scenario names already defined by the <code>create\_scenario</code> command. By default, all listed scenarios are in command focus. The command focus is the set of scenarios in the current session to which analysis commands are applied.

After using current\_session, you can further narrow the command focus by using the current\_scenario command to select a subset of the scenarios in the current session:

```
pt_shell> current_scenario {s3}
```

This command is useful during interactive analysis. For example, you might want to modify the timing characteristics of a path in one scenario by annotating a load on a particular net, and then run a new delay calculation on the net's driving cell or recheck the timing of the whole path for that scenario alone.

After narrowing the command focus, you can restore the command focus to all scenarios in the session by using the -all option:

```
pt_shell> current_scenario -all
```

#### Note:

Changing the *current-session* list requires images to be rebuilt and is a zero-cost operation.

# **Checking the Setup**

To check the distributed processing setup before you begin multi-scenario analysis, use the report\_multi\_scenario\_design command. For more information about this command, see the man page.

#### **Remote Execution**

To use the <code>remote\_execute</code> command, enclose the list of commands in a Tcl string. The commands should be separated by semicolons as this allows them to be executed one at a time rather than as a group. To evaluate subexpressions and variables remotely, generate the command string using curly braces. For example,

```
remote_execute {
```

```
# variable all_in evaluated at slave
  report_timing -from $all_in -to [all_outputs]
}
```

In this example, the report\_timing command is evaluated at the slave, and the all\_in variable and the all\_outputs expression are evaluated in a slave context.

To evaluate expressions and variables locally at the master, enclose the command string in quotes. All master evaluations must return a string. For example,

```
remote_execute "
    # variable all_out evaluated at master
    report_timing -to $all_out
"
```

In this example, the report\_timing command is evaluated at the slave, and the all\_out variable is evaluated at the master.

Upon issuing the remote\_execute command, the master generates tasks for execution in all scenarios in command focus.

If you use the -pre\_commands option with the remote\_execute command, the listed commands are executed before the command specified for remote execution.

If you use the <code>-post\_commands</code> option, the listed commands are executed after the commands specified for remote execution.

#### Example 1: Slave and master context variables

```
remote_execute {set x 10}
# Send tasks for execution in all scenarios in command focus
set x 20
remote_execute {report_timing -nworst $x}
# Leads to report_timing -nworst 10 getting executed at the slaves
remote_execute "report_timing -nworst $x"
# Leads to report_timing -nworst 20 getting executed at the slaves
```

#### Example 2: -pre commands option used with the remote execute command

```
remote_execute -pre_commands {cmd1; cmd2; cmd3}
"report_timing"
# On the slave host, execute cmd1, cmd2, and cmd3 before
# executing report_timing on the master
```

#### Example 3: -post commands option used with the remote execute command

```
remote_execute -post_commands {cmd1; cmd2; cmd3}
"report_timing"
# On the slave host, execute cmd1, cmd2, and cmd3 after
```

```
# executing report_timing on the master
```

You can use the remote\_execute command with the -verbose option to return all slave data to the master terminal screen, instead of piping it to the out.log file in the working directory of the distributed multi-scenario analysis file system hierarchy.

The ability to execute netlist editing commands remotely extends to all PrimeTime commands except the following:

- explicit save\_session (slave only)
- explicit restore\_session
- remove design

# **Distributed Analysis Process**

After you set up the analysis with the <code>create\_scenario</code>, <code>current\_session</code>, and (optionally) <code>current\_scenario</code> commands, you can start analysis of the scenarios in command focus.

The remote\_execute command is used in the master to explicitly evaluate commands, variables, and expressions in the slave context. There is a slight difference in the way that you can use the command, depending on whether you are executing commands in batch or interactive mode.

In batch mode, the commands are contained in scripts. For example, you might execute the following command at the UNIX prompt to invoke PrimeTime and execute a multi-scenario analysis in batch mode:

```
% pt shell -multi scenario -f script.tcl
```

The following is a sample script:

#### Note:

You must specify the multi\_scenario\_working\_directory and multi scenario merged error log variables before creating the distributed farm.

```
# Create the distributed farm for processing the scenarios
create_distributed_farm
set_multi_scenario_license_limit -feature PrimeTime 2
# Set the limit on the number of PrimeTime licenses usable
# by slaves to 2
create_scenario \
  -name scenario1 \
  -common_data common_data_scenarios_s1_s3.tcl \
  -specific_data specific_data_scenario_s1.tcl
create scenario \
  -name scenario2 \
  -common_data common_data_scenarios_s2_s4.tcl \
  -specific_data specific_data_scenario_s2.tcl
create_scenario \
  -name scenario3 \
   -common_data common_data_scenarios_s1_s3.tcl \
  -specific_data specific_data_scenario_s3.tcl
create_scenario \
  -name scenario4 \
  -common data common data scenarios s2 s4.tcl \
  -specific_data specific_data_scenario_s4.tcl
###############################
# End of specifying the setup
###############################
current_session {scenario1 scenario2}
remote_execute -pre_commands {"cmd1" "cmd2" "cmd3"} \
  {report_timing}
# cmd1,cmd2,cmd3, are placeholders for typical
# PrimeTime commands or scripts that need to be
# executed on scenario1 and scenario2
# End of specifying the first task
#####################################
quit
```

A task is a self-contained block of work that a slave process needs to execute in order to perform some function. A slave process starts execution of a task for the specified scenario as soon as it gets the licenses appropriate to that task. Otherwise, it waits for the licenses it requires.

In the script.tcl example, the main task that is user directed consists of cmd1, cmd2, cmd3 and the report\_timing command. However, there are other internal tasks that need to happen before you can execute the task containing these commands. This process is called common image generation. The following are the processes that take place prior to executing your commands but after specifying all scenarios, sessions, and so on.

The first set of tasks the master generates and delegates to arbitrary slave processes is to generate the baseline images. Every scenario in command focus requires access to a baseline image which consists of the netlist image and the common data files for that scenario. The slave process assigned to execute a baseline image generation task executes the common data files for that scenario in the order in which they were specified at the time the scenario was created using the <code>create\_scenario</code> command. After this, the slave process generates the baseline image for that scenario.

Before any other types of tasks can proceed in the scenario that is having its baseline image generated, the baseline image generation process must complete successfully. Given this dependence, failure of this process results in failure of the multi-scenario analysis only for those scenarios that depend on that failed image generation. The MS-020 warning message is issued and resources are reduced. Scenarios that have access to a successfully generated baseline image can proceed normally.

For each scenario in command focus that provides a baseline image, that image is written to the scenario\_name/baseline\_image directory under the multi-scenario working directory.

The third set of tasks that the master generates and delegates to slave processes is the execution of the user-specified commands in the scenarios that are in command focus. The slave process assigned a command execution task uses the baseline image for the scenario in which these commands need to be executed (this configures the slave process for the scenario), executes the specific data files for that scenario, and then executes the commands specified.

Where there are more scenarios in command focus than processes to execute the tasks for those scenarios, the slave process needs to save out a current image for one scenario while it proceeds with task execution for a different scenario. If this swapping is necessary, the slave process saves the current image in the scenario\_name/current\_image directory under the multi-scenario working directory.

# **Achieving Optimal Performance**

It is important to remember that the automatic reconfiguring of slave processes to run different tasks in different scenarios can be an expensive operation and should be minimized to maximize system throughput. The multi-scenario process operates to minimize the swapping out of scenarios, but is subject to the limitations imposed by the number of

scenarios in command focus and the number of slave processes added. If there is a significant imbalance of scenarios to slave processes, as a whole the system performance is degraded.

You can achieve optimal performance from the distributed multi-scenario mechanism if there is a slave process for every scenario in command focus, a CPU available to execute each slave process, and a license for each feature needed for every slave process. This results in all slave processes executing concurrently, allowing maximum throughout for the system.

# **Saving and Restoring Your Session**

Baseline images cannot be restored by a normal PrimeTime session; however, current images can be restored. You can also issue a <code>save\_session</code> command from the master to generate an image for each one of the scenarios in command focus. For example,

```
current_session {scen1 scen2}
save_session -replace /images
```

You can find the images generated by the master-issued <code>save\_session</code> command in the \$sh\_launch\_dir/images/scen1 and \$sh\_launch\_dir/images/scen2 directories. You can then reload these images into a normal PrimeTime session.

The save and restore features allow you to explicitly restore a saved image into a distributed multi-scenario analysis scenario. This is achieved with the addition of the following switch:

```
create_scenario -image
```

Using this switch, you can load any single-core analysis PrimeTime image that has been produced by a <code>save\_session</code> command (either inside or outside of distributed multi-scenario analysis). Load this image into distributed multi-scenario analysis directly as a scenario. You can then operate upon it in the normal way within the context of distributed multi-scenario analysis.

# **Manipulating Variables**

You can control the value of a variable in either the master or any of its slaves during distributed multi-scenario analysis.

#### **Master Context Variables**

The following is an example of a master context variable:

```
set x {"ffa/CP ffb/CP ffc/CP"}
```

```
report timing -from $x
```

Notice how x is forced to be a string.

# **Slave Context Variables and Expressions**

The master has no knowledge of variables residing on the slave, but can pass variable or expression strings to the slave for remote evaluation. To pass a token to the slave for remote evaluation, use curly braces. For example, say you had the following scenarios:

- Scenario 1: x has value of ff1/CP
- Scenario 2: x has value of ff2/CP

The report\_timing -from {\$x} command would report the worst paths from all paths starting at ff1/CP in the context of scenario 1, and all paths starting at ff2/CP in the context of scenario 2.

# **Setting Distributed Variables**

With the set\_distributed\_variables command you can set the values of variables at the slaves from the master. The variable you set can be a Tcl scalar variable, Tcl collection, Tcl array, or Tcl list.

To set variables in multiple scenarios, you first create a Tcl array of the desired values for those scenarios, then use the  $set\_distributed\_variables$  command to distribute the settings to the scenarios. For example, suppose that you have two scenarios, s1 and s2, running under the control of a master. From the master, you want to set the value of two variables x and y at the slave level, so that x=10 and y=0 in s1, and x=0 and y=15 in s2. You create an array, indexed by scenario name, containing the values to set in the slaves. From the master you execute:

```
pt_shell> array set x {s1 10 s2 0}
pt_shell> array set y {s1 0 s2 15}
pt_shell> set_distributed_variables {x y}
```

This sends the values specified in the arrays x and y from the master to the slaves, and creates the variables x and y at the slaves if they do not already exist, and sets them to the desired values.

When variables are pushed from the master into the scenarios, nonarray variables at the master are supported. The specified variable is created at each of the scenarios. This avoids the need for creating a temporary array at the master to push a simple variable value. For example,

```
pt_shell> set test_var 123
```

```
123
```

```
pt_shell> set_distributed_variables test_var
```

For more information about the set\_distributed\_variables command, see the man page.

# **Getting Distributed Variable Values**

Using the <code>get\_distrubuted\_variables</code> command provides the ability to get the values of variables set in scenarios in command focus. The variables retrieved by the command can be a Tcl variable, collection, array, or list. The retrieved values are returned to the master process and stored in a Tcl array, indexed by scenario name. For example, the following session retrieves slack attribute values from two scenarios:

```
current_session {scen1 scen2}

remote_execute {
    set pin_slack1 [get_attribute -class pin UI/Z slack];
    set pin_slack2 [get_attribute -class pin U2/Z slack]
    }

get_distributed_variables {
        pin_slack1 pin_slack2
    }
}
```

The session returns two arrays, pin\_slack1 and pin\_slack2. Indexing pin\_slack1(scen1) returns the scalar value of slack at U1/Z in context of scenario scen1. Indexing pin\_slack1(scen2) returns the scalar value of slack at U1/Z in the context of scenario scen2. When retrieving a collection, you must indicate what attributes you are interested in for the command to generate the desired list. The following session retrieves timing paths from two scenarios:

The session returns an array called mypaths. Indexing mypaths(scen1) yields a collection of the 100 worst paths from scenario scen1, ordered by slack. Similarly, indexing paths(scen2) yields a collection of the 100 worst paths from scen2.

When retrieving variables at the master, any existing array variables are updated with the retrieved values. For more information, see the man page.

# **Merging Distributed Variable Values**

You can use the <code>-merge\_type</code> and <code>-null\_merge\_method</code> options of the <code>get\_distributed\_variables</code> command to merge variable values that come from the scenarios as they are retrieved. This is especially useful when you are writing customized distributed multi-scenario analysis scripts.

By default, the <code>get\_distributed\_variables</code> command brings back a scenario variable as an array. With the <code>-merge\_type</code> option, the values can be merged back into a variable during retrieval. The merge types that are available are <code>min, max, average, total, list, sum.</code> and <code>unique\_list</code>. For example, to keep the numerically smallest value of the <code>worst\_slack</code> variable from all scenarios, use the following commands:

```
pt_shell> get_distributed_variables {worst_slack} -merge_type min
1
pt_shell> echo $worst_slack
-0.7081
```

You can also merge arrays of one or more dimensions and keep the worst value for each array entry. For example, if you have the following scenarios:

```
scenario best_case:
set slacks(min,pinA) -0.2044
set slacks(max,pinA) 0.3084

scenario type_case:
set slacks(min,pinA) -0.0523
set slacks(max,pinA) 0.0901

scenario worst_case:
set slacks(min,pinA) 0.1015
set slacks(max,pinA) -0.7081
```

You would use the following commands to obtain the merge results listed:

```
pt_shell> get_distributed_variables {slack} -merge_type min
1
pt_shell> echo $slacks(min, pinA)
-0.2044
pt_shell> echo $slacks(max, pinA)
-0.7081
```

The <code>-merge\_type</code> option can also merge together lists of values from the scenarios. For example, to obtain a unique list of all clock names from every scenario, use the following commands:

```
1
pt_shell> echo $clock_names
CLK33 CLK66 CLK50 CLK100 ATPGCLOCK JTAGCLK
```

The merged list is built from the list contents from each scenario with any duplicate list entries of identical values omitted.

To merge lists of object name lists in a multi-scenario analysis flow, a specialized <code>unique\_list</code> merging mode is available. This mode is useful when you want to bring back multiple lists of design object names, such as cell, pin, or net names, and there might be small variations between the scenario results due to differing constants, constaints, or interface logic model (ILM) netlists, or differences in the design. Where possible, the <code>unique\_list</code> merging mode keeps the sublists separate so that gaps can be filled, but merges these sublists together as needed. Using this merging mode is similar to applying the list merging type to each of the sublists, but additionally merges together any sublists that share common items. For example, consider following variable variables,

```
scenario best_case:
set cells {{U1 U2} {U4 U5} {U7 U8}}
scenario type_case:
set cells {{U2 U3} {U6 U7}}
scenario worst_case:
set cells {{U1} {U5 U6}}
```

Retrieving them with the unique\_list merging mode would provide the following result:

```
{{U1 U2 U3} {U4 U5 U6 U7 U8}}
```

The merged list is built from the list contents from each scenario, with any duplicate list entries of identical value omitted.

The <code>-null\_merge\_method</code> option specifies what behavior should be used when a null (empty) value of {} is encountered during the numerical merge operations. The available options are:

• ignore (the default)

Ignore any null values and only process the non-null values

error

Abort the merging process and issue an error

• override

Null values win the merging process and a null is returned

For example, you might have the libraries in the type\_case scenario misconfigured such that the BUFFX2 buffer cell cannot be resolved, and the value for this array entry was set to null. With the default null merging method of ignore, the null is ignored and the remaining BUFFX2 values are averaged as shown in the following example.

```
scenario best_case:
set buffer_delay(BUFFX1) 0.105
set buffer_delay(BUFFX2) 0.210
scenario type_case:
set buffer_delay(BUFFX1) 0.130
set buffer_delay(BUFFX2) {}
scenario worst_case:
set buffer_delay(BUFFX1) 0.140
set buffer_delay(BUFFX2) 0.280
```

If it is possible that some data entries can be null, you can specify the <code>-null\_merge\_method</code> override option to detect these cases of incomplete data array entries. In this situation, the null wins during the numerical merging process and overrides the other numerical values for that array entry, allowing the missing data to be detected in a controlled manner. For example, you would specify the following commands:

Alternatively, you can use the null merging method of error so that the get distributed variables command aborts with an error. For example,

The error null merging method can be used as an assertion to trap cases that should never happen. For example, if the array data should always be complete, it can be used to assert an error if some data is null for some unexpected reason.

#### Note:

A null data value is different from when a value is undefined. If array entries are undefined, the <code>-null\_merge\_method</code> option does not apply and the merging process operates normally on the remaining data values. For example, in the type\_case scenario, if the scenario scripting omitted the <code>BUFFX2</code> array entry rather than setting it to <code>null</code>, it would be impossible to detect any missing data after applying the merging process.

## **Merged Reporting**

Executing reporting commands in multi-scenario analysis can generate large amounts of data and detailed information about each scenario. The sheer quantity of data can make it difficult to identify the critical information. To manage these large data sets, and to help you identify critical issues across the design, PrimeTime provides the merged reporting capability.

Merged reporting is a mechanism that works with all the scenarios in command focus to automatically eliminate redundant data across scenarios and sort the data in order of criticality. This allows you to treat all the scenarios in command focus as if they are a single virtual PrimeTime instance. The merge reporting capability applies to the get\_timing\_paths, report\_analysis\_coverage, report\_clock\_timing, report\_constraint, report\_si\_bottleneck, and report\_timing commands.

The following sections provide general information on the reporting methods as well as specific information for each merge reporting command.

## **Using Merged Reporting**

To use merged reporting for a timing report, issue the report\_timing command at the master as you would in the single-core analysis PrimeTime, as in the following example:

```
pt_shell> report_timing
```

Executing the command in this way is called executing the command in the master context. This results in the master and slave processes working together to execute the report\_timing command in all the scenarios in command focus, to produce a final merged report that is displayed at the master console. Each of the reports include the scenario name from which it came.

#### **Generating Merged Reports**

When issuing commands in a master context, the commands are operating in a distributed manner, which necessitates specifying some of their options in a slightly different way compared to the single-core analysis mode.

Using commands in distributed multi-scenario analysis is similar to using these same commands in a single-core analysis session of PrimeTime. All of the options exist in the merged mode. However, you must first invoke the <code>-multi\_scenario</code> option to use the <code>-pre\_commands</code> and <code>-post\_commands</code> options. These options allow you to specify a string of commands to execute in the slave context before and after executing the merged report command. In situations where there are more scenarios than slave processes, using these options can reduce the amount of swapping out of scenarios by performing the <code>-pre\_commands</code> or <code>-post\_commands</code> options and the merged reporting command in series, as opposed to multiple swapping out and restoring the same scenarios for each command.

The following sections detail the commands:

- get\_timing\_path
- · report\_analysis\_coverage
- report\_clock\_timing
- report\_constraint
- report\_si\_bottleneck
- report\_timing

## get\_timing\_path

Using the <code>get\_timing\_paths</code> command from the master process returns a collection of timing path objects from each scenario, based on the parameters you set in the command. The timing path collection is condensed to meet the requirements you specify (such as, using <code>-nworst</code> or <code>-max paths</code>). It returns a merged output collection of the worst timing paths across all scenarios according to the reporting criteria set.

To find the scenario a particular timing path object belongs to, use the scenario attribute on the timing path object itself. To generate a list of attributes you are interested in, use the -attributes option with the get\_timing\_path command.

## report\_analysis\_coverage

The report\_analysis\_coverage command reports the coverage of timing checks over all active scenarios in the current session. The timing check is defined by the constrained pin, the related pin, and the type of the constraint. The timing check status is reported

- As violated if the calculated signal propagation time along the particular data path does not meet timing requirements (constraints)
- As met if timing requirements are satisfied
- As untested if the timing check was skipped

Timing checks are included in the Untested category only if they are untested in all scenarios. If a timing check is tested in at least one scenario, the timing check is reported as tested (showing in either the Violated or Met category) because it has been successfully exercised in some scenario. This allows meaningful reporting to be performed across scenarios with significantly differing behavior (for example, functional versus test modes).

The output for the merged reports is similar to the single-core analysis coverage reports; however, the merged reports contain a list of scenarios. Example 1-1 shows the summary merged analysis coverage report.

Example 1-1 Summary Merged Analysis Coverage Report

pt\_shell> report\_analysis\_coverage

\*\*\*\*\*\*\*\*\*\*

Report : analysis\_coverage
Design : multi-scenario design

Version: B-2008.06

Date : Mon Mar 31 07:17:11 2007

Scenarios: SLOW\_OPER, NOM\_OPER, FAST\_TEST

Type of Check	Total	Met	Violated	Untested
setup hold	8 8	3 (37.5%) 3 (37.5%)	3 (37.5%) 3 (37.5%)	2 ( 25%) 2 ( 25%)
All Checks	16	6 (37.5%)	6 (37.5%)	4 ( 25%)

If a timing check is untested in all scenarios in the command focus, instead of a list of scenarios, the all tag is listed in the scenario column; however, if a timing check is tested in at least one scenario, the check is reported as tested, either violated or met, because it has been successfully exercised in some scenarios. Example 1-2 shows a report where some scenarios are met and others are untested.

Example 1-2 Detailed Merged Analysis Coverage Report

pt\_shell> report\_analysis\_coverage -status\_details {untested met} -sort\_by slack

\*\*\*\*\*\*\*\*\*\*

Report : analysis\_coverage

-status\_details {untested met}

-sort\_by slack

Design : multi-scenario design

Version: B-2008.06

Date : Tue Mar 11 11:42:06 2008

\*\*\*\*\*\*\*\*\*\*

Scenarios: so	cen1, s	scen2,	scen3
---------------	---------	--------	-------

Type of Check	Total	Met	Violated	Untested
setup hold	15 15	2 ( 13%) 12 ( 80%)	12 ( 80%) 2 ( 13%)	1 ( 7%) 1 ( 7%)
All Checks	30	14 ( 47%)	14 ( 47%)	2 ( 7%)

Constrained Pin	Related Pin	Clock	Check Type	Scenario	Slack Reason
ffd/CR	CP(rise)		hold	scen2	untested
					constant_disabled
				scen1	
ffd/CR	CP(rise)		setup	scen2	untested
					constant_disabled
				scen1	
ffa/D	CP(rise)	clk2	hold	scen2	0.14
ffa/D	CP(rise)	CLK	hold	scen2	0.14
ffb/D	CP(rise)	CLK	hold	scen2	0.14
ffb/D	CP(rise)	clk2	hold	scen2	0.14
ffd/D	CP(rise)	CLK	hold	scen2	0.14
ffd/D	CP(rise)	clk2	hold	scen2	0.14
ffa/D	CP(rise)	clk3	hold	scen1	0.15
ffb/D	CP(rise)	clk3	hold	scen1	0.15
ffc/D	CP(rise)	clk3	hold	scen1	0.15
ffc/D	CP(rise)	CLK	hold	scen1	0.15
ffd/D	CP(rise)	clk3	hold	scen1	0.15
ffd/CR	CP(rise)	CLK	setup	scen3	9.10
ffd/CR	CP(rise)	clk2	setup	scen3	9.15
ffc/D	CP(rise)		hold	scen2	9.40
1					

## report\_clock\_timing

The report\_clock\_timing command executed by the master process returns a merged report that displays the timing attributes of clock networks in a design. The output for the merged report\_clock\_timing report is similar to the single-core analysis report\_clock\_timing report; however, the merged report contains a list of scenarios, which are displayed under the Scen column. Example 1-3 shows an example of the output of the merged report\_clock\_timing command.

Example 1-3 Merged report\_clock\_timing Report

```
pt_shell> report_clock_timing -type latency -nworst 3
```

\*\*\*\*\*\*\*\*

Report : clock timing
-type latency
-launch
-nworst 3
-setup

Design : multi-scenario design

Version : C-2009.06

Date : Tue Jun 30 02:44:25 2009

Scenarios: scen1, scen2

Clock: CLKA

Clock Pin	Scen	Trans	Source	Latency Network	y Total	
1_1/CP f1_3/CP gclk_ff/CP	scen1 scen2 scen1	0.00 0.00 0.00	0.11 0.11 0.10	25.36 23.96 22.96	25.47 24.07 23.06	rp-+ rp-+ rpi-+
1 pt_shell>						

#### report\_constraint

The report\_constraint command executed by the master process returns a merged report that displays constraint-based information for all scenarios in command focus. It reports whether or not a constraint is violated or met, by how much that constraint is violated, and which design object is the worst violator.

The merging process for the report\_constraint command for distributed multi-scenario analysis treats all the scenarios in command focus as if they are a single virtual PrimeTime instance. When an object is constrained in more than one scenario, these constraints are considered duplicates. PrimeTime reports the worst violating instance of each relevant object in the design. For example, for a max\_capacitance report, PrimeTime reports on the most critical instance for each pin in the design. When there are multiple instances of the same pin across multiple scenarios, PrimeTime retains the worst violator and uses the scenario name as a tie-breaker to ensure determinism. When you specify the -verbose or -all\_violators option, PrimeTime reports the scenario name for the constraint violators.

Collection handling using the report\_constraint command occurs in the same way as the report\_timing command. For an example of the report\_timing command collection handling, see "Explicit and Implicit Collection Example" on page 1-39.

#### Note:

There are many different types of constraints and reporting styles available when using the report\_constraint command. For more information about the differences between single-core and multi-scenario reports, see Appendix C, "Differences Between Single-Core and Multi-Scenario Constraint Reports.

Example 1-4 shows the constraint report output for the merged distributed multi-scenario analysis constraint report.

Example 1-4 PrimeTime Distributed Multi-Scenario Analysis Merged Constraint Report pt\_shell> report\_constraint -all\_violators -path slack\_only

\*\*\*\*\*\*\*\*\*

Report : constraint
-all\_violators
-path slack\_only

Design : multi-scenario design

Version: B-2008.06

Date : Tue Apr 1 04:37:42 2007

\*\*\*\*\*\*\*\*\*\*\*

max\_delay/setup ('default' group)

Endpoint	Scenario	Slack	
QA QB	scen1 scen1	-1.80 -1.79	(VIOLATED) (VIOLATED)
<pre>max_delay/setup ('CLK' group)</pre>			
Endpoint	Scenario	Slack	
<pre>ffd/D ffc/D ffb/D ffa/D min_delay/hold ('CLK' group)</pre>	scen1 scen2 scen1 scen2	-4.12 -4.01 -3.73 -3.60	(VIOLATED) (VIOLATED) (VIOLATED)
Endpoint	Scenario	Slack	

If you specify the report\_constraint command in summary mode for distributed multi-scenario analysis when handling setup checks, the report shows the worst setup constraint for all scenarios per group. The hold information displays the sum of the worst total endpoint cost per clock group over all scenarios. Example 1-5 shows the summary output for the merged distributed multi-scenario analysis constraint report shown in Example 1-4.

scen1 -0.40 (VIOLATED)

Example 1-5 PrimeTime Distributed Multi-Scenario Analysis Merged Summary Report pt\_shell> report\_constraint

Report : constraint

Design : multi\_scenario design

Version: B-2008.06

ffd/CR

Date : Tue Apr 1 04:37:42 2007

\*

Group (max_delay/setup)	Cost	Weight	Weighted Cost
default CLK	1.80 4.12	-	1.80 4.12
max_delay/setup			5.92

Group (min_delay/hold)	Cost	Weight	Weighte Cost	d
CLK	0.40	-	0.40	
min_delay/hold			0.40	
Constraint			Cost	
max_delay/setup min_delay/hold				VIOLATED) VIOLATED)

Example 1-6 shows the output of an all-violators constraint report with the max\_capacitance option for a multi-scenario analysis:

Example 1-6 PrimeTime Distributed Multi-Scenario Analysis Merged Constraint Report pt\_shell> report\_constraint -all\_violators -path slack\_only -max\_capacitance

Scenarios: scen1 scen2 max\_capacitance

Pin	Scenario	Capacitance	Required Capacitance	Actual Slack
RESET ffa/QN ffb/QN ffc/QN o/Z p/Z	scen2 scen1 scen1 scen1 scen1	0.40 0.40 0.50 0.50 0.50 0.50	7.00 6.00 5.00 4.00 4.00 4.00	-6.60 (VIOLATED) -5.60 (VIOLATED) -4.50 (VIOLATED) -3.50 (VIOLATED) -3.50 (VIOLATED) -3.50 (VIOLATED)

## report\_si\_bottleneck

The report\_si\_bottleneck command allows you to locate nets that are most critical in crosstalk delay. With it, you need minimal net repair effort to identify and fix most problems. Across all scenarios, sorting and printing is performed with duplicates pruned to leave a unique set of nets across the scenarios.

The following example executes the report si bottleneck command at the master.

Bottleneck Cost: total\_victim\_delay\_bump

Net	Scenario Name	Cost
OutFirstReg	s1	0.919074
Reg	s2	0.639971
PreNet	s1	0.367737
Comb	s4	0.021904
InReg	s3	0.000039
InComb	s2	0.000033

#### report\_timing

The report\_timing command executed by the master process returns a merged report that eliminates redundant data across scenarios and sorts the data in order of slack, effectively treating the scenarios in the command focus as a single analysis. The merging process allows you to treat all the scenarios in command focus as if they are a single virtual PrimeTime instance. To do this, PrimeTime reports the worst paths from all scenarios while maintaining the limits imposed by the <code>-nworst</code>, <code>-max\_paths</code>, and other options of the report\_timing command. When the same path is reported from multiple scenarios, PrimeTime keeps only the most critical instance of that path in the merged report and shows the scenario in which that instance of the path was the most critical. This way, the resulting report is more evenly spread across the design instead of being focused on the one portion of the design that is critical in all scenarios.

When the same path is reported from multiple scenarios, PrimeTime keeps only the most critical instance of that path in the merged report and shows the scenario in which that instance of the path was the most critical. This way, the resulting report is more evenly spread across the design instead of being focused on one portion of the design that is critical in all scenarios.

#### Note:

You can disable this capability with the <code>-dont\_remove\_duplicates</code> option of the report\_timing command. For more information, see "Handling Duplicate Paths" on page 1-40.

PrimeTime considers two paths from two scenarios to be instances of the same path if the two paths meet all of the following criteria:

· path group

- sequence of pins along the data portion of the path
- transitions at every pin along the data portion of the path

pt\_shell> report\_timing -delay\_type min -nworst 2 \

- launch clock
- capture clock
- constraint type

In the following example, a multi-scenario analysis was run with two scenarios, func\_bc and func\_wc. The following merged report\_timing command was issued at the master:

```
-max_paths 2 -group mrx_clk_pad_I
Start of Master/Slave Task Processing
______
Started : Command execution in scenario 'func_wc'
Started : Command execution in scenario 'func_bc'
Succeeded: Command execution in scenario 'func_bc'
Succeeded: Command execution in scenario 'func wc'
_____
End of Master/Slave Task Processing
 Startpoint: txethmac1/WillTransmit_reg
      (rising edge-triggered flip-flop clocked by mtx_clk_pad_i)
 Endpoint: WillTransmit_q_reg
     (rising edge-triggered flip-flop clocked by mrx_clk_pad_i)
 Path Group: mrx_clk_pad_i
 Path Type: min
 Scenario: func_bc
 Min Data Paths Derating Factor : 1.00
 Min Clock Paths Derating Factor: 1.00
 Max Clock Paths Derating Factor: 1.05
 Point IncrPath
 _____
 clock mtx_clk_pad_i (rise edge)
                                      0.00 0.00
library hold time -
                                       0.06
                                                 0.67
 data required time
 ______
 data required time
 data arrival time
 _____
 slack (MET)
                                                 0.10
 Startpoint: txethmac1/WillTransmit_reg
     (rising edge-triggered flip-flop clocked by mtx_clk_pad_i)
 Endpoint: WillTransmit_q_reg
     (rising edge-triggered flip-flop clocked by mrx_clk_pad_i)
 Path Group: mrx_clk_pad_i
 Path Type: min
```

```
Scenario: func wc
Min Data Paths Derating Factor : 0.95
Min Clock Paths Derating Factor: 0.95
Max Clock Paths Derating Factor: 1.00
Point IncrPath
______
clock mtx_clk_pad_i (rise edge) 0.00 0.00 clock network delay (propagated) 1.0 51.05 txethmac1/WillTransmit_reg/CP (_SDFCNQD1) 0.00 1.05 r txethmac1/WillTransmit_reg/Q (_SDFCNQD1) 0.44 1.49 f txethmac1/WillTransmit (eth_txethmac_test_1) 0.00 1.49 f WillTransmit_q_reg/D (_SDFQD1 0.00 1.49 f
data arrival time1.49
                                                   0.00 0.00
clock mrx_clk_pad_i (rise edge)
                                                             1.31
clock network delay (propagated
                                                    1.31
                                                    0.00
clock reconvergence pessimism
                                                              1.31
WillTransmit_q_reg/CP (_SDFQD1)
                                                    1.31 r
                                                          1.37
library hold time
                                                    0.06
data required time
_____
                                                    1.37
data required time
data arrival time
______
slack (MET)
```

For specific merge process examples, see the individual merging command man pages.

The following sections provide information on how to use the report\_timing options to control the output reports.

#### **Standard Option Handling**

All of the options of the report\_timing command are available for merged reporting, with a few exceptions (see "Limitations" on page 1-50). Provided collections are not being passed to the options, they can be specified at the master just as in normal PrimeTime as in the following examples:

```
pt_shell> report_timing -nworst 10
pt_shell> report_timing -nworst 10 -max_paths 15
pt_shell> report_timing -delay_type max_rise -path_type
full_clock -nosplit
pt_shell> report_timing -from UI/CP -rise_to U2/D
-significant_digits 5
```

As in the remote\_execute command, to evaluate sub-expressions and variables remotely, generate the options using curly braces. For example,

```
report_timing -from {$all_in} -to {[all_outputs]}
```

In this example, the report\_timing command is a merged reporting command which collates data from the slave and generates a merged report at the master. The all\_in variable and the all\_outputs expression are evaluated in a slave context.

To evaluate expressions and variables locally at the master, enclose the command string in quotes. All master evaluations must return a string. For example,

```
report timing -to "$all out"
```

#### **Explicit and Implicit Collection Example**

Use the <code>-pre\_commands</code> option so the collection is generated in the same task as the <code>report\_timing</code> command is executed. The merged <code>report\_timing</code> command at the master then refers to the explicit collection using the name you specified.

#### Example 1-7 Explicit collection

The implicit collection is referred to in the merged <code>report\_timing</code> command at the master using curly braces around the slave expression. At the slave, the implicit collection is generated and passed to the <code>-from</code> option of the <code>report\_timing</code> command.

#### Example 1-8 Implicit Collection

```
pt_shell> report_timing -from {[get_pins U1/A]}
```

#### **Complex Option Handling**

To allow for evaluating master and slaves variables and expressions from the multi-scenario master, the following options have been altered at the multi-scenario master:

```
-from -rise_from -fall_from
-through -rise_through -fall_through
-to -rise_to -fall_to
-exclude -rise_exclude -fall_exclude
```

Unlike in normal PrimeTime, where these variables accept a list as an argument, in multiscenario merged reporting these variables accept a string as an argument. For example,

#### **Handling Duplicate Paths**

The <code>-dont\_merge\_duplicates</code> option is available with the <code>report\_timing</code> command only if you invoke PrimeTime with the <code>-multi\_scenario</code> option. This option impacts the way in which paths from multiple scenarios are merged. By default, when the same path is reported from more than one scenario, PrimeTime reports only the single most critical instance of that path in the merged report and shows its associated scenario. When you use this option, PrimeTime does not merge duplicate instances of the same path into a single instance; however, it shows all critical instances of the path from all scenarios.

#### Note:

Since the number of paths reported is limited by the <code>-nworst</code>, <code>-max\_paths</code>, and other options of this command, when you use the <code>-dont\_merge\_duplicates</code> option, the resulting merged report may not be evenly spread out across the design. The report may be focused on the portion of the design that is critical in each scenario.

#### **Controlling Fault Handling**

In distributed multi-scenario analysis, PrimeTime supports fault handling, which you can control by setting the multi\_scenario\_fault\_handling variable to either ignore or exit. When the variable is set to ignore (the default) and a critical fault occurs in a slave process, the abnormally terminated scenarios and the scenarios that depend on those that terminated are excluded from further analysis within the context of the current session. A warning message is displayed showing which scenarios abnormally terminated. The session then proceeds to analyze the remaining scenarios that are in command focus. The following situations might occur:

- If all scenarios in command focus of the current session abnormally terminate, any
  subsequent distributed command issued at the master fails and you receive an error
  message explaining that there are no scenarios in command focus. You should change
  the command focus within the context of the current session and analyze the selected
  scenarios.
- If all scenarios in the current session abnormally terminate, the current session terminates and you receive a warning saying the session is removed. Any subsequent distributed commands issued at the master causes an error message explaining that there is no current session.
- Critical faults cause resources to go offline. If the resources available are reduced to the
  point where none are online, the session must terminate and you receive an error
  message explaining that the current session has terminated.

The exit option of the multi\_scenario\_fault\_handling variable is available for backwards compatibility. When you select this option, if a critical fault occurs in a slave process, the active command completes its task and then the master process terminates the entire analysis. The process exits gracefully and an informational message is displayed explaining what occurred.

The following sections explain the other improvements to fault handling in distributed multiscenario analysis.

- Merged Reporting Commands
- Netlist Editing Commands
- Using the remote\_execute Command
- Other Commands

#### **Merged Reporting Commands**

Merged reporting is a mechanism that works with all the scenarios in command focus to eliminate redundant data automatically across scenarios and sort the data in order of criticality. This allows you to treat all the scenarios in command focus as if they are a single virtual PrimeTime instance. Due to the distributed feature, if one or more slave processes terminate abnormally, the relevant information for the reporting command is not available. Therefore, when a scenario terminates abnormally, you receive a warning message, and PrimeTime removes this scenario from the current session. PrimeTime then automatically reissues the reporting command to the remaining scenarios in command focus. Any reporting command issued afterwards is applied only to the remaining scenarios in command focus and any abnormally terminated scenarios are excluded from further analysis.

## **Netlist Editing Commands**

Before a netlist change is committed to any scenario from the master, it must be possible to commit the change to all scenarios. Thus, PrimeTime first checks that the netlist change could be successful in all scenarios and next it commits the change. If a scenario terminates abnormally while PrimeTime is checking the possibility of successfully executing the netlist change, this scenario is removed from the command focus, and the netlist editing command is automatically reissued to the remaining scenarios in command focus. If all of the checking processes succeeded in all scenarios, but there was a scenario that terminated abnormally when PrimeTime went to commit the change, a warning message is issued, and all the remaining scenarios in command focus apply the netlist change. Subsequent netlist editing commands are applied only to the remaining scenarios in command focus and any abnormally terminated scenarios are excluded from further analysis.

#### Using the remote\_execute Command

Distributed multi-scenario analysis supports execution of any number of commands on all scenarios in command focus by using the remote\_execute command. If the remote\_execute command encounters a scenario that terminated abnormally, a warning message is issued, the scenario is removed from the current session, and subsequent calls to the command apply only to the remaining scenarios in command focus. Abnormal termination of one or more scenarios has no impact on command execution in other scenarios.

#### **Other Commands**

The following commands do not come under the categories that have been listed, but they are handled in a similar way when an abnormal termination occurs.

• get\_distributed\_variable command

When a scenario terminates abnormally, you receive a warning message, and the scenario is removed from the current session. PrimeTime then automatically reissues the command to the remaining scenarios in command focus.

• get\_timing\_path command

When a scenario terminates abnormally, you receive a warning message, and the scenario is removed from the current session. PrimeTime then automatically reissues the command to the remaining scenarios in command focus.

• save\_session command

When a scenario terminates abnormally, you receive a warning message, and the scenario is removed from the current session. PrimeTime then automatically reissues the command to the remaining scenarios in command focus.

set\_distributed\_variable command

When a scenario terminates abnormally, you receive a warning message, and the scenario is removed from the current session. The command executes as normal for the remaining scenarios in command focus.

## **Messages and Log Files**

Multi-scenario analysis has the potential to generate large amounts of data. To avoid overloading you with data at the master, all data is written to a set of log files. A limited set of interactive messages are displayed at the master.

The remote\_execute command sends all data to the master terminal if the -verbose switch is used.

#### **Interactive Messages**

While a task is executing on the slaves, the slaves send messages back to the master to indicate their progress.

#### **Progress Messages**

As the slave progresses through each stage of the analysis, the slaves send confidence messages to update you on the progress of the analysis. For example,

#### **User Control of Task Execution Status Messages**

You can control the verbosity of distributed multi-scenario analysis task execution status messages. You can set the multi\_scenario\_message\_verbosity\_level variable to one of two values, default and low. When you set to the default value, all task execution status messages are displayed:

When you set the variable to low, only error, fatal, and failure messages are displayed. You might find this useful for Tcl scripts where more control over the output is desired. If this variable is changed by a Tcl script, it is desirable to change the variable back to its original value after completing the script or procedure to avoid confusion.

#### **Error Messages**

When an error occurs on a slave for a given scenario, the error is reported in full at the master together with the name of that scenario. For example,

#### **Warning Messages**

When a warning occurs on a slave for a given scenario, the warning is reported at the master only if it is the first time that this warning has occurred in that scenario. For example,

## **Log Files**

You can examine all information generated by the slaves in the log, output log, command log, or merged error log file. The root working directory for all multi-scenario analysis data, including log files, is determined by the setting of the

multi\_scenario\_working\_directory variable. If you do not explicitly set this variable, it is set to the current directory (from which the PrimeTime master was invoked). You must have write permission to the working directory, and the directory must be accessible by the master and to all slaves.

## **Output Log**

Each scenario has its own output log file which can be found in the scenario working directory. For example, for a scenario named s1, the log would be as follows:

```
multi_scenario_working_directory/s1/out.log
```

You cannot set or change the name of the output log. The output log for a particular scenario contains all errors, warnings and informational messages (all information that you would normally see in the terminal window of a conventional single analysis PrimeTime run).

#### **Command Log**

Each remote process has its own command log file that you can find in the <code>command\_log</code> directory under the working directory. For example, for a process launched on a host named srv1 which is the sixth process to be launched, the command log would be in the following file:

```
multi_scenario_working_directory/command_log/srv1_6_pt_shell_command.log
```

You cannot set or change the name of the command log of remote processes. The command log for a particular process contains all commands executed on that process. You can locate the masters command log in the following file:

```
$sh_launch_dir/pt_shell_command.log
```

The sh\_source\_logging variable, when set to true, causes individual commands from sourced scripts to be written to the command log file.

#### **Merged Error Log**

Large numbers of errors, warnings, and informational messages can occur during a multi-scenario analysis. To help you debug these messages, you can set the merged error log variable at the master. For example, the following command creates a merged error file in multi\_scenario\_working\_directory/error.log:

```
pt_shell> set multi_scenario_merged_error_log "error.log"
```

When this variable is set, all error messages from the start of a particular task to the end of the task are merged together. If the same error message occurs on a number of scenarios, the message is printed to the merged error file only once, with a list of the scenarios in which the message occurred.

#### Note:

You must set the multi\_scenario\_working\_directory and multi\_scenario\_merged\_error\_log variables before issuing the create\_distributed\_farm command.

## **Command Output Redirection**

Command output redirection is supported in multi-scenario analysis. Be sure to redirect output to different destination files for each process. Otherwise, an error occurs when two different processes attempt to control the same file at the same time.

#### Note:

When using output redirection, be sure use a relative path. Do not use an absolute path; if you do, all slave processes attempt to write to the same file, which could lead to read/write conflicts and cause the slave processes to fail.

As with the previous log file example, the value of the

multi\_scenario\_working\_directory variable is used along with the scenario name to determine the output destination file name. The following examples demonstrate the file naming conventions:

Example 1: Interactive redirection

```
pt_shell> set x myfile
pt_shell> remote_execute {report_timing} > $x.out
```

The output of the report\_execute command is directed to a file named myfile.out in the current working directory. The \$x variable is evaluated only at the master process.

Example 2: Script-based redirection

The multi\_scenario\_working\_directory variable has been set to /rpt/new, and there are two scenarios in command focus, s3 and s4. The master issues a remote\_execute {"source myscript.tcl"} command, which sources the Tcl script "myscript.tcl" in the scenarios in command focus. The script "myscript.tcl" contains the following line:

```
report_timing > rt.log
```

The output of the report timing command goes into the following files:

```
/rpt/new/s3/rt.log
/rpt/new/s4/rt.log
```

#### **Session Example**

The following script is a typical multi-scenario master script.

#### Note:

```
You must set the multi_scenario_working_directory and multi_scenario_merged_error_log variables before issuing the create_distributed_farm command.
```

The .synopsys\_pt\_setup file in the directory where the master was launched (/rpt/new) contains the following settings:

```
set multi_scenario_working_directory "./ms_session_1"
set multi_scenario_merged_error_log "merged_errors.log"
```

```
# Start of specifying the set-up
# Start of specifying the first task
set search_path "./scripts"
# Add 2 32 bit hosts to the pool of hosts for
# the distributed farm from hosts platinum1 and platiunm2
add_distributed_hosts -32bit -farm now platinum1
add_distributed_hosts -32bit -farm now platinum2
# Create the distributed farm for processing the scenarios
create distributed farm
# set the upper limit on the license usage
set_multi_scenario_license_limit -feature PrimeTime 2
create_scenario -name s1 \
  -common data common data scenarios s1 s3.tcl \
  -specific_data_scenario_s1.tcl
create_scenario -name s2 \
  -common_data common_data_scenarios_s2_s4.tcl \
  -specific_data specific_data_scenario_s2.tcl
create scenario -name s3 \
  -common_data common_data_scenarios_s1_s3.tcl \
  -specific_data specific_data_scenario_s3.tcl
create_scenario -name s4 \
  -common data common data scenarios s2 s4.tcl \
  -specific_data specific_data_scenario_s4.tcl
##################################
# End of specifying the setup
#################################
current session {s3 s4}
remote_execute -pre_commands {source contraint_group1.tcl\
  source constrint_group2.tcl} {report_timing}
auit
# analysis is finished
# all slaves are inactivated and licenses are returned
```

#### This is what the script does:

1. The initial set command sets the search path at the master (used for finding scripts).

- 2. The add\_distributed\_hosts command specifies that one host from each host, platinum1 and platinum2, is to be added to the distributed farm for running 32 bit processes.
- 3. The create\_distributed\_farm command starts the slave processes on the hosts specified by the add\_distributed\_hosts command.
- 4. The set\_multi\_scenario\_license\_limit command limits to two the number of PrimeTime licenses that the master uses for slave processes.
- 5. The create\_scenario commands create four scenarios named s1 through s4. Each command specifies the common-data and specific-data scripts for the scenario.
- 6. The current\_session command selects s3 and s4 for the current session, which is also the command focus by default. (You can use the current\_scenario command to narrow the focus further.)
- 7. The remote\_execute -pre\_commands command begins the task generation process and execution of those tasks in scenarios s3 and s4. The resulting logs contain all the output from the commands that were executed.
  - Because the <code>-pre\_commands</code> option is specified, the two <code>source</code> commands are executed before the <code>report\_timing</code> command. The command list can contain any valid PrimeTime commands or sourcing of scripts that contain valid PrimeTime commands (excluding all commands that alter the netlist or save or restore).
- 8. The quit command terminates the slave processes and master processes in an orderly manner and returns all the checked-out PrimeTime licences back to the central license pool.

At the end of this example session, you would find the report files and log files in the full file paths listed below (assuming the master pt\_shell was launched from the directory /rpt/new).

Master command log:

```
/rpt/new/pt_shell_command.log
```

 Errors generated by the slaves and returned to the master and merged for reporting purposes:

```
/rpt/new/ms_session_1/merged_errors.log
```

Slave output log for work done for the session, that is, netlist image generation:

```
/rpt/new/ms session 1/default session/out.log
```

Slave output logs generated for s1 and s2:

```
/rpt/new/ms_session_1/s3/out.log
/rpt/new/ms_session_1/s4/out.log
```

#### Slave command logs:

```
/rpt/new/ms_session_1/pt_shell_command_log/
   platinum1_pt_shell_command.log
/rpt/new/ms_session_1/pt_shell_command_log/
   platinum2_pt_shell_command.log
```

#### **Modeling Support**

Distributed multi-scenario analysis supports interface logic models and extracted timing models without your having to perform any special work for setup. Additionally, you should not have to change any modeling arrangements made to your design. For more information about modeling support in PrimeTime, see the *PrimeTime Modeling User Guide*.

## **Activating CCS Timing Voltage Scaling**

A scenario is a specific combination of operating condition and operating mode for a given configuration. You create a scenario with the <code>create\_scenario</code> command, as in the following example:

This command specifies a scenario name, the common-data script files, and the specific-data script files.

## **Using Common or Specific Script Scenarios**

When you set up scenarios using common or specific scripts (-common\_scripts or -specific\_scripts options, respectively), you must create voltage scaling groups just before running the link\_design in one of the scripts used to set up a scenario.

If voltage scaling groups are created in a script that is part of a scenario's -specific\_scripts specification, only that scenario sees those scaling groups. If voltage scaling groups are created in a script that is part of a scenario's -common\_scripts specification and another scenario shares the same common specification, both of those scenarios see the same voltage scaling groups.

## Creating a New Scenario With a Previously Saved Scenario

If you specified voltage scaling groups in a single scenario analysis and ran the save\_session command, those voltage scaling groups are available to any scenario using that saved session. To access the saved scenario, use the create\_scenario -image command.

#### Limitations

The distributed multi-scenario feature has the following known functional limitations and issues:

- Maximum number of slave processes
   Currently, the maximum number of slave processes that the master process can control 256 concurrent hosts.
- Number of allocated licenses
   You cannot reduce the number of allocated licenses after they have been allocated.
- No support for the -true or -justify options of the merged report\_timing command

## 2

# Distributed Multi-Scenario Analysis Netlist Editing Support

PrimeTime provides commands for editing the netlist. Editing the netlist is performed to address timing issues without having to iterate through logic synthesis.

The netlist editing capability is described in the following sections:

- Introduction
- Editing the Netlist
- Replacement Cell Lookup
- Supporting ECO Commands

#### Introduction

PrimeTime distributed multi-scenario analysis feature provides the ability to make incremental changes to the netlist, such as <code>size\_cell</code> and <code>insert\_buffer</code>. It also enables you to analyze the circuit timing in the presence of these changes. This feature is important in the work flow for creating, evaluating, and implementing engineering change orders (ECOs). The distributed multi-scenario analysis flow supports the use of all netlist editing commands (except for <code>swap\_cell</code>). Using this feature you can quickly evaluate the effects of different netlist edits and obtain merged reporting on the tested scenarios.

You can execute any number of netlist editing commands using a varying command focus. Therefore, distributed multi-scenario analysis supports execution of netlist editing commands on a per-scenario basis using the remote\_execute command. The execution speed of these operations is highly optimized. Netlist editing command execution is also supported directly at the master; however, complex nested command structures are not supported in this mode of operation.

#### **Editing the Netlist**

The PrimeTime distributed multi-scenario analysis supports the use of the following netlist editing commands.

Table 2-1 Netlist Editing Commands

Object	Task	Command
Buffer	Inserting a buffer Removing a buffer	insert_buffer remove_buffer
Cell	Changing the size (or drive strength) of a cell Creating a cell Renaming a cell Removing a cell	size_cell create_cell rename_cell remove_cell
Net	Adding a new net to the design Connecting nets to pins in the design Disconnecting nets from pins in the design Renaming a net Removing a net	create_net connect_net disconnect_net rename_net remove_net

The swap\_cell netlist editing command is not supported at the master in distributed multi-scenario analysis, but can execute through theremote\_execute command. For more information about netlist editing in PrimeTime, see *PrimeTime Advanced Timing Analysis User Guide*.

## **Replacement Cell Lookup**

When replacing or sizing a cell in the current design, the PrimeTime applies the change to all scenarios in the current focus. Therefore, it is most useful to determine the alternative library cells you can use to replace a cell on all those scenarios, excluding library cells that you can only use as a replacement cell on a subset of the scenarios in the current design. By executing the <code>get\_alternative\_lib\_cells-base\_names</code> command in a master context, PrimeTime returns a list of library cell base names. You can use any library cell base name with the <code>size\_cell</code> command to replace the existing cell.

PrimeTime returns library cells in the order in which they are found according to the same search order that exists for the <code>size\_cell</code>, <code>insert\_buffer</code>, and <code>create\_cell</code> commands. For more information about the order in which libraries are searched, see *PrimeTime Advanced Timing Analysis User Guide*.

#### **Supporting ECO Commands**

You can execute the following commands in a slave process using the remote\_execute command and apply them to all the scenarios in the command focus:

- set coupling separation
- remove\_coupling\_separation
- read\_parasitics -eco

The set\_coupling\_separation command in distributed multi-scenario analysis allows you to create a separation constraint on nets in all the scenarios in command focus. Additionally, you can remove the coupling separation from all scenarios in command focus using the remove\_coupling\_separation command.

The <code>-eco</code> option to the <code>read\_parasitics</code> command indicates the files you are annotating are ECO parasitics from Star-RCXT only. In distributed multi-scenario analysis, you can use this option with the <code>read\_parasitics</code> command to apply the feature to all scenarios in command focus.

#### Note:

In the slave context, the <code>get\_alternative\_lib\_cells</code> and <code>report\_alternative\_lib\_cells</code> operate the same as these commands would when in the single-core analysis mode of PrimeTime.



## **Master Command List**

This appendix lists all of the commands that you use during a distributed multi-scenario analysis.

#### Note:

All regular Tcl commands are supported.

These commands are broken down into several sections within this appendix.

- · Configuration and Setup Commands
- Process Setup Commands
- License Setup Command
- Analysis Focus Commands
- Slave Context Commands
- Distributed Multi-Scenario Analysis report\_timing Options
- Reporting Variables
- Disallowed Commands

## **Configuration and Setup Commands**

Table A-1 lists the commands to use to create and remove your multi-scenario configurations and scenarios.

Table A-1 Configuration and Setup Commands

Command	Description
create_scenario	Creates a single scenario.
	This command is required.
-name [scenario_name]	A unique string used to identify and refer to a single scenario.
-common_data {file_list}	A list of files that contains commands and data that is common across scenarios.
	These files and the netlist image are used to generate the baseline image for the scenario.
-specific_data {file_list}	A list of files that contains commands and data that is specific to the scenario being created.
-common_variables {list}	A list of variables that is common across scenarios.
<pre>-specific_variables {list}</pre>	A list of variables that is specific to the scenario being created.
-image	Restores a PrimeTime session.
remove_scenario {scenario_list}	Removes one or more scenarios which are given as a list to the command.
remove_multi_scenario_design	Removes all multi-scenario data specified, including the session, all the scenarios, and the configuration.
report_multi_scenario_design	Reports on the current user-defined multi-scenario analysis.
-configuration	Reports on the current configuration.
-scenario	Reports on the current scenario.
-session	Reports on the current session.
-license	Reports on the current license.

## **Process Setup Commands**

Table A-2 lists the commands to use to add and remove distributed processes.

Table A-2 Process Setup Commands

Command	Description
add_distributed_hosts	Adds distributed hosts to the farm's pool.
	This command is required.
[-32bit]	Specifies the type of executable to be used.
-farm	Specifies the type of farm that is the source of the distributed hosts. The types must be one of $lsf$ , $grd$ , $generic$ , or $now$ .
[-setup_path setup path]	Specifies the path where submission scripts for grd, lsf or generic reside.
	LSF—the setup path should contain "bsub", "bkill"
	GRD— the setup path should contain "qsub", "qdel"
	Generic—the setup path should contain "gsub", "gdel"
[-num_of_hosts count]	Specifies the number of distributed hosts to use. If this is not specified one is assumed.
[-submission_script]	You can explicitly specify the script to call when submitting jobs to farm types grd, lsf or generic using this option. When both the <i>-setup_path</i> and <i>-submission_script</i> options are used simultaneously, the path and submission Sept. specification are combined to define the script used when submit jobs to the specified computing resource.
	The -submission_script option is not valid with -farm now.
[-options] string	Specifies the options to be provided to the submission_script.
[workstation_name]	Specifies the name of a work station (in now).
remove_distributed_hosts	Removes all distributed hosts added to the farm's pool.
create_distributed_farm	Starts the slave processes on the hosts specified by the add_distributed_hosts command.

## **License Setup Command**

Table A-3 shows the command to use to set the number of licenses the master can use to control the slave sessions.

Table A-3 License Setup Command

Command	Description
set_multi_scenario_license_limit	Specifies the number of licenses the master can use for slave processes.
	This command is required.
number	An integer greater than zero (0). This number should be equal to the number of slave processes you wish to use.
-feature feature	String consisting of the feature name. Values are PrimeTime, PrimeTime-SI.
	For example, -feature PrimeTime 4 checks out four PrimeTime licenses from the global license pool for slave usage.
-force_checkout	Forces licenses to be checked out immediately.

## **Analysis Focus Commands**

Table A-4 lists the commands to use to set and remove sessions and scenarios that interpret commands from the master process.

Table A-4 Analysis Focus Commands

Command	Description
current_session	Puts a particular group of scenarios in focus for analysis. The scenarios in focus receive and interpret commands from the master. Returns a list of all scenarios in the current session.
	This command is required.
-all	Adds all previously created scenarios to the current scenario.

Table A-4 Analysis Focus Commands (Continued)

Command	Description
{scenario_list}	A list of the names of scenarios to put in the current session. All scenarios listed must have previously been created.
remove_current_session	Removes the previously set session. Defocuses all scenarios.
	Scenarios stay in memory until removed by the remove_scenario or quit command.
current_scenario	Changes the command focus to the selected scenarios within the current session. Returns a list of all scenarios in command focus.
{scenario list}	A list of scenario names in the current session.
[-all]	Brings the focus back to all of the scenarios specified with current_session.

#### **Slave Context Commands**

Table A-5 lists the commands to use to create a command buffer from the master to the slave processes. You can run these commands in batch or interactive mode.

Table A-5 Slave Context Commands

Command	Description
remote_execute	Batch or interactive mode: From the master, creates a command buffer to be executed in the slave context.
-pre_commands {slave_cmd_string}	Specifies string of semicolon-delimited commands to be executed in slave context before the execution of the default command string. The maximum size of a command is 1000 characters.
-post_commands {slave_cmd_string}	Specifies a string of semicolon-delimited commands to be executed in slave context. The maximum size of a command is 1000 characters.
-verbose	Returns all data produced at the slaves to the master terminal.

## Distributed Multi-Scenario Analysis report\_timing Options

Table A-6 lists report\_timing options you can use for multi-scenario reporting.

Table A-6 report\_timing Options

Option	Description
-dont_merge_duplicates	Turns off the merging of duplicate paths in the timing report. By default, when the same path is reported from more than one scenario, PrimeTime reports only the single most critical instance of that path in the merged report and shows its associated scenario. By using this option, PrimeTime does not merge duplicate instances of the same path into a single instance, but instead shows all critical instances of the path from all scenarios. Since the number of paths reported is limited by the <code>-nworst, -max_paths</code> , and other options of this command, the resulting merged report, when this option is used, may not be evenly spread out across the design, but instead may be focused on the portion of the design that is critical in each scenario.
-pre_commands	Specifies string of semicolon-delimited commands to be executed in slave context before the execution of the merged_reporting command. The maximum size of a command is 1000 characters.
-post_commands	Specifies string of semicolon-delimited commands to be executed in slave context before after the execution of the merged_reporting command. The maximum size of a command is 1000 characters.

## **Reporting Variables**

Table A-7 lists variables to use for multi-scenario reporting.

#### Note:

You must set the multi\_scenario\_working\_directory and multi\_scenario\_merged\_error\_log variables before creating the distributed farm.

Table A-7 Reporting Variables

Variable	Description
multi_scenario_merged_error_log	Default value is "".  Note: Must be specified before issuing the create_distributed_farm command.
multi_scenario_merged_error_limit	Default value is 100. Specifies the maximum number of errors of a particular type to be written to the command log on a per-task basis.
multi_scenario_working_directory	Default value is cwd.
	Set the working directory to a directory which can be seen by all slaves and the master and to which you have write permissions.
	Note: Must be specified before issuing the create_distributed_farm command.
pt_shell_mode	Specifies the working mode: primetime, primetime_master, Or primetime_slave.
	This variable is read-only
	You can use this variable in your scripts to determine if you are operating in a normal PrimeTime session or on the master or slave. For example, to block warnings about the working directory, you could use the following:  if {\$pt_shell_mode == "primetime_master"} {     set_multi_scenario_working_directory "/
	home/wd"
	}

#### **Disallowed Commands**

Some commands are not allowed at certain stages of the flow. For example, if during the analysis, you execute the remove\_design command either in a script or at the command line, an error condition results. Table A-8 lists the commands that you cannot run on the slave processes.

Table A-8 Disallowed Commands for Slave Processes

Command	Description
remove_design	Removes one or more designs from memory.
rename_design	Renames a design.
quit	Quits pt_shell.
exit	Exits pt_shell.
restore_session	Restores a pt_shell. session.

Table A-9 lists the commands that you cannot run on the master process.

Table A-9 Disallowed Commands for the Master Process

Command	Description
remove_design	Removes one or more designs from memory.
rename_design	Renames a design.
swap_cell	Swaps a cell with a new design or lib cell.
restore_session	Restores a pt_shell. session.

## В

# Procedure for Filing STARs for Multi-Scenario Analysis

This appendix describes the procedure for filing Synopsys Technical Action Requests (STARs) for multi-scenario analysis problems or issues.

This appendix contains the following sections:

- · Problems and Issues
- Initial Problem Diagnosis
- Transient Issues
- Reproducible Issues
- Other Required Information

#### **Problems and Issues**

Problems and issues in multi-scenario may be difficult to reproduce reliably. It is extremely important to provide comprehensive supporting information when filing a multi-scenario STAR. If you do not provide the information requested, then problem resolution becomes very difficult, resulting in longer turn-around times for filed issues. When diagnosing and filing the issues, follow the steps described in this appendix.

#### **Initial Problem Diagnosis**

The purpose of this procedure is to determine if the issue is a single-core analysis or a multi-scenario analysis specific problem.

To diagnose the problem:

- Try a single-core analysis PrimeTime run with your command set. Do this by running a script file that calls each of the common and specific scenario script components that make up the scenario:
  - · source read netlist.tcl
  - source libs.tcl
  - source operating conditions.tcl
- 2. If the problem occurs in single-core analysis mode, follow the normal STAR filing procedure.
- 3. If the problem does not occur in single-core analysis mode, follow the steps for either a large design (more than 200,000 instances), or a small design (fewer than 200,000 instances).

#### **Diagnosing Large Test Cases**

To diagnose problems for large test cases (more than 200,000 instances):

- 1. Try to establish if this is a transient (intermittent) or reliably reproducible problem.
- 2. Try to reproduce the problem in multi-scenario using the provided demo design. To download the demo design, see the following SolvNet article:
  - https://solvnet.synopsys.com/retrieve/014511.html
- 3. If the problem is transient, see "Transient Issues" on page B-3.
- 4. If the problem occurs every time, see "Reproducible Issues" on page B-4.

- 5. If you are unable to reproduce the issue at all, then document as much as you can about the problem including the hardware setup (see "Other Required Information" on page B-4), and go back to "Initial Problem Diagnosis" on page B-2 and try the same process with your original design while trying to simplify the test case as much as possible.
  - Remove all commands after the problem command, so that the last command received is the one that causes the issue.
  - Remove any other superfluous commands that do not affect the outcome you are observing.
- 6. Package the test case and any additional information and file a STAR using the normal procedure.

#### **Diagnosing Small Test Cases**

To diagnose problems for small test cases (fewer than 200,000 instances):

- 1. Try to establish if this is a transient or reproducible problem.
- 2. Using your test case, try to reproduce the problem in multi-scenario mode.
- 3. If the problem is transient, see "Transient Issues."
- 4. If the problem occurs every time, see "Reproducible Issues" on page B-4.
- 5. If you are unable to reproduce the issue at all, document as much as you can about the problem including the hardware setup (see "Other Required Information" on page B-4).

#### Transient Issues

To diagnose transient issues:

- 1. Try to establish a pattern and record the following data:
  - Describe how often and under what conditions the problem occurred.
  - Are there any other import factors that may be affecting your network?
- 2. Generate the information listed in the "Other Required Information section.
- 3. Package the test case and all the additional information requested, then file a STAR using the normal procedure.

#### Reproducible Issues

If your issue is reproducible, record the conditions as follows:

- Describe under what system conditions the problem occurred.
- Generate the information listed in the "Other Required Information section.
- Package the test case and all the additional information requested and file a STAR using the normal procedure.

#### **Other Required Information**

The following sections describe the other types of information that you must gather before filing a multi-scenario STAR.

#### **Hardware Setup and Loading Conditions**

To gather the hardware setup and loading information for your STAR:

- 1. Define what hardware configuration you are using.
- 2. Specify machine use (master, slave, or both).
- 3. Provide data on your computer using the following commands:
  - uname -aX > snps ms hw uname.txt
  - sysinfo > snps\_ms\_hw\_sysinfo.txt
- 4. Collect the following required information:
  - · Machine manufacturer
  - Number of hosts
  - Amount of RAM
  - Amount of swap space
- 5. Provide data on the loading in your hardware environment. This can be captured with the UNIX top command.

#### **Multi-Scenario Environment**

Provide the following information about your multi-scenario environment:

- 1. Your multi\_scenario\_merged\_error\_log file.
- 2. Your .synopsys\_pt.setup file used at the master launch point or the your .synopsys\_pt.setup file from your home account or both.

#### **Your Environment**

Provide the following information about your environment:

- 1. A text file of all the environment variable settings:
  - printenv > snps\_ms\_printenv.log
  - set > snps\_ms\_set.log
  - setenv > snps\_ms\_setenv.log
- 2. A copy of your .cshrc file.

## C

### Differences Between Single-Core and Multi-Scenario Constraint Reports

This appendix lists the differences in the report output for single-core and distributed multiscenario analysis for constraint reports. It describes the different types of constraints and reporting styles available for the report\_constraint command.

- Constraint Merging Operations
- Printing Styles
- Reporting Modes

#### **Constraint Merging Operations**

There are four fundamental operations performed to gather constraint information for merging reports. Table C-1 describes how these operations are currently defined in single-core analysis mode and how they are supported in the multi-scenario mode of PrimeTime.

Table C-1 Constraint Merging Operation

Name	Single Scenario Analysis	Distributed Multi-Scenario Analysis
Constraint summation	Add all weighted constraint costs of a particular constraint together.	Add the worst constraint cost at each violating endpoint, pin, and net over all scenarios in command focus. When multiple scenarios have the same violating endpoints, pins, or nets, use the worst slack of these scenarios.
Worst constraint per group	Find the worst cost per path group of a particular constraint.	Find the worst cost per path group of a particular constraint across all scenarios. Groups are considered duplicate if they have the same name. If there is a tie between scenarios, the scenario name is used as a tie-breaker
Worst constraint	Find the worst cost of a particular constraint.	Find the worst cost of a particular constraint across all scenarios. If there is a tie between scenario names, group names, or both, the group name and then the scenario name is used as tie-breakers.
Sort constraints	Sort all violators of a particular constraint from best to worst.	Sort all violators of a particular constraint across all scenarios from best to worse. For each constraint type remove any duplicate constraints. A constraint is considered duplicate if the same constraint is specified on the same pin. Two pins are considered duplicate if they have the same leaf name and hierarchy. For example, a/b/c, d, a/b, c/d are different. If there is a tie between constraints, the scenario name is used as the tie-breaker

#### **Printing Styles**

There are a number of printing styles you can specify to write out an individual constraint report. Table C-2 describes how these printing styles are currently defined in the single-core analysis mode and how they are defined in the multi-scenario mode of PrimeTime.

Table C-2 Printing Styles

Printing Style	Single Scenario	Analysis		Distribu	uted Multi-	Scena	ario Anal	ysis
Group summary	Group (max_delay/setup) CLK	Cost Weight	Weighted Cost 0.00	Group (ma	ax_delay/setup)	Cost 0.00	Weight	Weighted Cost 0.00
Constraint summary	Constraint	Cost	OLATED)	Constraint max_delay			Cost 2.46 (VIOL	ATED)
Object summary	Pin         pulse v           nand1/Z         10.00	,	Slack	Pin nand1/Z		lse width	pulse widtl	n Slack -0

Table C-2 Printing Styles (Continued)

Printing Style	Single Scenario Ana	lysis		Distributed Multi-Sce	nario Anal	ysis
Path verbose	Startpoint: c (input port)			Ctade aint: a (input part)		
	Endpoint: z3 (output port) Path Group: default Path Type: max			Startpoint: c (input port) Endpoint: z3 (output port) Path Group: default Scenario: scen1	i)	
	Point	Incr	Path	Path Type: max	Incr	Path
	input external delay c (in) U6/Z (IV)	0.00 0.00 1.34	0.00 r 0.00 r 1.34 f	input external delay c (in)	0.00 0.00	0.00 r 0.00 r
	U2/Z (NŔ2) U15/Z (AO7) U24/Z (AO3)	3.35 0.87 1.02	4.69 r 5.56 f 6.57 r	UĠ/Ź (IV) U2/Z (NR2)	1.34 3.35 0.87	1.34 f 4.69 r 5.56 f
	z3 (out) data arrival time	0.00	6.57 r 6.57	U15/Z (AO7) U24/Z (AO3) z3 (out) data arrival time	1.02 0.00	6.57 r 6.57 r 6.57
	max_delay output external delay data required time	6.50 0.00 6.50	6.50 6.50	max_delay output external delay	6.50 0.00	6.50 6.50
	data required time data arrival time		6.50 -6.57	data required time data required time data arrival time	6.50	6.50 -6.57
	slack (VIOLATED)		-0.07	slack (VIOLATED)		-0.07
Path slack only						
summary	min_delay/hold ('CLK' group)			min_delay/hold ('CLK' grou	p)	
	Endpoint ffd/CR	-0.40 (VIC	DLATED)	Endpoint Scenario ffd/CR scen1	Slack -0.40 (\	/IOLATED)
Object verbose	Net: a			Net: a Scenario: scen1	·	,
	max_fanout	5.00		max_fanout	5.00	
	- Fanout Slack	7.00 -2.00 (VIO	LATED)	- Fanout Slack	7.00 -2.00 (VIOL	ATED)

#### **Reporting Modes**

Table C-3 classifies the constraints into different constraint types. Each constraint type has several reporting modes depending on the -all\_violators, -path\_type, and -verbose options that you specify. Each reporting mode is associated with a particular merging operation (see Table C-1) and printing format (see Table C-2).

Table C-3 Reporting Modes

Constraint Type	Constraints	Report Mode
Connection class	connection_class	Summary  Constraint summary  Verbose  Worst constraint  Object verbose  All violators  Sort constraints  Object summary  All violators, verbose  Sort constraints  Object verbose
Design rule checking	<ul> <li>max_capacitance</li> <li>min_capacitance</li> <li>max_transition</li> <li>min_transition</li> <li>max_fanout</li> <li>min_fanout</li> <li>max_area</li> </ul>	<ul> <li>Summary</li> <li>Constraint summary</li> <li>Verbose</li> <li>Worst constraint</li> <li>Object verbose</li> <li>All violators</li> <li>Sort constraints</li> <li>Object summary</li> <li>All violators, verbose</li> <li>Sort constraints</li> <li>Object verbose</li> <li>Sort constraints</li> <li>Object verbose</li> </ul>

Table C-3 Reporting Modes (Continued)

Constraint Type	Constraints	Report Mode
Miscellaneous timing constraints	<ul><li>min_pulse_width</li><li>min_period</li><li>max_skew</li><li>clock_separation</li></ul>	<ul> <li>Constraint summation</li> <li>Constraint summary</li> <li>Verbose</li> <li>Worst constraint</li> <li>Object verbose</li> <li>All violators</li> <li>Sort constraints</li> <li>Object summary</li> <li>All violators, verbose</li> <li>Sort constraints</li> <li>Path verbose</li> </ul>
Timing path	<ul> <li>setup</li> <li>hold</li> <li>clock_gating_setup</li> <li>clock_gating_hold</li> <li>recovery</li> <li>removal</li> </ul>	<ul> <li>Summary</li> <li>Worst constraint per group (clock_gating_setup, setup, and recovery)</li> <li>Constraint summation (clock_gating_hold, hold, and removal)</li> <li>Group summary</li> <li>Constraint summary</li> <li>Verbose</li> <li>Worst constraint per group</li> <li>Path verbose</li> <li>All violators</li> <li>Sort constraints</li> <li>Path slack only summary</li> <li>All violators, verbose</li> <li>Sort constraints</li> <li>Path verbose</li> <li>All violators, path_type_end</li> <li>Sort constraints</li> <li>Object summary</li> </ul>

### Index

A  add_distributed_hosts command 1-7, 1-9,	analysis focus A-4 configuration and setup A-2 create_distributed_farm 1-7, 1-11, A-3 create_scenario 1-3, 1-7, 1-16, 1-20, 1-49,
·	• –

detailed merged analysis coverage report 1-31
disallowed commands A-8
distribited variable values
merging 1-26
distributed analysis process 1-23
distributed farm
creating 1-11
distributed hosts
adding 1-7, 1-9
distributed processing setup 1-8
_
E
editing commands
for netlists 2-2
enable_license_auto_reduction variable 1-15
error logs 1-9
_
F
farm
distributed 1-11
fault handling
controlling 1-40
merged reporting commands 1-41 netlist editing 1-41
remote_execute command 1-42
flow
diagram 1-6, 1-12
overview 1-4 to 1-7
C
G
get_alternative_lib_cells command 2-3 get_distributed_variables command 1-25, 1-26
get_timing_paths command 1-30 GRD 1-9
Ц
Н
hardware setup B-4

nosts adding 1-7, 1-9	merged reporting 1-23 to 1-38 example 1-32
adding 1-7, 1-9	log file 1-9
	options A-6
	overview 1-29
image	
image current 1-2	using 1-29
incremental licenses	merged reports
handling 1-14	constraint summary example 1-34, 1-35 generating 1-30
reducing 1-14	merging 1-30
invoking	distributed variable values 1-26
multi-scenario analysis 1-5	
PrimeTime for distributed processing 1-8	muliple scenarios processing in parallel 1-2
issue	
diagnosing B-2	multi_scenario_fault_handling variable 1-40
diagnosing large test cases B-2	multi_scenario_merged_error_limit variable A-7
diagnosing small test cases B-3 diagnosing transient B-3	multi_scenario_merged_error_log variable 1-9, 1-20, A-7
procedure for filing B-1	multi_scenario_working_directory variable
reproducible B-4	1-7, 1-8, 1-20, A-7
	multi-scenario analysis
L	restoring session 1-23
	saving session 1-23
licenses 1-12 to 1-14	
auto-reduction 1-15	N
handling 1-14	
reducing 1-14	netlist editing 2-2
setup commands A-4	fault handling 1-41
spanning 1-15	netlist editing commands 2-2
loading conditions B-4	NOW (network of workstations) 1-9
log files 1-9	
LSF 1-9	0
M	optimizing performance 1-22
managed compute resources 1-9	overview
	distributed muli-scenario analysis 1-2
managing resources	
dynamically 1-7	Р
master process 1-2	•
merged report	PrimeTime PX 1-8
cosntraint example 1-34	problem

diagnosing B-2 diagnosing large test cases B-2 diagnosing small test cases B-3 diagnosing transient B-3 procedure for filing B-1 reproducible B-4 process master 1-2 setup commands A-3 slave 1-3 processing scenarios 1-7 pt_shell_mode variable A-7	detailed merged analysis coverage example 1-31 executing commands 1-29 generating merged reports 1-30 merged example 1-32 summary merged analysis coverage example 1-31 variables A-7 reporting modes for constraints C-5 reproducible issues B-4 restoring
	multi-scenario analysis 1-23
R read_ddc command 1-15 read_milkyway command 1-15	S save_session command 1-23, 1-50 saving
read_parasitics command 2-3 reducing licenses 1-14, 1-15 remote execution 1-18 to 1-20 remote_execute fault handling 1-42	multi-scenario analysis session 1-23 scenario 1-3, 1-16 to 1-17 creating 1-3 creating from previously saved session 1-50 removing 1-17
remote_execute command 1-7, 1-18, 1-20, 1-42, 2-2, A-5 remove_current_session command A-5	scripts 1-4 command-data 1-16 specific-data 1-16
remove_multi_scenario_design command A-2 remove_scenario command 1-17, A-2 removing scenarios 1-17	scripts using scenarios 1-49 search path 1-4 to 1-5 search_path variable 1-4 to 1-5
report_analysis_coverage command 1-30 report_clock_timing command 1-32 report_constraint command 1-33, 1-34, C-1 report_multi_scenario_design command 1-18, A-2	session 1-3, 1-4 current 1-18 definition 1-3 saving 1-23
report_si_bottleneck command 1-35 report_timing command 1-29, 1-36, A-6	set_distributed_variables command 1-24 set_multi_scenario_license_limit command 1-6, 1-13, 1-14, A-4
report_timing options A-6 reporting constraint example 1-34 constraint summary example 1-34, 1-35	setup checking 1-18 distributed processing 1-8 file file.setup 1-5

slave test cases, diagnosing B-2, B-3 adding hosts 1-7 transient issues, diagnosing B-3 allocation 1-9 context commands A-5 IJ definition 1-3 specific script scenarios 1-49 unmanaged compute resources 1-9 specific-data scripts 1-4, 1-16 **NOW 1-9** specifying licenses 1-6 usage flow 1-5 to 1-7 **STARs** hardware and loading information B-4 V procedure for filing B-1 starting variables multi-scenario analysis 1-5 enable\_license\_auto\_reduction 1-15 PrimeTime for distributed processing 1-8 multi scenario fault handling 1-40 multi\_scenario\_merged\_error\_limit A-7 summary merged analysis coverage report example 1-31 multi\_scenario\_merged\_error\_log 1-9, 1-20, support multi\_scenario\_working\_directory 1-7, 1-8, database 1-15 1-20, A-7 Synopsys Technical Action Requests, pt\_shell\_mode A-7 procedure for filing B-1 reporting A-7 .synopsys\_pt.setup file 1-5 search\_path 1-4 to 1-5 setting values 1-24

task 1-3, 1-21

Т