## PRG Jumper used to program ATTINY261

BKLT\_SRC: 2-3 5V connected, D6 PWM not used

