

EB tresos® AutoCore Generic 8 CRY documentation

Module release 2.6.2





Elektrobit Automotive GmbH Am Wolfsmantel 46 91058 Erlangen, Germany Phone: +49 9131 7701 0

Fax: +49 9131 7701 6333

Email: info.automotive@elektrobit.com

Technical support

https://www.elektrobit.com/support

Legal disclaimer

Confidential and proprietary information

ALL RIGHTS RESERVED. No part of this publication may be copied in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Elektrobit Automotive GmbH.

All brand names, trademarks and registered trademarks are property of their rightful owners and are used only for description.

Copyright 2019, Elektrobit Automotive GmbH.



Table of Contents

1.	Overvi	ew	8
2.	Cry m	odule release notes	9
	2.1.	Change log	9
	2.2.	New features	. 12
	2.3.	EB-specific enhancements	. 12
	2.4.	Deviations	. 13
	2.5.	Limitations	. 13
3.	Cry us	er's guide	. 15
	3.1.	Overview	. 15
	3.2.	Background information	15
		3.2.1. Mapping of Cryptographic Functionalities to Csm Services	15
		3.2.2. Using the time slicing feature for RSASSA-PSS and RSASSA-PKCS1-v1_5 signature	
		verification	. 17
		3.2.3. Using the restart feature	. 17
		3.2.4. Using the immediate restart feature	18
		3.2.5. AES implementation variants	. 19
		3.2.6. Using the time slicing feature for SHA-1 and SHA-2 primitives	. 20
		3.2.7. Using the time slicing feature for EdDSA signature generation and verification primi-	
		tives	. 20
		3.2.8. Long number library implementation variants	
	3.3.	Configuring the Cry	. 23
4.	Cry m	odule references	. 27
	4.1.	Configuration parameters	. 27
		4.1.1. CommonPublishedInformation	. 28
		4.1.2. CryGeneral	. 31
		4.1.3. CrySHA1	. 34
		4.1.4. CrySHA1Config	. 34
		4.1.5. CrySHA2	. 35
		4.1.6. CrySHA2Config	. 36
		4.1.7. CrySHA3	
		4.1.8. CrySHA3Config	. 38
		4.1.9. CryRsaSsaPssVerify	39
		4.1.10. CryRsaSsaPssVerifyConfig	. 41
		4.1.11. CryRsaSsaV15Generate	. 42
		4.1.12. CryRsaSsaV15GenerateConfig	. 43
		4.1.13. CryRsaSsaV15Verify	. 43
		4.1.14. CryRsaSsaV15VerifyConfig	. 45
		4.1.15. CryEdDSAVrfy	. 46
		4.1.16. CryEdDSAVrfyConfig	. 47

49
+9
50
51
51
52
53
54
54
54
55
55
56
57
57
58
58
58
59
59
60
60
62
62
62
62
63
63
64
65
67
67
68
68
69
69
70
70
72
72
73
73



4.2.1. Type definitions	73
4.2.1.1. Cry_EdDSAGenKeyType	. 73
4.2.1.2. Cry_EdDSAVrfyKeyType	74
4.2.1.3. Cry_ExtractECPubKeyCtxType	74
4.2.1.4. Cry_ExtractECPubKeyStateType	74
4.2.2. Macro constants	. 75
4.2.2.1. CRY_MD5_BLOCK_SIZE	. 75
4.2.2.2. CRY_MD5_HASH_LEN_BYTES	75
4.2.2.3. CRY_MD5_STATE_BYTES	75
4.2.2.4. CRY_MD5_STATE_WORDS	76
4.2.3. Functions	76
4.2.3.1. Cry_AES_DecryptFinish	76
4.2.3.2. Cry_AES_DecryptMainFunction	76
4.2.3.3. Cry_AES_DecryptStart	77
4.2.3.4. Cry_AES_DecryptUpdate	77
4.2.3.5. Cry_AES_EncryptFinish	78
4.2.3.6. Cry_AES_EncryptMainFunction	78
4.2.3.7. Cry_AES_EncryptStart	79
4.2.3.8. Cry_AES_EncryptUpdate	79
4.2.3.9. Cry_CMACGenFinish	80
4.2.3.10. Cry_CMACGenMainFunction	81
4.2.3.11. Cry_CMACGenStart	81
4.2.3.12. Cry_CMACGenUpdate	82
4.2.3.13. Cry_CMACVrfyFinish	82
4.2.3.14. Cry_CMACVrfyMainFunction	83
4.2.3.15. Cry_CMACVrfyStart	83
4.2.3.16. Cry_CMACVrfyUpdate	. 84
4.2.3.17. Cry_CRCFinish	84
4.2.3.18. Cry_CRCMainFunction	85
4.2.3.19. Cry_CRCStart	. 85
4.2.3.20. Cry_CRCUpdate	86
4.2.3.21. Cry_CVCPublicKeyExtractFinish	86
4.2.3.22. Cry_CVCPublicKeyExtractMainFunction	87
4.2.3.23. Cry_CVCPublicKeyExtractStart	87
4.2.3.24. Cry_CVCPublicKeyExtractUpdate	88
4.2.3.25. Cry_CbcPkcs7DecryptFinish	88
4.2.3.26. Cry_CbcPkcs7DecryptMainFunction	89
4.2.3.27. Cry_CbcPkcs7DecryptStart	89
4.2.3.28. Cry_CbcPkcs7DecryptUpdate	
4.2.3.29. Cry_CbcPkcs7EncryptFinish	91
4.2.3.30. Cry_CbcPkcs7EncryptMainFunction	91
4.2.3.31. Cry_CbcPkcs7EncryptStart	92



4.2.3.32. Cry_CbcPkcs7EncryptUpdate	92
4.2.3.33. Cry_CcmDecryptFinish	93
4.2.3.34. Cry_CcmDecryptMainFunction	94
4.2.3.35. Cry_CcmDecryptStart	94
4.2.3.36. Cry_CcmDecryptUpdate	94
4.2.3.37. Cry_CcmEncryptFinish	95
4.2.3.38. Cry_CcmEncryptMainFunction	96
4.2.3.39. Cry_CcmEncryptStart	96
4.2.3.40. Cry_CcmEncryptUpdate	97
4.2.3.41. Cry_EdDSAGenFinish	97
4.2.3.42. Cry_EdDSAGenMainFunction	98
4.2.3.43. Cry_EdDSAGenStart	98
4.2.3.44. Cry_EdDSAGenUpdate	99
4.2.3.45. Cry_EdDSAVrfyFinish	99
4.2.3.46. Cry_EdDSAVrfyMainFunction	100
4.2.3.47. Cry_EdDSAVrfyStart	100
4.2.3.48. Cry_EdDSAVrfyUpdate	101
4.2.3.49. Cry_ExtractECPubKeyFinish	101
4.2.3.50. Cry_ExtractECPubKeyMainFunction	102
4.2.3.51. Cry_ExtractECPubKeyStart	102
4.2.3.52. Cry_ExtractECPubKeyUpdate	102
4.2.3.53. Cry_ExtractRsaPublicKeyFinish	103
4.2.3.54. Cry_ExtractRsaPublicKeyMainFunction	104
4.2.3.55. Cry_ExtractRsaPublicKeyStart	104
4.2.3.56. Cry_ExtractRsaPublicKeyUpdate	104
4.2.3.57. Cry_HMACGenFinish	105
4.2.3.58. Cry_HMACGenMainFunction	106
4.2.3.59. Cry_HMACGenStart	106
4.2.3.60. Cry_HMACGenUpdate	107
4.2.3.61. Cry_HMACVrfyFinish	107
4.2.3.62. Cry_HMACVrfyMainFunction	108
4.2.3.63. Cry_HMACVrfyStart	108
4.2.3.64. Cry_HMACVrfyUpdate	109
4.2.3.65. Cry_KEY_SYM_ExtractFinish	110
4.2.3.66. Cry_KEY_SYM_ExtractMainFunction	110
4.2.3.67. Cry_KEY_SYM_ExtractStart	110
4.2.3.68. Cry_KEY_SYM_ExtractUpdate	111
4.2.3.69. Cry_MD5AlgorithmId	111
4.2.3.70. Cry_MD5Finish	112
4.2.3.71. Cry_MD5MainFunction	113
4.2.3.72. Cry_MD5Start	113
4.2.3.73. Cry_MD5Update	113



4.2.3.74. Cry_RsaSsaPssVerifyFinish	. 114
4.2.3.75. Cry_RsaSsaPssVerifyMainFunction	. 114
4.2.3.76. Cry_RsaSsaPssVerifyStart	115
4.2.3.77. Cry_RsaSsaPssVerifyUpdate	115
4.2.3.78. Cry_RsaSsaV15GenFinish	116
4.2.3.79. Cry_RsaSsaV15GenMainFunction	116
4.2.3.80. Cry_RsaSsaV15GenStart	116
4.2.3.81. Cry_RsaSsaV15GenUpdate	116
4.2.3.82. Cry_RsaSsaV15VerifyFinish	116
4.2.3.83. Cry_RsaSsaV15VerifyMainFunction	117
4.2.3.84. Cry_RsaSsaV15VerifyStart	117
4.2.3.85. Cry_RsaSsaV15VerifyUpdate	118
4.2.3.86. Cry_SHA1Algorithmld	118
4.2.3.87. Cry_SHA1Finish	119
4.2.3.88. Cry_SHA1MainFunction	120
4.2.3.89. Cry_SHA1Start	120
4.2.3.90. Cry_SHA1Update	120
4.2.3.91. Cry_SHA2Algorithmld	121
4.2.3.92. Cry_SHA2Finish	121
4.2.3.93. Cry_SHA2MainFunction	122
4.2.3.94. Cry_SHA2Start	122
4.2.3.95. Cry_SHA2Update	123
4.2.3.96. Cry_SHA3Algorithmld	123
4.2.3.97. Cry_SHA3Finish	124
4.2.3.98. Cry_SHA3MainFunction	124
4.2.3.99. Cry_SHA3Start	125
4.2.3.100. Cry_SHA3Update	125
4.2.3.101. Cry_SSGGenerate	126
4.2.3.102. Cry_SSGGenerateMainFunction	126
4.2.3.103. Cry_SSGSeedFinish	126
4.2.3.104. Cry_SSGSeedMainFunction	127
4.2.3.105. Cry_SSGSeedStart	127
4.2.3.106. Cry_SSGSeedUpdate	. 127
4.3. Integration notes	128
4.3.1. Integration requirements	128



1. Overview

Welcome to the EB tresos AutoCore Generic 8 CRY product release notes and documentation.

This document provides:

- Chapter 2, "Cry module release notes": details of changes and new features in the current release
- Chapter 3, "Cry user's guide": concept information and configuration instructions
- Chapter 4, "Cry module references": configuration parameters and the application programming interface



2. Cry module release notes

AUTOSAR R4.0 Rev 3

AUTOSAR SWS document version: 1.2.0

Module version: 2.6.2.B256295

Supplier: Elektrobit Automotive GmbH

2.1. Change log

This chapter lists the changes between different versions.

Module version 2.6.2

2018-07-26

ASCCRY-335 Fixed known issue: EdDSA signature verification gets stuck in endless loop if the key/signature cannot be decoded

Module version 2.6.1

2018-06-22

Corrected macro name for multiple inclusion protection for files Cry HMACGen.h and Cry HMACVrfy.h

Module version 2.6.0

2018-03-30

- Changed the HMAC primitive with respect to the generated/verified MAC length. The length of the generated MAC is now specified in bytes, whilst the length of the MAC to be verified is now specified in bits
- ASCCRY-323 Fixed known issue: RsaSsaV15 signature generation primitive gets stuck if synchronous mode is used
- ASCCRY-311 Fixed known issue: EdDSA signature generate/verify primitives get stuck if synchronous mode is used
- ASCCRY-307 Fixed known issue: Cry HMAC primitive calls the Csm callback notification with a wrong error code.
- Improved the speed of the Long Number library



- ASCCRY-308 Fixed known issue: HMAC generate/verify primitives get stuck if synchronous mode is used
- ASCCRY-313 Fixed known issue: Elliptic curve key extraction primitive gets stuck if synchronous mode is used
- ► ASCCRY-312 Fixed known issue: CCM encryption/decryption primitives get stuck if synchronous mode is used

Module version 2.5.0

2018-01-30

- ASCCRY-298 Fixed known issue: Cry will not compile if only CCM encryption is used
- ASCCRY-294 Fixed known issue: RSA signature verify primitives get stuck if synchronous mode is used
- Implemented the time slicing feature for EdDSA signature generation/verification
- ASCCRY-301 Fixed known issue: Cry symmetric block encryption/decryption primitive gets stuck if the callback is called with an error code

Module version 2.4.0

2017-11-16

- ASCCRY-279 Fixed known issue: Cry might not compile if a mix between RsaSsaV15 and RsaSsaPss signature verifications with Barrett reduction is used
- Implemented performance optimized RSA verification variants
- Improved the EdDSA signature verification algorithm
- Implemented elliptic curve asymmetric public key extraction algorithm
- Optimized the speed of the SHA-1/SHA-2 algorithm implementations. Implemented non-interruptable SHA-1/SHA-2 algorithm variants
- ASCCRY-266 Fixed known issue: RsaSsaV15 signature generation primitive might perform an out-of-bounds memory access

Module version 2.3.0

2017-09-28

- Implemented checksum algorithms:CRC-8, CRC-16, CRC-32.
- Optimized the speed of the AES algorithm implementation. Implemented a look-up table based AES encryption and decryption variant



- Implemented the immediate restart feature for the following primitives: It is available for the MD5, SHA-2, SHA-3, CMAC, HMAC, SSGSeed, SSGGenerate, AES encryption/decryption, CBC PKCS7 encryption/decryption, RSA and symmetric key extraction, RSASSA-PSS and RSASSA-PKCS1-v1_5 signature verification.
- ► Implemented RSASSA-PKCS1-v1_5 signature generation algorithm.
- Implemented SHA-224, SHA-384 and SHA-512 algorithms.
- Implemented feature which allows to configure the number of Cry_SHA1 or Cry_SHA2 algorithms iterations per main function call.
- Implemented OMAC2 and CCM algorithm.
- Implemented EdDSA signature generation/verification algorithm.
- Implemented the immediate restart feature for the EdDSA signature generation/verification.
- Implemented feature to restart an ongoing cryptographic process. The feature was added for the HashEd-DSA variants of Edwards-curve Digital Signature Algorithm, which is named Ed25519ph.

Module version 2.2.0

2017-07-03

- Implemented asymetric public key extraction algorithm.
- Added salt length check for RsaSsa-PSS siganture verification.
- Implemented MD5 hash functions.
- ASCCRY-228 Fixed known issue: Non-existing functions referenced in Cry_Bswmd.arxml
- ASCCRY-229 Fixed known issue: BSW-MODULE-ENTRY for SHA3 is missing
- ASCCRY-230 Fixed known issue: Invalid BSW-MODULE-ENTRY Cry_CMACGentart referenced in Cry_-Bswmd.arxml

Module version 2.1.0

2017-03-31

- Implemented SHA-3 hash functions.
- Implemented Edwards-curve Digital Signature Algorithm.
- Implemented Edwards-curve Digital Signature Algorithm.

Module version 2.0.3

2016-06-22



- ASCCRY-132 Fixed known issue: Incorrect closing of memory section in file Cry_CVCPublicKeyExtract.c
- Implemented new feature which allows to configure the time spent in a main function call, during signature verification (RsaSsaPss and RsaSsaV15). Added feature that allows configuring time slicing callback function, when time slicing is activated.
- Implemented feature to cancel an ongoing cryptographic process. The feature was added for SHA-2, RSASSA-PKCS1-v1_5 and RSASSA-PSS primitives.

Module version 2.0.2

2016-04-27

- ▶ Improved stability of Der parser for primitive CVCPublicKeyExtract
- Corrected parameter description of the application programming interface (API)
- ▶ Added new configuration parameter CryCVCPublicKeyExtractEnableCertChain
- ► Changed the return value of the API Cry_CMACGenFinish from CSM_E_SMALL_BUFFER to CSM_-E_NOT_OK
- ASCCRY-135 Fixed known issue: Cry_RsaSsaV15VerifyUpdate and Cry_RsaSsaV15VerifyFinish return CSM_E_BUSY when CSM_E_NOT_OK is expected
- ASCCRY-136 Fixed known issue: If Csm_HashUpdate returns an error, the algorithm Cry_RsaSsaV15 does not report the error to the application

Module version 2.0.0

2015-10-15

Cry primitives compliant to AUTOSAR 4.0.3

2.2. New features

Improved speed of the Long Number library: The Cry module offers the configuration parameters named CryLNAlgorithmImplementation and CryLNPlatformDoubleWordSupport which allow the integrator to choose between a memory optimized or a speed optimized implementation version.

2.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.



This module provides no EB-specific enhancements.

2.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

Synchronous job processing not supported

Description:

Synchronous job processing as specified by AUTOSAR is not supported by the Cry module.

Requirements:

CSM0031, CSM0035, CSM0505

▶ API functions do not return CSM_E_SMALL_BUFFER

Description:

The CSM specification only defines a reaction for the internal CSM state for the API functions for the following CRY primitive return values: CSM_E_OK, CSM_E_BUSY, CSM_E_NOT_OK. Therefore the CRY shall check if the provided buffer is large enough to hold the result of the computation. If the provided buffer is too small, CSM_E_NOT_OK shall be returned. See http://www.autosar.org/bugzilla/show_bug.cgi?id=71250 for more information. Affected APIs: Cry_CMACGenFinish, Cry_AES_DecryptUpdate, Cry AES EncryptUpdate.

Requirements:

CSM0663, CSM0700, CSM0662, CS SECURE CRY 0042, CS SECURE CRY 0038

2.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

The CCM algorithm does not support the streaming approach

Description:

The CCM algorithm provides support for Authenticated Encryption with Associated Data. As a consequence to the fact that this algorithm first authentificates the data and then encrypts it all input data must be provided with a single call of Csm <Service>Update.



In the case of decryption the plain text should be available only after the MAC is verified.

► The CCM algorithm supports only payloads smaller than 2^32 bytes

Description:

The maximum size of the payload data must be lower than 2^32 bytes.

The EdDSA algorithm does not support configurable context

Description:

Irtf-cfrg-eddsa-08 RFC specifies in Chapter 5.1. that Ed25519ph provides support for configurable context.

In the current implementation the context is always empty.



3. Cry user's guide

3.1. Overview

This user's guide describes the Cryptographic Primitives (Cry) module and explains the basic functionality of the Cry. The guide also describes the modules which are necessary to configure the Cry module. The Cry module reference provides further information on configuring the Cry itself.

This user's guide is intended for readers who have good knowledge of AUTOSAR and about the purpose of the Cry. The information provided here should help you to integrate the Cry in your AUTOSAR project.

- Section 3.2, "Background information" provides an overview of the basic functionality of the Cry.
- Section 3.3, "Configuring the Cry" provides information on related modules that are needed in order to configure the Cry.
- For configuration details for the Cry module itself, see the parameter descriptions provided in the Cry module reference Chapter 4, "Cry module references".

3.2. Background information

The Cry module provides several cryptographic functionalities. Cry acts as a lower interface to the Csm software module, which in turn provides access to the cryptographic functionalities to the user via services.

The Cry module is implemented according to the following specifications:

- ▶ AUTOSAR 4.0.3 Specification of Crypto Service Manager, v1.2.0
- Software Specification Cry, Conti VED Cyber Security, v1.0.0

The primitives of the Cry module are provided as asynchronous functions.

You need a Csm module to use the cryptographic functionality provided by the Cry module. You must create configurations in the Csm which link to the Cry configurations.

3.2.1. Mapping of Cryptographic Functionalities to Csm Services

The following is a list of the cryptographic primitives which are priovided by the Cry. It also contains the string which has to be entered into the field "Primitive name" in the Csm configuration created for the service.



Functionality	Csm Service	Cry Primitive Name
symmetrical key extraction	SymKeyExtract	KEY_SYM_Extract
AES-ECB encryption	SymBlockEncrypt	AES_Encrypt
AES-ECB decryption	SymBlockDecrypt	AES_Decrypt
CBC decryption with PKCS7 Padding	SymDecrypt	CbcPkcs7Decrypt
CBC encryption with PKCS7 Padding	SymEncrypt	CbcPkcs7Encrypt
CCM encryption	SymEncrypt	CCMEncrypt
CCM decryption	SymDecrypt	CCMDecrypt
CMAC/OMAC2 generation	MacGenerate	CMACGen
CMAC/OMAC2 verification	MacVerify	CMACVrfy
CV certificate key extraction	AsymPublicKeyExtract	CVCPublicKeyExtract
RSASSA-PSS signature verification	SignatureVerify	RsaSsaPssVerify
RSASSA-PKCS1-v1_5 signature verification	SignatureVerify	RsaSsaV15Verify
EdDSA signature generation	SignatureVerify	EdDSAGen
EdDSA signature verification	SignatureGenerate	EdDSAVrfy
SHA-1 Hash	Hash	SHA1
SHA2-224 Hash	Hash	SHA2
SHA2-256 Hash	Hash	SHA2
SHA2-384 Hash	Hash	SHA2
SHA2-512 Hash	Hash	SHA2
SHA3-224 Hash	Hash	SHA3
SHA3-256 Hash	Hash	SHA3
SHA3-384 Hash	Hash	SHA3
SHA3-512 Hash	Hash	SHA3
MD5 Hash	Hash	MD5
Pseudo random generation using the Self-Shrinking Generator	RandomGenerate	SSGGenerate
Seeding the pseudo random number generator (Self-Shrinking Generator)	RandomSeed	SSGSeed



Functionality	Csm Service	Cry Primitive Name
RSASSA-PKCS1-v1_5 signature generation	Csm_SignatureGenerate	RsaSsaV15Generate
RSA key extraction	AsymPublicKeyExtract	ExtractRsaPublicKey
Elliptic curve key extraction	AsymPublicKeyExtract	ExtractECPubKey

Table 3.1. Cry primitives

3.2.2. Using the time slicing feature for RSASSA-PSS and RSASSA-PKCS1-v1_5 signature verification

This feature is used to limit the maximum duration of a main function call and to conform to the real-time requirements of the system. It is the trade-off between the duration of one main function call on one other hand and the overall duration of a signature verification, on the other hand. You can activate the feature by enabling the parameters <code>CryRsaSsaPssVerifyUseTimeSlices</code> and <code>CryRsaSsaV15VerifyUseTimeSlices</code>. Furthermore, the number of the time slices should be configured by setting the parameters <code>CryRsaSsaPssVerifyUseTimeSlices</code> and <code>CryRsaSsaV15VerifyNumberOfTimeSlices</code>.

You can configure an optional callback function name for this feature, which returns the maximum number of iterations for the use during long-running calculations during signature a verification. The callback function can used to facilitate the evaluation of the correct number of time slices. This feature is activated by enabling CryRsaSsaPssVerifyUseCbk and CryRsaSsaV15VerifyUseCbk. The names of the callback functions are configured using the parameters CryRsaSsaPssTimeSlicesCbk and CryRsaSsaV15TimeSlicesCbk.

3.2.3. Using the restart feature

The restart feature allows to restart an already running calculation for signature verification and hash calculation. The precondition to use this service is the usage of a CSM which also supports the restart feature. When a $Csm_{service}$ -Start function is called when the service is not idle, and the $Csm_{service}$ -Start is called with the same cfgId than the currently running calculation, the CSM shall restart the service by calling the $Cry_{service}$ -Start.

The restart feature can be enabled with configuration parameter Cry<Primitive>SupportRestart. It is available for the SHA-256 and all SHA-3 hashes, RSA, RSASSA-PSS and RSASSA-PKCS1-v1_5 signature verification, as well as EdDSA signature generation and verification.



NOTE

Restart Feature and Callbacks



When you use the restart feature, please note that a service should only be restarted after the last expected callback notification was called. Otherwise, if $Cry_{service}$ start can interrupt $Cry_{service}$ mainFunction, callback notifications related to the canceled calculation might be called.

3.2.4. Using the immediate restart feature

The restart feature allows to restart an already running calculation regardless of the configuration ID or if other instances are running. The precondition to use this feature is the usage of a CSM which also supports the immediate restart feature. When a Csm_<Service>Start function is called the CSM shall restart the service by calling the Cry <Service>Start.

The immediate restart feature can be enabled with configuration parameter Cry<Primitive>ImmediateRestart. It is available for the following algorithms:

- MD5
- ► SHA-2
- ► SHA-3
- CMAC
- HMAC
- SSGSeed
- SSGGenerate
- AES encryption/decryption
- CBC PKCS7 encryption/decryption
- RSA and symmetric key extraction
- RSASSA-PSS and RSASSA-PKCS1-v1_5 signature verification
- EdDSA signature generation and verification



NOTE

Immediate restart feature on complex primitives



When you use the immediate restart feature on a primitive which needs a another primitive for part of processing both of them need to have the immediate restart feature enabled. For example, the RsaSsaV15 signature verification depends on the SHA primitive for it's internal calculations. In this case the SHA primitive and the corresponding CSM service need to have the Immediate Restart feature enabled.

3.2.5. AES implementation variants

The Cry module offers two implementation variants for the encryption and decryption parts of the AES algorithm. These variants allow you to achieve a balance between resource usage and processing speed according to your project's needs. The implementation variants are described below:

- ▶ RESOURCE_EFFICIENT this implementation variant is designed to offer a balance between the processing time and resource usage.
- ► FAST this implementation variant is based on pre-computed look-up tables and is designed to offer maximum processing speed by trading resource consumption.

<u>Table 3.2, "Cry AES encryption-only RAM resource usage"</u> provides approximate values for the RAM usage of the look-up tables for the implementation variants when only encryption is enabled.

Implementation variant (encryption)	RAM usage (bytes)
RESOURCE_EFFICIENT	1279
FAST	1576

Table 3.2. Cry AES encryption-only RAM resource usage

<u>Table 3.3, "Cry AES decryption-only RAM resource usage"</u> provides approximate values for the RAM usage of the look-up tables for the implementation variants when only decryption is enabled.

Implementation variant (decryption)	RAM usage (bytes)
RESOURCE_EFFICIENT	1279
FAST	1576

Table 3.3. Cry AES decryption-only RAM resource usage

<u>Table 3.4, "Cry AES encryption and decryption RAM resource usage"</u> provides approximate values for the RAM usage of the look-up tables for the implementation variants when both encryption and decryption are enabled.

Implementation variant (encryptic	RAM usage (bytes)	
RESOURCE_EFFICIENT	RESOURCE_EFFICIENT	1279



Implementation variant (encryption	on and decryption)	RAM usage (bytes)
RESOURCE_EFFICIENT	FAST	2343
FAST	RESOURCE_EFFICIENT	2343
FAST	FAST	2600

Table 3.4. Cry AES encryption and decryption RAM resource usage

3.2.6. Using the time slicing feature for SHA-1 and SHA-2 primitives

This feature is used for configuring the maximum number of SHA-1/SHA-2 algorithm iterations during the compression phase per Cry_SHA1MainFunction()/Cry_SHA2MainFunction() call in order to conform to the real-time requirements of the system. It is the trade-off between duration of one main function call and overall duration of a digest generation. The feature is activated by configuring the number of algorithm iterations per main function using the parameters CrySHA1IterationsPerMain or CrySHA2IterationsPerMain respectively. If zero is configured the number of internal iterations shall not be limited.

This feature is available only if SHA-1/SHA-2 interruptible code variant is used (CrySHAOneAndTwoImplementation = CRY_SHAONEANDTWO_INTERRUPTABLE).

3.2.7. Using the time slicing feature for EdDSA signature generation and verification primitives

This feature is used for configuring the maximum number of EdDSA signature generation/verification algorithm iterations during long number operations or point operations per <code>Cry_EdDSAGenMainFunction()/Cry_-EdDSAVrfyMainFunction()</code> call in order to conform to the real-time requirements of the system. It is the trade-off between duration of one main function call and overall duration of a signature generation/verification. The feature is activated by configuring the number of algorithm iterations per main function using the parameters <code>CryEdDSAGenNumberOfTimeSlices</code> or <code>CryEdDSAVrfyNumberOfTimeSlices</code> respectively. If zero is configured, the number of internal iterations shall not be limited. If one is configured, the slicing mechanism is disabled.

3.2.8. Long number library implementation variants

The Cry module implements a customizable, long number library, which is used for all public-key algorithms, for example RSA signature generation/verification, EdDSA signature generation/verification. The long number



library can be tailored to the project-specific resource consumption and performance needs by setting the values of the following three configuration parameters:

- CryLNAlgorithmImplementation
 - CRY LN MEMORY OPTIMIZED

This implementation variant uses the least amount of RAM during the processing of long number operations. The stack usage during of this implementation variant is negligible.

This variant is intented for the use on platforms that have a limited amount of RAM memory available for cryptographic algorithms.

CRY LN SPEED OPTIMIZED

This implementation variant is designed to achieve the maximum processing speed at the cost of requiring an increased stack usage for storing the intermediate calculation results. An estimate value in bytes of the least amount of required stack-allocated RAM can be calculated by multiplying the byte length of the largest private/public key by 4.

As an example, a 1024 bit key, requires a stack usage of at least (1024 bits / 8) * 4 = 512 bytes for storing the intermediate results only.

This variant is intented for the use on platforms that have a larger amount of available RAM for cryptographic algorithms.

CryInterruptableLN

This configuration parameter is available only if CRY_LN_MEMORY_OPTIMIZED algorithm implementation variant is used.

true

The Cry module splits the long number operations into several sub-functions, which are executed asynchronously, during Cry main function calls.

This implementation variant is intented for the use in projects which require a low CPU usage during long number operations.

false

The Cry module performs long number operations synchronously, in a single function call.

This implementation variant is intented for the use in projects which require a lower total processing time of the algorithm and can afford a high CPU usage during long number operations.

CryLNPlatformDoubleWordSupport

This configuration parameter is available only if CRY_LN_SPEED_OPTIMIZED algorithm implementation variant is used.



The Cry module stores long numbers in arrays of Cry_LNWordType elements, e.g. used to represent the value of the modulo from public keys. These elements have the length equal to the target platform's word length. During calculations involving long numbers, the partial results can exceed the precision of the Cry_LNWordType. The value of the CryLNPlatformDoubleWordSupport configuration parameter defines the handling of operations performed on Cry_LNWordType elements.

true

The Cry module defines and uses variables of type Cry_LNDoubleWordType, which are twice as large as Cry_LNWordType. For example, if the target platform has a 32 bit CPU, Cry_LNWordType is represented using a 32 bit unsigned integer while Cry_DoubleLNWordType is represented using a 64 bit unsigned integer.

The target platform and compiler need to offer support for data types that have twice the length of the platform's word length.

This implementation variant is intented for the use in projects which require the shortest processing time for cryptographic algorithms.

false

The Cry module splits operations on Cry_LNWordType elements into operations on the corresponding lower/upper parts of the word.

This implementation variant is intented for the use on targets which do not offer support for data types larger than the platform's word length.

Figure 3.1, "Cry long number library implementation variants" summarizes the implementation variants of the long number library and shows the increase of processing speed and RAM usage according to the value of the three configuration parameters previously described.






Figure 3.1. Cry long number library implementation variants

3.3. Configuring the Cry

The following section explains how to configure a signature verification service using the RSASSA-PSS algorithm with a SHA-256.

- ▶ Open the Cry module configuration.
- Switch to the tab of the primitive SHA2 to configure.
- Click the **Add element** button † to create a primitive configuration.






Figure 3.2. Cry SHA tab

- ► Open the Csm module configuration.
- Switch to the tab of the service corresponding to the Cry primitive.
- Click the **Add element** button * to create a service configuration.
- ▶ The value of the InitConfiguration must be the name of the configuration created in the Cry.
- ► The value of the PrimitiveName must be the name of the corresponding Cry primitive.
- The value of the Callback is the name of the function, which is invoked by the Csm, when the service has finished a calculation step.




Figure 3.3. Csm Hash tab

- Open the Cry module configuration again.
- Switch to the tab of primitive RsaSsaPssVerify to configure.



- Now, the Hash service configuration created in the Csm can be referenced.
- For some primitives a key length can be configured.
- Click the **Add element** button * to create a primitive configuration.




Figure 3.4. Cry RsaSsaPssVerify tab

- ▶ Open the Csm module configuration again.
- Switch to the tab of the service corresponding to the Cry primitive.
- Click the **Add element** button * to create a service configuration.
- ► The value of the InitConfiguration must be the name of the configuration created in the Cry.
- ► The value of the PrimitiveName must be the name of the corresponding Cry primitive.
- The value of the Callback is the name of the function, which is invoked by the Csm, when the service has finished a calculation step.




Figure 3.5. Csm Signature Verify tab

- ► Switch to the Csm General tab.
- In the respective service container a key length can be configured.

Configure the length of the key large enough to hold the key configured for the corresponding Cry primitive.






Figure 3.6. Csm General tab

To verify the signature of some data, the user application needs to implement the following call sequence:

- First call Csm_SignatureVerifyStart() and pass the Csm Signature Verify configuration and a key to the function.
- While the Csm_MainFunction() is schedulded cyclically wait for the application's callback to be invoked.
- Then call Csm_SignatureVerifyUpdate() and pass the Csm Signature Verify configuration and the signed data to the function.
- While the Csm MainFunction() is schedulded cyclically wait for the application's callback to be invoked.
- The previous two steps might be repeated if the data is passed to the services in several chunks.
- Then call Csm_SignatureVerifyFinish() and pass the Csm Signature Verify configuration, the signature and a buffer for the verification result to the function.
- While the Csm MainFunction() is schedulded cyclically wait for the application's callback to be invoked.
- Now, the provided buffer holds the verification result.

For simplicity, the given sequence does not take other return values than CSM_E_OK into account. The application must be able to react to other values returned by the APIs or passed to the Callback function



4. Cry module references

4.1. Configuration parameters

Containers included			
Container name	Multiplicity	Description	
CommonPublishedInfor-	11	Label: Common Published Information	
<u>mation</u>		Common container, aggregated by all modules. It contains published information about vendor and versions.	
CryGeneral	11	The general configuration	
CrySHA1	11	The configurations of SHA1	
CrySHA2	11	The configurations of SHA2	
CrySHA3	11	The configurations of SHA3	
<u>CryRsaSsaPssVerify</u>	11	The configurations of Signature RsaSsa PSS Verify	
CryRsaSsaV15Generate	11	The configurations of RsaSsa V15(PKCS1) Signature Generate	
CryRsaSsaV15Verify	11	The configurations of Signature RsaSsa V15(PKCS1) Verify	
CryEdDSAVrfy	11	The configurations of EdDSA verification with Ed25519ph curve	
CryEdDSAGen	11	The configurations of ECDSA generation with Ed25519ph curve	
CryMD5	11	The configurations of MD5	
CryAESEncrypt	11	The configurations of AES encrypt	
CryAESDecrypt	11	The configurations of AES decrypt	
CryCMACVrfy	11	The configurations of CMAC	
CryCMACGen	11	The configurations of CMAC	
CrySSGGenerate	11	The configurations of the self shrinking generator	
CrySSGSeed	11	The configurations of the self shrinking generator	
CrySSGState	11	The configurations of the self shrinking generator	
CryKeyExtractSym	11	The configurations of symmmetrical key extract	
CryCVCPublicKeyEx-	11	Label: CVCPublicKeyExtract configurations	
tract		The configurations of the CVC public key extract	



Containers included		
CryCbcPkcs7Encrypt	11	The configurations of CBC encryption with PKCS#7 padding
CryCbcPkcs7Decrypt	11	The configurations of CBC decryption with PKCS#7 padding
CryCcmEncrypt	11	The configurations of Ccm encryption
<u>CryCcmDecrypt</u>	11	The configurations of Ccm decryption
<u>CryHMACVrfy</u>	11	The configurations of HMAC Verify
CryHMACGen	11	The configurations of HMAC Generate
CryExtractRsaPublicKey	11	Label: ExtractRsaPublicKey configurations The configurations of RSA public key extract
CryCrc	11	The configurations of cyclic redundancy check
CryExtractECPubKey	11	Label: ExtractECPubKey configurations The configurations of public elliptic key extract
PublishedInformation	11	Label: EB Published Information Additional published parameters not covered by CommonPublishedInformation container.

Parameters included	
Parameter name	Multiplicity
IMPLEMEN-	11
TATION_CON-	
FIG_VARIANT	

Parameter Name	IMPLEMENTATION_CONFIG_VARIANT
Label	Config Variant
Description	Select the configuration variant. Currently only PreCompile is supported.
Multiplicity	11
Туре	ENUMERATION
Default value	VariantPreCompile
Range	VariantPreCompile

4.1.1. CommonPublishedInformation

Parameters included	
Parameter name	Multiplicity



Parameters included	
<u>ArMajorVersion</u>	11
ArMinorVersion	11
<u>ArPatchVersion</u>	11
<u>SwMajorVersion</u>	11
<u>SwMinorVersion</u>	11
<u>SwPatchVersion</u>	11
ModuleId	11
Vendorld	11
Release	11

Parameter Name	ArMajorVersion
Label	AUTOSAR Major Version
Description	Major version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	1
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArMinorVersion
Label	AUTOSAR Minor Version
Description	Minor version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	2
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArPatchVersion
Label	AUTOSAR Patch Version
•	Patch level version number of AUTOSAR specification on which the appropriate implementation is based on.



Multiplicity	11
Туре	INTEGER_LABEL
Default value	0
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMajorVersion
Label	Software Major Version
Description	Major version number of the vendor specific implementation of the module.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	2
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwMinorVersion
Label	Software Minor Version
Description	Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	6
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	SwPatchVersion
Label	Software Patch Version
Description	Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific.
Multiplicity	11
Туре	INTEGER_LABEL
Default value	2
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH



Parameter Name	Moduleld	
Label	Numeric Module ID	
Description	Module ID of this module from Module List	
Multiplicity	11	
Туре	INTEGER_LABEL	
Default value	0	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	Vendorld		
Label	Vendor ID		
Description	Vendor ID of the dedicated implementation of this module according to the AU- TOSAR vendor list		
Multiplicity	11		
Туре	INTEGER_LABEL		
Default value	1		
Configuration class	PublishedInformation:		
Origin	Elektrobit Automotive GmbH		

Parameter Name	Release	
Label	Release Information	
Multiplicity	11	
Туре	STRING_LABEL	
Default value		
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

4.1.2. CryGeneral

Parameters included	
Parameter name	Multiplicity
CryLNAlgorithmImple- mentation	11



Parameters included	
CryInterruptableLN	11
CryLNPlatformDouble- WordSupport	11
CrySHAOneAndTwolm-plementation	11

Parameter Name	CryLNAlgorithmImplementation		
Label	LN algorithm implementation variant		
Description	Selects the implementation variant of long number library.		
	Range:		
	CRY_LN_MEMORY_OPTIMIZED		
	This implementation variant offers a trade-off between RAM usage and processing time.		
	CRY_LN_SPEED_OPTIMIZED		
	This implementation variant allocates RAM on the stack during the execution of long number functions to achieve a shorter processing time.		
Multiplicity	11		
Туре	ENUMERATION		
Default value	CRY_LN_MEMORY_OPTIMIZED		
Range	CRY_LN_MEMORY_OPTIMIZED		
	CRY_LN_SPEED_OPTIMIZED		

Parameter Name	CryInterruptableLN		
Label	Interruptable LN operations		
Description	If disabled, the Cry module will process all operations related to long numbers in a single main function call. This implementation variant trades CPU usage per main function call for achieving a smaller total processing time of the algorithm. If enabled, the Cry module splits all operations related to long numbers across several main function calls. This implementation variant offers a trade-off between the total processing time of the algorithm and CPU usage per main function call.		
	Note: this configuration parameter is only available if the "memory optimized" long number library implementation variant is used (CryLNAlgorithmImplementation = CRY_LN_MEMORY_OPTIMIZED).		



Multiplicity	11
Туре	BOOLEAN
Default value	true

Parameter Name	CryLNPlatformDoubleWordSupport		
Label	Support for double words		
Description	Switch to enable/disable support for double words (words having the length equal to double the platform size).		
	FALSE: The Cry module uses single words for calculating partial results during long number operations by splitting the operands in lower/upper parts.		
	➤ TRUE: The Cry module uses double words for calculating partial results during long number operations.		
	Note: this configuration parameter is only available if the "speed optimized" long number library implementation variant is used (CryLNAlgorithmImplementation = CRY LN SPEED OPTIMIZED).		
Multiplicity	11		
Туре	BOOLEAN		
Default value	false		

Parameter Name	CrySHAOneAndTwoImplementation		
Label	SHA-1/SHA-2 implementation variant		
Description	Selects the implementation variant of the SHA-1 and SHA-2 hashing algorithms.		
	Range:		
	CRY_SHAONEANDTWO_INTERRUPTABLE		
	The Cry module splits SHA-1/SHA-2 hash computations across several main function calls.		
	This implementation variant offers a trade-off between the total processing time of the algorithm and CPU usage per main function call.		
	CRY_SHAONEANDTWO_FAST		
	The Cry module performs as many SHA-1/SHA-2 hash computations as possible per main function call.		
	This implementation variant trades CPU usage per main function call for achieving a smaller total processing time of the algorithm.		



Multiplicity	1	
Туре	JMERATION	
Default value	Y_SHAONEANDTWO_INTERRUPTABLE	
Range	CRY_SHAONEANDTWO_INTERRUPTABLE	
	CRY_SHAONEANDTWO_FAST	

4.1.3. CrySHA1

Containers included		
Container name	Multiplicity	Description
CrySHA1Config	032	

Parameters included	
Parameter name	Multiplicity
CrySHA1ImmediateResta	aftEnabled

Parameter Name	CrySHA1ImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.4. CrySHA1Config

Parameters included	
Parameter name	Multiplicity
CrySHA1Type	11
CrySHA1IterationsPerMain1	

Parameter Name	CrySHA1Type
----------------	-------------



Label	Prime
Description	Prime used
Multiplicity	11
Туре	ENUMERATION
Default value	CRY_SHA_1
Range	CRY_SHA_1

Parameter Name	CrySHA1IterationsPerMain
Label	Number of iterations per MainFunction()
Description	Defines the number of SHA1 algoritm iterations per Cry_SHA1MainFunction() call during the compression phase. This allows to fine tune the execution time per main function call and thus the number of calls. The value 0 means that the number of iterations shall not be limited. Note: This configuration parameter is available only if SHA-1/SHA-2 interruptable code variant is used (CrySHAOneAndTwoImplementation = CRY_SHAONE-ANDTWO_INTERRUPTABLE)
Multiplicity	11
Туре	INTEGER
Default value	1
Range	<=65535
	>=0
Configuration class	PreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

4.1.5. CrySHA2

Containers included		
Container name	Multiplicity	Description
CrySHA2Config	032	

Parameters included	
Parameter name	Multiplicity
CrySHA2ImmediateResta	aftEnabled



Parameter Name	CrySHA2ImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.6. CrySHA2Config

Parameters included	
Parameter name	Multiplicity
CrySHA2Type	11
CrySHA2IterationsPerMa	ift1
CrySHA2SupportRestart	11

Parameter Name	CrySHA2Type
Label	Prime
Description	Prime used
Multiplicity	11
Туре	ENUMERATION
Default value	CRY_SHA_256
Range	CRY_SHA_224
	CRY_SHA_256
	CRY_SHA_384
	CRY_SHA_512

Parameter Name	CrySHA2IterationsPerMain
Label	Number of iterations per MainFunction()
·	Defines the number of SHA-2 algoritm iterations per Cry_SHA2MainFunction() call during the compression phase. This allows to fine tune the execution time per main function call and thus the number of calls. The value 0 means that the number of iterations shall not be limited.



	Note: This configuration parameter is available only if SHA-1/SHA-2 interruptable code variant is used (CrySHAOneAndTwoImplementation = CRY_SHAONE-ANDTWO_INTERRUPTABLE)	
Multiplicity	11	
Туре	INTEGER	
Default value	1	
Range	<=65535	
	>=0	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	CrySHA2SupportRestart	
Label	Enable the cancelation of ongoing requests	
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_SHA2Start can interrupt Cry_SHA2MainFunction, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmHashEnableRestart in the CSM has the same value as this parameter.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

4.1.7. CrySHA3

Containers included		
Container name	Multiplicity	Description
CrySHA3Config	032	

Parameters included	
Parameter name	Multiplicity
CrySHA3ImmediateResta	aftEnabled

Parameter Name	CrySHA3ImmediateRestartEnabled
----------------	--------------------------------



Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.8. CrySHA3Config

Parameters included	
Parameter name	Multiplicity
CrySHA3Type	11
CrySHA3SupportRestart	11

Parameter Name	CrySHA3Type
Label	Prime
Description	Prime used
Multiplicity	11
Туре	ENUMERATION
Default value	CRY_SHA3_256
Range	CRY_SHA3_224
	CRY_SHA3_256
	CRY_SHA3_384
	CRY_SHA3_512

Parameter Name	CrySHA3SupportRestart
Label	Enable the cancelation of ongoing requests
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_SHA3Start can interrupt Cry_SHA3MainFunction, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmHashEnableRestart in the CSM has the same value as this parameter.
Multiplicity	11



Туре	BOOLEAN
Default value	false

4.1.9. CryRsaSsaPssVerify

Containers included		
Container name	Multiplicity	Description
CryRsaSsaPssVerify-	032	
Config		

Parameters included	
Parameter name	Multiplicity
CryRsaSsaPssVerifyIm- mediateRestartEnabled	11
CryRsaSsaPssVeri- fyUseTimeSlices	11
CryRsaSsaPssVeri- fyNumberOfTimeSlices	11
CryRsaSsaPssVeri- fyUseCbk	11
CryRsaSs- aPssTimeSlicesCbk	11

Parameter Name	CryRsaSsaPssVerifyImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaPssVerifyUseTimeSlices
Label	Use time slicing for RSASSA-PSS signature verification.
•	If enabled, the signature verification is split into time slices. Specifically, the modular exponentiation performed during signature verification is split into several steps.



Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaPssVerifyNumberOfTimeSlices
Label	Number of RsaSsaPss time slices
Description	The maximum number of steps of the modular exponentiation performed in one Cry main function call during the RSASSA-PSS signature verification. NOTE: This configuration parameter is disabled, when CryRsaSsaPssVerifyUseCbk configuration parameter is enabled.
Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=1 <=4294967295

Parameter Name	CryRsaSsaPssVerifyUseCbk
Label	Use configured callback function which returns maximum number of time slices
Description	If enabled, the configuration parameter CryRsaSsaPssTimeSlicesCbk is enabled, to configure the name of a callback which returns the maximum number of time slices to be used during RSASSA-PSS signature verification.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaPssTimeSlicesCbk	
Label	CryRsaSsaPssTimeSlicesCbk	
Description	Optional configuration parameter which can be used to configure the name of the callback which returns the maximum number of time slices to be used during RSASSA-PSS signature verification. NOTE: This configuration parameter is enabled, only when CryRsaSsaPssVerifyUseCbk configuration parameter is enabled.	
Multiplicity	11	
Туре	FUNCTION-NAME	
Configuration class	PreCompile:	VariantPreCompile



4.1.10. CryRsaSsaPssVerifyConfig

Parameters included	
Parameter name	Multiplicity
CryRsaSsaPssVerify- HashCfgRef	11
CryRsaSsaPssVeri- fyKeyLength	11
CryRsaSsaPssVeri- fySaltLength	11
CryRsaSsaPssVerifyB64	<u> Elnabded</u>
CryRsaSsaPssVeri- fyUseBarrett	11
CryRsaSsaPssVeri- fySupportRestart	11

Parameter Name	CryRsaSsaPssVerifyHashCfgRef
Label	Hash configuration
Description	Hash configuration used
Multiplicity	11
Туре	REFERENCE

Parameter Name	CryRsaSsaPssVerifyKeyLength
Label	Key Length
Description	Key Length in bytes used in the signature verification
Multiplicity	11
Туре	INTEGER
Default value	384

Parameter Name	CryRsaSsaPssVerifySaltLength
Label	Salt Length
Description	Salt Length in bytes used in the signature verification
Multiplicity	11
Туре	INTEGER
Default value	384



Range	>=0
	<=4294967295

Parameter Name	CryRsaSsaPssVerifyB64Encoded
Label	Base64 Encoded
Description	The signature is Base64-encoded.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaPssVerifyUseBarrett
Label	Barrett reduction
Description	If enabled, the Barret reduction is used to verify the signature.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaPssVerifySupportRestart
Label	Enable the cancelation of ongoing requests
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_RsaSsaPssVerifyStart can interrupt Cry_RsaSsaPssVerifyMain-Function, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmSignatureVerifyEnableRestart in the CSM has the same value as this parameter.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.11. CryRsaSsaV15Generate

Containers included		
Container name	Multiplicity	Description
CryRsaSsaV15Generate	<u> (Co.1312g</u>	



4.1.12. CryRsaSsaV15GenerateConfig

Parameters included	
Parameter name	Multiplicity
CryRsaSsaV15Generate	Ha≾ hCfgRef
CryRsaSsaV15Generate	deyL ength

Parameter Name	CryRsaSsaV15GenerateHashCfgRef
Label	Hash configuration
Description	Hash configuration used
Multiplicity	11
Туре	REFERENCE

Parameter Name	CryRsaSsaV15GenerateKeyLength
Label	Key Length
Description	Key length in bytes used in the signature generation
Multiplicity	11
Туре	INTEGER
Default value	384

4.1.13. CryRsaSsaV15Verify

Containers included		
Container name	Multiplicity	Description
CryRsaSsaV15VerifyCon	© .32	

Parameters included	
Parameter name	Multiplicity
CryRsaSsaV15VerifyImm	ddiateRestartEnabled
CryRsaSsaV15VerifyUse	7fim1eSlices
CryRsaSsaV15VerifyNun	nbetOfTimeSlices
CryRsaSsaV15VerifyUse	Obli
CryRsaSsaV15TimeSlice	SCI



Parameter Name	CryRsaSsaV15VerifyImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaV15VerifyUseTimeSlices
Label	Use time slices for RSASSA-PKCS1-v1_5 signature verification.
Description	If enabled, the signature verification is split into time slices. Specifically, the modular exponentiation performed during RSASSA-PKCS1-v1_5 signature verification is split into several steps.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaV15VerifyNumberOfTimeSlices
Label	Number of RsaSsaV15 time slices
Description	The maximum number of steps of the modular exponentiation performed in one Cry main function call during the RSASSA-PKCS1-v1_5 signature verification. NOTE: This configuration parameter is disabled, when CryRsaSsaV15VerifyUseCbk configuration parameter is enabled.
Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=1 <=4294967295

Parameter Name	CryRsaSsaV15VerifyUseCbk
Label	Use configured callback function which returns maximum number of time slices.
-	If enabled, the configuration parameter CryRsaSsaV15TimeSlicesCbk is enabled, to configure the name of a callback which returns the maximum number of time slices to be used during RSASSA-PKCS1-v1_5 signature verification.
Multiplicity	11



Туре	BOOLEAN
Default value	false

Parameter Name	CryRsaSsaV15TimeSlicesCbk	
Label	CryRsaSsaV15TimeSlicesCbk	
Description	Optional configuration parameter which can be used to configure the name of the callback which returns the maximum number of time slices to be used during RSASSA-PKCS1-v1_5 signature verification. NOTE: This configuration parameter is enabled, only when CryRsaSsaV15VerifyUseCbk configuration parameter is enabled.	
Multiplicity	11	
Туре	FUNCTION-NAME	
Configuration class	PreCompile:	VariantPreCompile

4.1.14. CryRsaSsaV15VerifyConfig

Parameters included	
Parameter name	Multiplicity
CryRsaSsaV15VerifyHas	rtCfgRef
CryRsaSsaV15VerifyKey	Lienigth
CryRsaSsaV15VerifyB64	<u>Andoded</u>
CryRsaSsaV15VerifyUse	Bartett
CryRsaSsaV15VerifySup	plor 1 Restart

Parameter Name	CryRsaSsaV15VerifyHashCfgRef	
Label	Hash configuration	
Description	Hash configuration used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryRsaSsaV15VerifyKeyLength	
Label	Key Length	
Description	Key Length in bytes used in the signature verification	
Multiplicity	11	



Туре	INTEGER
Default value	384

Parameter Name	CryRsaSsaV15VerifyB64Encoded	
Label	Base64 Encoded	
Description	he signature is Base64-encoded.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

Parameter Name	CryRsaSsaV15VerifyUseBarrett	
Label	Barrett reduction	
Description	If enabled, the Barret reduction is used to verify the signature.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

Parameter Name	CryRsaSsaV15VerifySupportRestart	
Label	Enable the cancelation of ongoing requests	
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_RsaSsaV15VerifyStart can interrupt Cry RsaSsaV15VerifyMainFunction, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmSignatureVerifyEn-ableRestart in the CSM has the same value as this parameter.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

4.1.15. CryEdDSAVrfy

Containers included		
Container name	Multiplicity	Description



Containers included		
CryEdDSAVrfyConfig	032	

Parameters included	
Parameter name	Multiplicity
CryEdDSAVrfyImmedi-	11
<u>ateRestartEnabled</u>	

Parameter Name	CryEdDSAVrfyImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.16. CryEdDSAVrfyConfig

Parameters included	
Parameter name	Multiplicity
CryEdDSAVrfyHashCf- gRef	11
CryEdDSAVrfySupport- Restart	11
CryEdDSAVrfyNum- berOfTimeSlices	11

Parameter Name	CryEdDSAVrfyHashCfgRef
Label	Hash configuration
Description	Hash configuration used
	A reference to SHA-512 is mandatory.
Multiplicity	11
Туре	REFERENCE

Parameter Name	CryEdDSAVrfySupportRestart
----------------	----------------------------



Label	Enable the cancelation of ongoing requests
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_EdDSAVrfyStart can interrupt Cry_EdDSAVrfyMainFunction, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmHashEnableRestart in the CSM has the same value as this parameter.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryEdDSAVrfyNumberOfTimeSlices
Label	Number of time slices for EdDSA signature verification
Description	The maximum number of steps of the point operations performed in one Cry main function call during the EdDSA signature verification.
	Note: The value of this configuration parameter allows the integrator of the Cry module to achieve a balance between the total processing time of the algorithm and the CPU usage per main function call.
	0: The Cry module does not limit the number of time slices per Cry_Ed- DSAVrfyMainFunction() function call.
	1: The Cry module processes a single time slice (i.e. the slicing mechanism is disabled) per Cry_EdDSAVrfyMainFunction() function call.
	> 1: The Cry module processes the configured number of slices Cry_Ed- DSAVrfyMainFunction() function call.
Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=0
	<=65535

4.1.17. CryEdDSAGen

Containers included		
Container name	Multiplicity	Description



Containers included		
CryEdDSAGenConfig	032	

Parameters included	
Parameter name	Multiplicity
CryEdDSAGenImmediateRestartEnabled	11

Parameter Name	CryEdDSAGenImmediateRestartEnabled	
Label	Enable the cancelation of ongoing requests	
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

4.1.18. CryEdDSAGenConfig

Parameters included	
Parameter name	Multiplicity
CryEdDSAGenHashCf- gRef	11
CryEdDSAGenSupport- Restart	11
CryEdDSAGenNum- berOfTimeSlices	11

Parameter Name	CryEdDSAGenHashCfgRef
Label	Hash configuration
Description	Hash configuration used
	A reference to SHA-512 is mandatory.
Multiplicity	11
Туре	REFERENCE

Parameter Name CryEdDSAGenSupportRestart	
--	--



Label	Enable the cancelation of ongoing requests
Description	If enabled, the restart feature of the service is enabled. Important: If Cry_EdDSAGenStart can interrupt Cry_EdDSAGenMainFunction, a service should only be restarted after the last expected callback notification has been called. Otherwise, callback notifications related to the canceled calculation might be called. Please ensure that the corresponding parameter CsmHashEnableRestart in the CSM has the same value as this parameter.
Multiplicity	11
Туре	BOOLEAN
Default value	false

Parameter Name	CryEdDSAGenNumberOfTimeSlices	
Label	Number of time slices for EdDSA signature generation	
Description	The maximum number of steps of the point operations performed in one Cry main function call during the EdDSA signature generation.	
	Note: The value of this configuration parameter allows the integrator of the Cry module to achieve a balance between the total processing time of the algorithm and the CPU usage per main function call.	
	0: The Cry module does not limit the number of time slices per Cry_EdDSA-GenMainFunction() function call.	
	1: The Cry module processes a single time slice (i.e. the slicing mechanism is disabled) per Cry_EdDSAGenMainFunction() function call.	
	> 1: The Cry module processes the configured number of slices Cry_Ed- DSAGenMainFunction() function call.	
Multiplicity	11	
Туре	INTEGER	
Default value	1	
Range	>=0	
	<=65535	

4.1.19. CryMD5

Containers included		
Container name	Multiplicity	Description



Containers included		
CryMD5Config	032	

Parameters included	
Parameter name	Multiplicity
CryMD5ImmediateResta	ttEnlabled

Parameter Name	CryMD5ImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.20. CryMD5Config

4.1.21. CryAESEncrypt

Containers included	_	
Container name	Multiplicity	Description
CryAESEncryptConfig	032	

Parameters included	
Parameter name	Multiplicity
CryAESEncryptImple- mentation	01

Parameter Name	CryAESEncryptImplementation	
Label	Cry AES Encrypt Implementation	
Description	Selects the implementation variant of the AES encryption algorithm.	



	Range:		
	CRY_AES_ENCRYPT_RESOURCE_EFFICIENT		
	This implementation variant offers a ber of CPU instructions.	trade-off between RAM usage the num-	
	Requires 1279 bytes for look-up tab and decryption.	les, which are shared between encryption	
	CRY_AES_ENCRYPT_FAST		
	This implementation variant trades the number of CPU instructions for RAM usage.		
	Requires 1064 bytes for look-up tables only for the encryption part and an ad-		
	ditional 512 bytes for tables shared between encryption and decryption.		
Multiplicity	01		
Туре	ENUMERATION		
Default value	CRY_AES_ENCRYPT_RESOURCE_EFFICIENT		
Range	CRY_AES_ENCRYPT_RESOURCE_EFFICIENT		
	CRY_AES_ENCRYPT_FAST		
Configuration class	VariantPreCompile:	VariantPreCompile	

4.1.22. CryAESEncryptConfig

Parameters included	
Parameter name	Multiplicity
CryAESEncryptType	11

Parameter Name	CryAESEncryptType	
Label	Key Length	
Description	Key Length used	
Multiplicity	I1	
Туре	ENUMERATION	
Default value	CRY_AES_KEY_256	
Range	CRY_AES_KEY_128	
	CRY_AES_KEY_192	



CRY_AES_KEY_256

4.1.23. CryAESDecrypt

Containers included		
Container name	Multiplicity	Description
CryAESDecryptConfig	032	

Parameters included	
Parameter name	Multiplicity
CryAESDecryptImple-	01
<u>mentation</u>	

Parameter Name	CryAESDecryptImplementation	
Label	Cry AES Decrypt Implementation	
Description	Selects the implementation variant of the AES decryption algorithm.	
	Range:	
	CRY_AES_DECRYPT_RESOURCE_EFFICIENT	
	This implementation variant offers a trade-off between RAM usage the number of CPU instructions.	
	Requires 1279 bytes for look-up tables, which are shared between decryption and encryption.	
	CRY_AES_DECRYPT_FAST	
	This implementation variant trades the number of CPU instructions for RAM usage.	
	Requires 1064 bytes for look-up tables only for the decryption part and an additional 512 bytes for tables shared between decryption and encryption.	
Multiplicity	01	
Туре	ENUMERATION	
Default value	CRY_AES_DECRYPT_RESOURCE_EFFICIENT	
Range	CRY_AES_DECRYPT_RESOURCE_EFFICIENT	
	CRY_AES_DECRYPT_FAST	



Configuration class	VariantPreCompile:	VariantPreCompile	
---------------------	--------------------	-------------------	--

4.1.24. CryAESDecryptConfig

Parameters included	
Parameter name	Multiplicity
CryAESDecryptType	11

Parameter Name	CryAESDecryptType	
Label	Key Length	
Description	Key Length used	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CRY_AES_KEY_256	
Range	CRY_AES_KEY_128	
	CRY_AES_KEY_192	
	CRY_AES_KEY_256	

4.1.25. CryCMACVrfy

Containers included		
Container name	Multiplicity	Description
CryCMACVrfyConfig	032	

4.1.26. CryCMACVrfyConfig

Parameters included		
Multiplicity		
11		
11		



Parameter Name	CryCMACVrfySymBlockEncryptCfgRef	
Label	SymBlockEncrypt configuration	
Description	SymBlockEncrypt configuration used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryCMACVrfyType	
Label	MAC Type	
Description	Type of One-Key CBC MAC:	
	CMAC which is equivalent with OMAC1. OMAC2	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CMAC	
Range	CMAC	
	OMAC2	

4.1.27. CryCMACGen

Containers included		
Container name	Multiplicity	Description
CryCMACGenConfig	032	

4.1.28. CryCMACGenConfig

Parameters included	
Parameter name	Multiplicity
CryCMACGenSym- BlockEncryptCfgRef	11
CryCMACGenType	11

Parameter Name CryCMACG	enSymBlockEncryptCfgRef
-------------------------	-------------------------



Label	SymBlockEncrypt configuration	
Description	SymBlockEncrypt configuration used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryCMACGenType
Label	MAC Type
Description	Type of One-Key CBC MAC: CMAC which is equivalent with OMAC1.
	OMAC2
Multiplicity	11
Туре	ENUMERATION
Default value	CMAC
Range	CMAC
	OMAC2

4.1.29. CrySSGGenerate

Containers included		
Container name	Multiplicity	Description
CrySSGGenerateConfig	032	

Parameters included	
Parameter name	Multiplicity
CrySSGGenerateImme-	11
diateRestartEnabled	

Parameter Name	CrySSGGenerateImmediateRestartEnabled	
Label	Enable the cancelation of ongoing requests	
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.	
Multiplicity	11	
Туре	BOOLEAN	



Default value	false
---------------	-------

4.1.30. CrySSGGenerateConfig

Parameters included	
Parameter name	Multiplicity
CrySSGRandomS- tateRef	11

Parameter Name	CrySSGRandomStateRef
Label	Random state
Description	Random state used
Multiplicity	11
Туре	REFERENCE

4.1.31. CrySSGSeed

Containers included		
Container name	Multiplicity	Description
CrySSGSeedConfig	032	

Parameters included	
Parameter name	Multiplicity
CrySSGSeedImmediateRestartEnabled	11

Parameter Name	CrySSGSeedImmediateRestartEnabled	
Label	Enable the cancelation of ongoing requests	
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	



4.1.32. CrySSGSeedConfig

Parameters included	
Parameter name	Multiplicity
CrySSGRandomS-	11
tateRef	

Parameter Name	CrySSGRandomStateRef
Label	Random state
Description	Random state used
Multiplicity	11
Туре	REFERENCE

4.1.33. CrySSGState

Containers included		
Container name	Multiplicity	Description
CrySSGStateConfig	032	

4.1.34. CrySSGStateConfig

Parameters included	
Parameter name	Multiplicity
<u>CrySSGStateSize</u>	11

Parameter Name	CrySSGStateSize
Label	Random state size
Description	Random state size in bytes
Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=1
	<=4294967295



4.1.35. CryKeyExtractSym

Containers included		
Container name	Multiplicity	Description
CryKeyExtractSymCon-	08	
fig		

Parameters included	
Parameter name	Multiplicity
CryKeyExtractSymIm- mediateRestartEnabled	11

Parameter Name	CryKeyExtractSymImmediateRestartEnabled	
Label	Enable the cancelation of ongoing requests	
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

4.1.36. CryKeyExtractSymConfig

Parameters included	
Parameter name	Multiplicity
<u>CryKeyExtractSymType</u>	11

Parameter Name	CryKeyExtractSymType
Label	Key Length
Description	Key Length used
Multiplicity	11
Туре	ENUMERATION
Default value	CRY_KEY_SYM_256
Range	CRY_KEY_SYM_128
	CRY_KEY_SYM_192



CRY_KEY_SYM_256
OKT_KET_OTM_230

4.1.37. CryCVCPublicKeyExtract

Containers included		
Container name	Multiplicity	Description
CryCVCPublicKeyEx- tractConfig	032	

4.1.38. CryCVCPublicKeyExtractConfig

Parameters included		
Parameter name	Multiplicity	
CryCVCPublicKeyEx- tractCfgRef	11	
CryExtractCVCRootCer- tificateLength	11	
CryExtractCVCSigCer- tificateLength	11	
CryCVCPublicKeyEx- tractLength	11	
CryCVCPublicKeyEx- tractEnableCertChain	11	

Parameter Name	CryCVCPublicKeyExtractCfgRef	
Label	Signature verify configuration	
Description	Signature verify configuration which is used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryExtractCVCRootCertificateLength	
Label	Length of the issuing certificate (in bytes)	
Description	Length of the issuing certificate (in bytes) which is used	



Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=1
	<=4294967295

Parameter Name	CryExtractCVCSigCertificateLength	
Label	Length of the key certificate (in bytes)	
Description	Length of the key certificate (in bytes) which is used	
Multiplicity	11	
Туре	INTEGER	
Default value	1	
Range	>=1	
	<=4294967295	

Parameter Name	CryCVCPublicKeyExtractLength
Label	Key Length (in bytes)
Description	Key Length used
Multiplicity	11
Туре	INTEGER
Default value	1
Range	>=0
	<=4294967295

Parameter Name	CryCVCPublicKeyExtractEnableCertChain
Label	Use certificate chain verification
Description	This configuration parameter enables or disables the verification of the certificate chain. True: The key certificate is verified (i.e. its dates and signature) against the issuing certificate. False: The key is extracted from the key certificate without verifying the certificate against its issuing certificate
Multiplicity	11
Туре	BOOLEAN
Default value	true



4.1.39. CryCbcPkcs7Encrypt

Containers included		
Container name	Multiplicity	Description
CryCbcPkcs7EncryptCor	10 g.32	

4.1.40. CryCbcPkcs7EncryptConfig

Parameters included	
Parameter name	Multiplicity
CryCbcPkcs7EncryptSyn	n B ldckEncryptCfgRef

Parameter Name	CryCbcPkcs7EncryptSymBlockEncryptCfgRef	
Label	SymBlockEncrypt configuration	
Description	Symmetrical block encryption configuration used	
Multiplicity	11	
Туре	REFERENCE	

4.1.41. CryCbcPkcs7Decrypt

Containers included		
Container name	Multiplicity	Description
CryCbcPkcs7DecryptCor	10 g32	

4.1.42. CryCbcPkcs7DecryptConfig

Parameters included		
Parameter name	Multiplicity	
CryCbcPkcs7DecryptSyr	nBldckDecryptCfgRef	

Parameter Name	CryCbcPkcs7DecryptSymBlockDecryptCfgRef	
Label	SymBlockDecrypt configuration	
Description	Symmetrical block decryption configuration used	



Multiplicity	11
Туре	REFERENCE

4.1.43. CryCcmEncrypt

Containers included		
Container name	Multiplicity	Description
CryCcmEncryptConfig	032	

4.1.44. CryCcmEncryptConfig

Parameters included		
Parameter name	Multiplicity	
CryCcmEncryptSym- BlockEncryptCfgRef	11	
CryCCMMacLength	11	
CryCCMLengthField- Size	11	
<u>CryCCMAdataLen</u>	11	

Parameter Name	CryCcmEncryptSymBlockEncryptCfgRef	
Label	SymBlockEncrypt configuration	
Description	Symmetrical block encryption configuration used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryCCMMacLength	
Label	MAC length	
Description	The octet length of the MAC. t parameter in the "NIST Special Publication 800-38C".	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CRY_CCM_MAC_8_BYTES	



Range	CRY_CCM_MAC_4_BYTES
	CRY_CCM_MAC_6_BYTES
	CRY_CCM_MAC_8_BYTES
	CRY_CCM_MAC_10_BYTES
	CRY_CCM_MAC_12_BYTES
	CRY_CCM_MAC_14_BYTES
	CRY_CCM_MAC_16_BYTES

Parameter Name	CryCCMLengthFieldSize	
Label	Size of length field	
Description	The octet length of the binary representation of the octet length of the payload. q parameter in the "NIST Special Publication 800-38C".	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CRY_CCM_LEN_FIELD_2_BYTES	
Range	CRY_CCM_LEN_FIELD_2_BYTES	
	CRY_CCM_LEN_FIELD_3_BYTES	
	CRY_CCM_LEN_FIELD_4_BYTES	

Parameter Name	CryCCMAdataLen	
Label	Authenticated data length	
Description	The length of the authenticated data	
Multiplicity	11	
Туре	INTEGER	
Default value	8	
Range	>=0	
	<=4294967296	

4.1.45. CryCcmDecrypt

Containers included		
Container name	Multiplicity	Description



Containers included		
CryCcmDecryptConfig	032	

4.1.46. CryCcmDecryptConfig

Parameters included	
Parameter name	Multiplicity
CryCcmEncryptSym- BlockEncryptCfgRef	11
CryCCMMacLength	11
CryCCMLengthField- Size	11
<u>CryCCMAdataLen</u>	11
CryCCMMaxPayload- Size	11

Parameter Name	CryCcmEncryptSymBlockEncryptCfgRef	
Label	SymBlockEncrypt configuration	
Description	Symmetrical block encryption configuration used	
Multiplicity	11	
Туре	REFERENCE	

Parameter Name	CryCCMMacLength	
Label	MAC length	
Description	The octet length of the MAC.	
	t parameter in the "NIST Special Publication 800-38C".	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CRY_CCM_MAC_8_BYTES	
Range	CRY_CCM_MAC_4_BYTES	
	CRY_CCM_MAC_6_BYTES	
	CRY_CCM_MAC_8_BYTES	
	CRY_CCM_MAC_10_BYTES	



CRY_CCM_MAC_12_BYTES
CRY_CCM_MAC_14_BYTES
CRY_CCM_MAC_16_BYTES

Parameter Name	CryCCMLengthFieldSize
Label	Size of length field
Description	The octet length of the binary representation of the octet length of the payload. q parameter in the "NIST Special Publication 800-38C".
Multiplicity	11
Туре	ENUMERATION
Default value	CRY_CCM_LEN_FIELD_2_BYTES
Range	CRY_CCM_LEN_FIELD_2_BYTES
	CRY_CCM_LEN_FIELD_3_BYTES
	CRY_CCM_LEN_FIELD_4_BYTES

Parameter Name	CryCCMAdataLen	
Label	Authenticated data length	
Description	The length of the authenticated data	
Multiplicity	11	
Туре	INTEGER	
Default value	8	
Range	>=0	
	<=4294967296	

Parameter Name	CryCCMMaxPayloadSize
Label	Maximum payload length
Description	The maximum payload data length in bytes. Please note that the memory consumption of the algorithm is proportional with this value.
Multiplicity	11
Туре	INTEGER
Default value	8
Range	>=0



<=42	4967296	
<=42	4967296	

4.1.47. CryHMACVrfy

Containers included		
Container name	Multiplicity	Description
CryHMACVrfyConfig	032	

Parameters included	
Parameter name	Multiplicity
CryHMACVrfyImmedi-	11
ateRestartEnabled	

Parameter Name	CryHMACVrfyImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.48. CryHMACVrfyConfig

Parameters included	
Parameter name	Multiplicity
CryHMACVrfyHashCf- gRef	11
<u>CryHMACKeyLength</u>	11

Parameter Name	CryHMACVrfyHashCfgRef
Label	Hash configuration
Description	Hash configuration used
Multiplicity	11
Туре	REFERENCE



Parameter Name	CryHMACKeyLength
Label	Key Length
Description	Key Length used in the HMAC verification
Multiplicity	11
Туре	INTEGER
Default value	64

4.1.49. CryHMACGen

Containers included		
Container name	Multiplicity	Description
CryHMACGenConfig	032	

Parameters included	
Parameter name	Multiplicity
CryHMACGenImmedi- ateRestartEnabled	11

Parameter Name	CryHMACGenImmediateRestartEnabled
Label	Enable the cancelation of ongoing requests
Description	Enable the cancelation of an ongoing calculation regardless of the configuration ID.
Multiplicity	11
Туре	BOOLEAN
Default value	false

4.1.50. CryHMACGenConfig

Parameters included	
Parameter name	Multiplicity
CryHMACGenHashCf- gRef	11
<u>CryHMACKeyLength</u>	11



Parameter Name	CryHMACGenHashCfgRef
Label	Hash configuration
Description	Hash configuration used
Multiplicity	11
Туре	REFERENCE

Parameter Name	CryHMACKeyLength
Label	Key Length
Description	Key Length used in the HMAC generation
Multiplicity	11
Туре	INTEGER
Default value	64

4.1.51. CryExtractRsaPublicKey

Containers included		
Container name	Multiplicity	Description
CryExtractRsaPublicK- eyConfig	032	

4.1.52. CryExtractRsaPublicKeyConfig

Parameters included	
Parameter name	Multiplicity
CryExtractRsaPublicK-	11
<u>eyLength</u>	

Parameter Name	CryExtractRsaPublicKeyLength
Label	Key Length
Description	Key Length used
Multiplicity	11
Туре	INTEGER
Default value	384



Range	>=0
	<=4294967295

4.1.53. CryCrc

Containers included		
Container name	Multiplicity	Description
CryCrcConfig	032	

4.1.54. CryCrcConfig

Parameters included		
Parameter name	Multiplicity	
<u>CryCrcType</u>	11	
CryCrcPoly	11	
CryCrclputXor	11	
CryCrcOputXor	11	
CryCrclputReflect	11	
CryCrcOputReflect	11	
CryCrcMaxBytesPerCy-	11	
<u>cle</u>		

Parameter Name	CryCrcType	
Label	Order of Polynom	
Description	Order of polynom that is used for cyclic redundancy check	
Multiplicity	11	
Туре	ENUMERATION	
Default value	CRY_CRC_32	
Range	CRY_CRC_8	
	CRY_CRC_16	
	CRY_CRC_32	

Parameter Name	CryCrcPoly
----------------	------------



Label	Generator Polynom	
Description	Generator Polynom that is used for cyclic redundancy check	
Multiplicity	11	
Туре	INTEGER	
Default value	1	
Range	>=0	
	<=4294967295	

Parameter Name	CryCrclputXor
Label	XOR Input
Description	Polynom with which the input data is XORed
Multiplicity	11
Туре	INTEGER
Default value	0
Range	>=0
	<=4294967295

Parameter Name	CryCrcOputXor	
Label	XOR Output	
Description	Polynom with which the output data is XORed	
Multiplicity	11	
Туре	INTEGER	
Default value	0	
Range	>=0	
	<=4294967295	

Parameter Name	CryCrclputReflect	
Label	Reflect Input	
Description	Shall the input data be reflected?	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

Parameter Name	CryCrcOputReflect	
Parameter Name	CryCrcOputReflect	



Label	Reflect Output	
Description	Shall the output data be reflected?	
Multiplicity	11	
Туре	BOOLEAN	
Default value	false	

Parameter Name	CryCrcMaxBytesPerCycle	
Label	Bytes per Cycle	
Description	maximal number of Bytes given by set of Bytes by Csm_ChecksumUpdate that are processed during a single task cycle	
Multiplicity	11	
Туре	INTEGER	
Default value	32	
Range	>=1	
	<=4294967295	

4.1.55. CryExtractECPubKey

Containers included		
Container name	Multiplicity	Description
CryExtractECPubKey- Config	032	

4.1.56. CryExtractECPubKeyConfig

Parameters included	
Parameter name	Multiplicity
<u>CryEllipticCurve</u>	11

Parameter Name	CryEllipticCurve
Label	Elliptic Curve
Description	Elliptic curve used
Multiplicity	11



Туре	ENUMERATION
Default value	CRY_EDC_255
Range	CRY_EDC_255

4.1.57. PublishedInformation

Parameters included	
Parameter name	Multiplicity
<u>PbcfgMSupport</u>	11

Parameter Name	PbcfgMSupport
Label	PbcfgM support
Description	Specifies whether or not the Cry can use the PbcfgM module for post-build support.
Multiplicity	11
Туре	BOOLEAN
Default value	false
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

4.2. Application programming interface (API)

4.2.1. Type definitions

4.2.1.1. Cry_EdDSAGenKeyType

Purpose	The private key used for creating a signature.	
Туре	struct	
Members	uint32 length	Dummy element to make the type compatible with the Csm key type.



	Cry_LNWordType D	The secret which has to be a b-bit string.	
--	------------------	--	--

4.2.1.2. Cry_EdDSAVrfyKeyType

Purpose	The public key used for verifying a signature.	
Туре	struct	
Members	uint32 length	Dummy element to make the type compatible with the Csm key type.
	Cry_LNWordType A	An EdDSA public key is a curve point, which is created by multiplying the s with Point B, encoded in b bits.

4.2.1.3. Cry_ExtractECPubKeyCtxType

Purpose	Structure which contains the context of the	Structure which contains the context of the elliptic curve public key extraction.	
Туре	struct		
Members	uint32 keyLvl	Stores the ammount of bytes currently copied in Cry's internal buffer.	
	uint32 keyLen	Stores the length of the key provided by the user during the initialization of the algorithm.	
	Cry_ECKeyType * oputDataPtr	Stores the address of the user-provided output buffer.	
	Cry_ExtractECPubKeyStateType ctxState	Stores the internal state of the elliptic curve public key extraction algorithm.	
	Csm_ReturnType ctxError		
	uint8 keyBuf		

4.2.1.4. Cry_ExtractECPubKeyStateType

Purpose	Internal states of the elliptic curve public key extraction.	
Туре	enum	
Constants	CRY_EXTRACT_ECPUBKEY_STATE IDLE	The algorithm is in the idle state.



	CRY_EXTRACT_ECPUBKEY_STATE START	The initialization of the algorithm is in progress.
	CRY_EXTRACT_ECPUBKEY_STATE INITIALIZED	The initialization of the algorithm is completed.
	CRY_EXTRACT_ECPUBKEY_STATE UPDATE	The algorithm was provided with input data.
	CRY_EXTRACT_ECPUBKEY_STATE CALCULATED	The algorithm finished copying data to the internal buffer and is waiting for the user-provided output buffer.
	CRY_EXTRACT_ECPUBKEY_STATE FINISH	The algorithm is converting the user-provided byte array to long number representation.
	CRY_EXTRACT_ECPUBKEY_STATE ERROR	An error occurred due to the user provided data.

4.2.2. Macro constants

4.2.2.1. CRY_MD5_BLOCK_SIZE

•	A message which should be hashed is divided into blocks which are processed indi-	
	vidually. This macro gives the length of a block in bytes.	
Value	64U	

4.2.2.2. CRY_MD5_HASH_LEN_BYTES

Purpose	The length of a message digest computed with the MD5 algorithm in bytes.
Value	16U

4.2.2.3. CRY_MD5_STATE_BYTES

Purpose	The hash algorithm uses a state which is modified by processing the input. The state	
	after processing the whole input is the hash digest. This macro gives the length of the	
	state in 8-bit words.	



|--|

4.2.2.4. CRY_MD5_STATE_WORDS

Purpose	The hash algorithm uses a state which is modified by processing the input. The state after processing the whole input is the hash digest. This macro gives the length of the state in 32-bit words.
Value	4U

4.2.3. Functions

4.2.3.1. Cry_AES_DecryptFinish

Purpose	Finish AES block decryption computation.	
Synopsis	Csm_ReturnType Cry_AES_DecryptFinish (void);	
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no AES block decryption computation has been started via Csm_SymBlockDecryptStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the finishing of the AES block decryption computation and the storing of the decrypted text in the given buffer. The finish is performed in Cry_AESDecrypt_MainFunction().	

4.2.3.2. Cry_AES_DecryptMainFunction

Purpose	Perform the AES block decryption computation tasks.	
Synopsis	<pre>void Cry_AES_DecryptMainFunction (void);</pre>	
Description	This function performs the actual AES block decryption computation tasks which have been requested by the service functions. The function calls the main function of the configured primitive to perform the tasks.	



4.2.3.3. Cry_AES_DecryptStart

Purpose	Start AES block decryption computation.	
Synopsis	Csm_ReturnType Cry_AES_DecryptStart (const	
	void * cfgPtr , const Cs	sm_SymKeyType * keyPtr);
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the AES decryption is requested.
	keyPtr	A pointer to the key which should be used in the AES block decryption computation.
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	
	CSM_E_BUSY	If a service of the AES block decryption computation is already running.
Description	This function requests the start of the AES decryption computation for the given configuration. The start is performed in Cry_AES_Decrypt_MainFunction().	

4.2.3.4. Cry_AES_DecryptUpdate

Purpose	Update AES block decryption computation.	
Synopsis	* iputTextPtr , uint32	<pre>cryptUpdate (const uint8 iputTextLength , uint8 * oputTextLengthPtr);</pre>
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant cipher text that shall be decrypted.
	iputTextLength	Length of the constant cipher text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been decrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the decrypted text will be stored.



Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no AES block decryption computation has been started via Csm_SymBlockDecryptStart(), yet. Or if the provided buffer is too small to store the result.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the AES block decryption computation for the given data. The update is performed in Cry_AES_Decrypt_MainFunction().	

4.2.3.5. Cry_AES_EncryptFinish

Purpose	Finish AES block encryption computation.	
Synopsis	Csm_ReturnType Cry_AES_EncryptFinish (void);	
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no AES block encryption computation has been started via Csm_SymBlockEncryptStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the finishing of the AES block encryption computation and the storing of the encrypted text in the given buffer. The finish is performed in Cry_AESEncrypt_MainFunction().	

4.2.3.6. Cry_AES_EncryptMainFunction

Purpose	Perform the AES block encryption computation tasks.	
Synopsis	<pre>void Cry_AES_EncryptMainFunction (void);</pre>	
Description	This function performs the actual AES block encryption computation tasks which have been requested by the service functions. The function calls the main function of the configured primitive to perform the tasks.	



4.2.3.7. Cry_AES_EncryptStart

Purpose	Start AES block encryption computation.	
Synopsis	Csm_ReturnType Cry_AES_EncryptStart (const	
	<pre>void * cfgPtr , const Csm_SymKeyType * keyPtr);</pre>	
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the AES encryption is requested.
	keyPtr	A pointer to the key which should be used in the AES block encryption computation.
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	
	CSM_E_BUSY	If a service of the AES block encryption computation is already running.
Description	This function requests the start of the AES encryption computation for the given configuration. The start is performed in Cry_AES_Encrypt_MainFunction().	

4.2.3.8. Cry_AES_EncryptUpdate

Purpose	Update AES block encryption computation.	
Synopsis	* iputTextPtr , uint32	<pre>cryptUpdate (const uint8 iputTextLength , uint8 * oputTextLengthPtr);</pre>
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant plain text that shall be encrypted.
	iputTextLength	Length of the constant plain text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been encrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the encrypted text will be stored.



Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no AES block encryption computation has been started via Csm_SymBlockEncryptStart(), yet. Or if the provided buffer is too small to store the result.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the AES block encryption computation for the given data. The update is performed in Cry_AES_Encrypt_MainFunction().	

4.2.3.9. Cry_CMACGenFinish

Purpose	Finish CMAC generation.	
Synopsis	<pre>Csm_ReturnType Cry_CMACGenFinish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean TruncationIsAllowed);</pre>	
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	TruncationIsAllowed	Is truncation of the result allowed or must an error be returned when the result buffer is too small?
Parameters (in,out)	resultLengthPtr	A pointer to a variable which contains the maximal allowed length for the CMAC in bits and where the actual length of the CMAC will be stored.
Parameters (out)	resultPtr	A pointer to the start of a buffer where the generated CMAC will be stored.
Return Value	Error code	
	CSM_E_OK	If the finishing was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no CMAC generation has been started via Cry_CMACGenStart() yet or if the finishing of the CMAC computation is already requested.



Description	This function requests the finishing of the CMAC generation and the storing of the	
	CMAC in the given result buffer. The finishing is performed in Cry_CMACGenMain-	
	Function().	

4.2.3.10. Cry_CMACGenMainFunction

Purpose	Perform the CMAC generation tasks.
Synopsis	<pre>void Cry_CMACGenMainFunction (void);</pre>
Sync/Async	Asynchronous
Reentrancy	Not reentrant
Description	This function performs the actual CMAC generation tasks which have been requested by the service functions. When a task has finished, the function Csm_MacGenerateServiceCallbackNotification() is called to inform the CSM of the result. If the complete CMAC generation has finished, additionally the function Csm_MacGenerateServiceFinishNotification() is called.

4.2.3.11. Cry_CMACGenStart

Purpose	Start CMAC generation.		
Synopsis	<pre>Csm_ReturnType Cry_CMACGenStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr);</pre>		
Sync/Async	Asynchronous	Asynchronous	
Reentrancy	Not reentrant		
Parameters (in)	cfgPtr	a pointer to the configuration for which the start of the CMAC generation is requested.	
	keyPtr	a pointer to the key which will be used in the CMAC generation.	
Return Value	Error code		
	CSM_E_OK	If the start was successfully requested.	
	CSM_E_BUSY	If a service of the CMAC generation is already running.	
Description	This function requests the start of the CMAC generation for the given configuration and key. The start is performed in Cry_CMACGenMainFunction ().		



4.2.3.12. Cry_CMACGenUpdate

Purpose	Update CMAC generation.	
Synopsis	Csm_ReturnType Cry_CMACGenUpdate (con-	
	st uint8 * dataPtr ,	, uint32 dataLength);
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	dataPtr A pointer to the start of an array which contains a part of the data for which the CMAC will be generated.	
	dataLength	The amount of data in bytes.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no CMAC generation has been started via Cry_CMACGenStart()) yet or if the finishing of the CMAC computation is already requested.
Description	This function requests the update of the CMAC generation for the given data. The update is performed in Cry_CMACGenMainFunction() .	

4.2.3.13. Cry_CMACVrfyFinish

Purpose	Finish CMAC verification.		
Synopsis	Csm_ReturnType Cry_CMACVrfyFinish (const uint8		
	* authenticationPtr ,	* authenticationPtr , uint32 authentication-	
	Length , Csm_VerifyResultType * resultPtr);		
Sync/Async	Asynchronous		
Reentrancy	Not reentrant		
Parameters (in)	authenticationPtr A pointer to the start of a buffer where		
		CMAC to verify is stored.	
	authenticationLength	The length of the CMAC to verify in bits.	
Parameters (out)	resultPtr	A pointer to a variable where the result of the CMAC verification will be stored.	



Return Value	Error code	
	CSM_E_OK	If the finishing was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no CMAC verification has been started via Cry_CMACVrfyStart() yet or if the finishing of the CMAC computation is already requested.
Description	This function requests the finishing of the formed in Cry_CMACVrfyMainFunction ().	CMAC verification. The finishing is per-

4.2.3.14. Cry_CMACVrfyMainFunction

Purpose	Perform the CMAC verification tasks.
Synopsis	<pre>void Cry_CMACVrfyMainFunction (void);</pre>
Sync/Async	Asynchronous
Reentrancy	Not reentrant
Description	This function performs the actual CMAC verification tasks which have been requested by the service functions. When a task has finished, the function Csm_MacVerifyServiceCallbackNotification() is called to inform the CSM of the result. If the complete CMAC verification has finished, additionally the function Csm_MacVerifyServiceFinishNotification() is called.

4.2.3.15. Cry_CMACVrfyStart

Purpose	Start CMAC verification.	
Synopsis	<pre>Csm_ReturnType Cry_CMACVrfyStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr);</pre>	
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	cfgPtr	a pointer to the configuration for which the start of the CMAC verification is requested.



	keyPtr	a pointer to the key which will be used in the CMAC verification.
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of the CMAC verification is already running.
Description	This function requests the start of the CMA and key. The start is performed in Cry_CMA	

4.2.3.16. Cry_CMACVrfyUpdate

Purpose	Update CMAC verification.	
Synopsis	Csm_ReturnType Cry_CMACVrfyUpdate (con- st uint8 * dataPtr , uint32 dataLength);	
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	A pointer to the start of an array w contains a part of the data for which CMAC will be verified.	
	dataLength	The amount of data in bytes.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no CMAC verification has been started via Cry_CMACVrfyStart() yet or if the finishing of the CMAC computation is already requested.
Description	This function requests the update of the CMAC verification for the given data. The update is performed in Cry_CMACVrfyMainFunction ().	

4.2.3.17. Cry_CRCFinish

Purpose	Finish CRC calculation.
---------	-------------------------



Synopsis	<pre>Csm_ReturnType Cry_CRCFinish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean truncationIsAllowed);</pre>	
Parameters (in)	truncationIsAllowed	A flag that states wheter a truncation of the calculated CRC result is allowed. TRUE = truncation is allowed. FALSE = truncation is not allowed.
Parameters (out)	resultPtr	A pointer to the buffer where the calculated CRC result should be stored. If the result does not fit into the given buffer, and truncation is allowed, the result will be truncated.
	resultLengthPtr	On calling the function it is the amount of bytes of resultPtr. After finishing of function call it is the actual length of the calculated CRC result.
Return Value	Return Value Error value.	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no CRC calculation has been started via Csm_SymKeyExtractStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the finishing of the CRC calculation and the storing of the calculated CRC result in the given buffer. The finish is performed in Cry_CRCMainFunction() .	

4.2.3.18. Cry_CRCMainFunction

Purpose	Perform the CRC calculation tasks.
Synopsis	<pre>void Cry_CRCMainFunction (void);</pre>
Description	This function performs the actual CRC calculation tasks which have been requested by the service functions. The function calls the main function of the configured primitive to perform the tasks.

4.2.3.19. Cry_CRCStart

Purpose Start CRC calculation.	
--------------------------------	--



Synopsis	<pre>Csm_ReturnType Cry_CRCStart (const void * cfgPtr);</pre>	
Parameters (in)	cfgId	An identification of the configuration for which the start of the CRC calculation should be requested.
Return Value	Error value.	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	
	CSM_E_BUSY	If a service of the CRC calculation is already running.
Description	This function requests the start of the CRC calculation for the given configuration. The start is performed in Cry_CRCMainFunction() .	

4.2.3.20. Cry_CRCUpdate

Purpose	Update of CRC calculation.	
Synopsis	Csm_ReturnType Cry_CRCUpdate (con- st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	A pointer to the start of an array which contains the data for which the CRC shall be calculated.
	dataLength	The amount of bytes of data.
Return Value	Error value.	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no CRC calculation has been started via Csm_SymKeyExtractStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the CRC calculation for the given data. The update is performed in Cry_CRCMainFunction() .	

4.2.3.21. Cry_CVCPublicKeyExtractFinish

Purpose	Finish RSA public key extract computation.
---------	--



Synopsis	<pre>Csm_ReturnType Cry_CVCPublicKeyExtractFin- ish (Csm_AsymPublicKeyType * keyPtr);</pre>	
Parameters (out)	keyPtr	A pointer to the structure where to store the result.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no RSA public key extract computation was started via Csm_SymKeyExtractS-tart() beforehand.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the finishing of the RSA public key extract computation and the storing of the extracted key data in the given buffer. The finish is performed in CVCPublicKeyExtractMainFunction ().	

4.2.3.22. Cry_CVCPublicKeyExtractMainFunction

Purpose	Perform the RSA public key extract computation tasks.	
Synopsis	<pre>void Cry_CVCPublicKeyExtractMainFunction (void);</pre>	
Description	This function performs the actual RSA public key extract computation tasks which have been requested by the service functions.	

${\bf 4.2.3.23.} \ {\bf Cry_CVCPublicKeyExtractStart}$

Purpose	Start RSA public key extract computation.	
Synopsis	<pre>Csm_ReturnType Cry_CVCPublicKeyEx- tractStart (const void * cfgPtr);</pre>	
Parameters (in)	A pointer to the configuration for which the start of the RSA public key extraction is requested.	
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	



		If a service of the RSA public key extract computation is already running.
Description	This function requests the start of the RSA en configuration. The start is performed in 9	

4.2.3.24. Cry_CVCPublicKeyExtractUpdate

Purpose	Update RSA public key extract computation.	
Synopsis	<pre>Csm_ReturnType Cry_CVCPublicKeyExtractUpdate (const uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)	dataPtr	A pointer to the start of an array which contains the key that have to extract in a CSM-conforming format.
	dataLength	Length of the key data in bytes.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no RSA public key extract computation was started via Csm_SymKeyExtractS-tart() beforehand.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the RSA public key extract computation for the given data. The update is performed in Cry_CVCPublicKeyExtractMainFunction (). Update is called twice: 1) Cry_CVCPublicKeyExtractUpdate is first called with the Root certificate (in some documents Verify cv) changing the state of the state machine and preparing Cry_CVCPublicKeyExtractMainFunction to extract the key 2) Another call of the Cry_CVCPublicKeyExtractUpdate is with Signing certificate (in some docs Key cv) changing the state of state machine and preparing Cry_CVCPublicKeyExtractMainFunction for verifying (with the previous extracted key from root cv)	

4.2.3.25. Cry_CbcPkcs7DecryptFinish

Purpose	Finish Decrypt.



Synopsis	<pre>Csm_ReturnType Cry_CbcPkcs7DecryptFinish (uint8 * oputTextPtr , uint32 * oputTextLengthPtr);</pre>	
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been decrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the decrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the encrypted data.
Description	This function finishes the decryption.	

4.2.3.26. Cry_CbcPkcs7DecryptMainFunction

Purpose	Perform primitive tasks.	
Synopsis	<pre>void Cry_CbcPkcs7DecryptMainFunction (void);</pre>	
Description	This function performs periodic tasks of the primitive that may be necessary (e.g. checking if a CSE command has to be sent or if a CSE command has finished). This function is called by a corresponding CSM main function.	

4.2.3.27. Cry_CbcPkcs7DecryptStart

Purpose	Start the symmetric decryption.	
Synopsis	Csm_ReturnType Cry_CbcPkcs7DecryptStart (const void	
	* cfgPtr , const Csm_SymKeyType * keyPtr , const	
	<pre>uint8 * initVectorPtr , uint32 initVectorLength);</pre>	



Parameters (in)	cfgPtr	The service configuration.
	keyPtr	Pointer to the key to be used.
	initVectorPtr	Holds a pointer to the key which has to be used during the symmetrical decryption computation.
	initVectorLength	Holds the length in bytes of the initialisation vector which has to be used during the symmetrical decryption computation.
Return Value	Error code	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function starts the SymDecrypt service which will decrypt blocks of data.	

4.2.3.28. Cry_CbcPkcs7DecryptUpdate

Purpose	Stream data to be decrypted (Single-Shot only).	
Synopsis	Csm_ReturnType Cry_CbcPkcs7DecryptUpdate (con- st uint8 * iputTextPtr , uint32 iputTextLength , uint8 * oputTextPtr , uint32 * oputTextLengthPtr);	
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant plain text that shall be decrypted.
	iputTextLength	Length of the constant cipher text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been decrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the decrypted text will be stored.
Return Value Error code		
	CSM_E_OK	If the update was successfully requested.



	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the decrypted data.
Description	This function streams data to be decrypted into the CSE.	

4.2.3.29. Cry_CbcPkcs7EncryptFinish

Purpose	Finish encrypt.	
Synopsis	<pre>Csm_ReturnType Cry_CbcPkcs7EncryptFinish (uint8 * oputTextPtr , uint32 * oputTextLengthPtr);</pre>	
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been encrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the encrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the encrypted data.
Description	This function finishes the encryption.	

4.2.3.30. Cry_CbcPkcs7EncryptMainFunction

Purpose	Perform primitive tasks.	
Synopsis	<pre>void Cry_CbcPkcs7EncryptMainFunction (void);</pre>	



Description	This function performs periodic tasks of the primitive that may be necessary (e.g.
	checking if a CSE command has to be sent or if a CSE command has finished). This
	function is called by a corresponding CSM main function.

4.2.3.31. Cry_CbcPkcs7EncryptStart

Purpose	Start the symmetric encryption.	
Synopsis	<pre>Csm_ReturnType Cry_CbcPkcs7EncryptStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr , const uint8 * initVectorPtr , uint32 initVectorLength);</pre>	
Parameters (in)	cfgPtr	The service configuration.
	keyPtr	Pointer to the key to be used.
	initVectorPtr	Holds a pointer to the key which has to be used during the symmetrical encryption computation.
	initVectorLength	Holds the length in bytes of the initialisation vector which has to be used during the symmetrical encryption computation.
Return Value	Error code	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function starts the SymEncrypt service which will encrypt blocks of data.	

4.2.3.32. Cry_CbcPkcs7EncryptUpdate

Purpose	Stream data to be encrypted (Single-Shot only).	
Synopsis	<pre>Csm_ReturnType Cry_CbcPkcs7EncryptUpdate (con- st uint8 * iputTextPtr , uint32 iputTextLength , uint8 * oputTextPtr , uint32 * oputTextLengthPtr);</pre>	
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant plain text that shall be encrypted.



	iputTextLength	Length of the constant plain text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been encrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the encrypted text will be stored.
Return Value	urn Value Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the encrypted data.
Description	This function streams data to be encrypted into the CSE.	

4.2.3.33. Cry_CcmDecryptFinish

Purpose	Finish decrypt.	
Synopsis	<pre>Csm_ReturnType Cry_CcmDecryptFinish (uint8 * oputTextPtr , uint32 * oputTextLengthPtr);</pre>	
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been decrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the decrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.



	CSM_E_BUSY	If another instance of this service is already running.
Description	This function finishes the decryption.	

4.2.3.34. Cry_CcmDecryptMainFunction

Purpose	Perform primitive tasks.	
Synopsis	<pre>void Cry_CcmDecryptMainFunction (void);</pre>	
Description	This function performs periodic tasks of the primitive that may be necessary (e.g. checking if a CSE command has to be sent or if a CSE command has finished). This function is called by a corresponding CSM main function.	

4.2.3.35. Cry_CcmDecryptStart

Purpose	Start the symmetric decryption.	
Synopsis	<pre>Csm_ReturnType Cry_CcmDecryptStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr , const uint8 * initVectorPtr , uint32 initVectorLength);</pre>	
Parameters (in)	cfgPtr	The service configuration.
	keyPtr	Pointer to the key to be used.
	initVectorPtr	Holds a pointer to the key which has to be used during the symmetrical decryption computation.
	initVectorLength	Holds the length in bytes of the initialisation vector which has to be used during the symmetrical decryption computation.
Return Value	Error code	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
Description	This function starts the SymDecrypt service which will decrypt blocks of data.	

4.2.3.36. Cry_CcmDecryptUpdate

Purpose Stream data to be decrypted (Single-Shot only).	
---	--



Synopsis	Csm_ReturnType Cry_CcmDecryptUpdate (const uint8	
	* iputTextPtr , uint32	iputTextLength , uint8
	* oputTextPtr , uint32	<pre>* oputTextLengthPtr);</pre>
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant cipher text that shall be decrypted.
	iputTextLength	Length of the constant cipher text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been decrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the decrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the decrypted data.
Description	This function streams data to be decrypted into the CSE.	

4.2.3.37. Cry_CcmEncryptFinish

Purpose	Finish encrypt.	
Synopsis	<pre>Csm_ReturnType Cry_CcmEncryptFinish (uint8 * oputTextPtr , uint32 * oputTextLengthPtr);</pre>	
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been encrypted shall be stored.



Parameters (out)	oputTextPtr	A pointer to the start of an array where the encrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function finishes the encryption.	

4.2.3.38. Cry_CcmEncryptMainFunction

Purpose	Perform primitive tasks.	
Synopsis	<pre>void Cry_CcmEncryptMainFunction (void);</pre>	
Description	This function performs periodic tasks of the primitive that may be necessary (e.g. checking if a CSE command has to be sent or if a CSE command has finished). This function is called by a corresponding CSM main function.	

4.2.3.39. Cry_CcmEncryptStart

Purpose	Start the symmetric encryption.	
Synopsis	<pre>Csm_ReturnType Cry_CcmEncryptStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr , const uint8 * initVectorPtr , uint32 initVectorLength);</pre>	
Parameters (in)	cfgPtr	The service configuration.
	keyPtr	Pointer to the key to be used.
	initVectorPtr	Holds a pointer to the key which has to be used during the symmetrical encryption computation.
	initVectorLength	Holds the length in bytes of the initialisation vector which has to be used during the symmetrical encryption computation.
Return Value	Error code	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.



Description	This function starts the SymEncrypt service which will encrypt blocks of data.	
		Ĺ

4.2.3.40. Cry_CcmEncryptUpdate

Purpose	Stream data to be encrypted (Single-Shot only).	
Synopsis	* iputTextPtr , uint32	<pre>cryptUpdate (const uint8 iputTextLength , uint8 * oputTextLengthPtr);</pre>
Parameters (in)	iputTextPtr	A pointer to the start of an array which contains the constant associated data and plain text that shall be encrypted.
	iputTextLength	Length of the constant plain text in bytes.
Parameters (in,out)	oputTextLengthPtr	Holds a pointer to a memory location in which the length information in bytes is stored. On calling this function this parameter shall contain the size of the buffer provided by oputTextPtr. When the request has finished, the amount of data that has been encrypted shall be stored.
Parameters (out)	oputTextPtr	A pointer to the start of an array where the encrypted text will be stored.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If the service has not been started.
	CSM_E_BUSY	If another instance of this service is already running.
	CSM_E_SMALL_BUFFER	If the result buffer is too small for the encrypted data.
Description	This function streams data to be encrypted into the CSE.	

4.2.3.41. Cry_EdDSAGenFinish

Purpose	Finish signature generation.	
Synopsis	Csm_ReturnType Cry_EdDSAGenFinish (uint8	
	<pre>* resultPtr , uint32 * resultLengthPtr);</pre>	



Parameters (out)	resultPtr	A pointer to the start of a buffer which holds the signature.
	resultLengthPtr	Length of the signature in bytes.
Return Value	Error value.	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no signature generation has been start-
		ed via Cry_EdDSAGenStart().
	CSM_E_BUSY	If the main function is processing a re-
		quested service at the moment.
Description	This function requests the finishing of the EdDSA signature generation and the storing	
	of the signature in the given result buffer. The finishing is performed in Cry_EdDSA-	
	GenMainFunction().	

4.2.3.42. Cry_EdDSAGenMainFunction

Purpose	Perform the EdDSAGen tasks.	
Synopsis	<pre>void Cry_EdDSAGenMainFunction (void);</pre>	
Description	This function performs the actual EdDSA signature generation tasks which have been requested by the service functions. When a task has finished, the function Csm_SignatureGenerateCallbackNotification() is called to inform the CSM of the result. If the complete signature generation has finished, additionally the function Csm_Signature-GenerateServiceFinishNotification() is called.	

4.2.3.43. Cry_EdDSAGenStart

Purpose	Start signature generation.	
Synopsis	<pre>Csm_ReturnType Cry_EdDSAGenStart (const void * cfgP- tr , const Csm_AsymPrivateKeyType * privateKeyPtr);</pre>	
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the signature generation should be requested.
	privateKeyPtr	A pointer to the key which should be used in the signature generation.
Return Value	Error value.	
	CSM_E_OK	If the service can be started.



		If another instance of this service is already running.
Description	This function requests the start of the EdDSA signature generation for the given configuration and key. The start is performed in Cry_EdDSAGenMainFunction() .	

4.2.3.44. Cry_EdDSAGenUpdate

Purpose	Update signature generation.	
Synopsis	Csm_ReturnType Cry_EdDSAGenUpdate (con- st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	A pointer to the start of an array which contains data or a part of the data for which the signature should be created.
	dataLength	The amount of bytes of data.
Return Value	Error value.	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no signature generation has been started via Cry_EdDSAGenStart() .
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
Description	This function requests the update of the EdDSA signature generation for the given data. The update is performed in Cry_EdDSAGenMainFunction() .	

4.2.3.45. Cry_EdDSAVrfyFinish

Purpose	Finish signature verification.	
Synopsis	<pre>Csm_ReturnType Cry_EdDSAVrfyFinish (const uint8 * signaturePtr , uint32 signatureLength , Csm_VerifyResultType * resultPtr);</pre>	
Parameters (in)	signaturePtr	A pointer to the start of a buffer which holds the signature.
	signatureLength	Length of the signature in bytes.
Parameters (out)	resultPtr	Verification result.
Return Value	Error value.	



	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function requests the finishing of the EdDSA signature verification and the storing of the signature in the given result buffer. The finishing is performed in Cry_Ed-DSAVrfyMainFunction() .	

4.2.3.46. Cry_EdDSAVrfyMainFunction

Purpose	Perform the EdDSAVrfy tasks.	
Synopsis	<pre>void Cry_EdDSAVrfyMainFunction (void);</pre>	
Description	This function performs the actual EdDSA signature verification tasks which have been requested by the service functions. When a task has finished, the function Csm_SignatureVerifyCallbackNotification() is called to inform the CSM of the result. If the complete signature verification has finished, additionally the function Csm_SignatureVerifyServiceFinishNotification() is called.	

4.2.3.47. Cry_EdDSAVrfyStart

Purpose	Start signature verification.	
Synopsis	Csm_ReturnType Cry_EdDSAVrfyStart (const void *	
	cfgPtr , const Csm_Asym	PublicKeyType * keyPtr);
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the signature verification should be requested.
	keyPtr	A pointer to the key which should be used in the signature verification.
Return Value	Error value.	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function requests the start of the EdDSA signature verification for the given configuration and key. The start is performed in Cry_EdDSAVrfyMainFunction() .	



4.2.3.48. Cry_EdDSAVrfyUpdate

Purpose	Update signature verification.	
Synopsis	<pre>Csm_ReturnType Cry_EdDSAVrfyUpdate (con- st uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the signature should be created.
	dataLength	The amount of bytes of data.
Return Value	Error value.	
	CSM_E_OK	If the service can be started.
	CSM_E_NOT_OK	If the key is invalid.
	CSM_E_BUSY	If another instance of this service is already running.
Description	This function requests the update of the EdDSA signature verification for the given data. The update is performed in Cry_EdDSAVrfyMainFunction() .	

4.2.3.49. Cry_ExtractECPubKeyFinish

Purpose	Finish asym public key extract computation.	
Synopsis	<pre>Csm_ReturnType Cry_ExtractECPubKeyFin- ish (Csm_AsymPublicKeyType * keyPtr);</pre>	
Parameters (in)	ReyPtr A pointer to the structure where to store the result.	
Return Value	Error value.	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no asym public key extract computation has been started via Cry_ExtractECPub-KeyStart()) yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
	CSM_E_SMALL_BUFFER	If the size of the structure where to store the result is smaller than the current publick key size.



Description	This function requests the finishing of the asym public key extract computation and
	the storing of the extracted key data in the given buffer. The finish is performed in
	Cry_ExtractECPubKeyMainFunction().

4.2.3.50. Cry_ExtractECPubKeyMainFunction

Purpose	Perform the asym public key extract computation tasks.	
Synopsis	<pre>void Cry_ExtractECPubKeyMainFunction (void);</pre>	
Description	This function performs the actual asym public key extract computation tasks which have been requested by the service functions. The function calls the main function of the configured primitive to perform the tasks.	

4.2.3.51. Cry_ExtractECPubKeyStart

Purpose	Start asym public key extract computation.	
Synopsis	<pre>Csm_ReturnType Cry_ExtractECPub- KeyStart (const void * cfgPtr);</pre>	
Parameters (in)	cfgId	An identification of the configuration for which the start of the asym public key extract computation should be requested.
Return Value	Error value. CSM E OK	If the start was successfully requested.
	CSM_E_NOT_OK	If the configuration used is not recognised or if the asym public key extract computation has allready been started via Cry_ExtractECPubKeyStart()
	CSM_E_BUSY	If a service of the asym public key extract computation is already running.
Description	This function requests the start of the asym public key extract computation for the given configuration. The start is performed in Cry_ExtractECPubKeyMainFunction() .	

4.2.3.52. Cry_ExtractECPubKeyUpdate

Purpose	Update asym public key extract computation.
---------	---



Synopsis	Csm_ReturnType Cry_ExtractECPubKeyUpdate (con-	
	st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	A pointer to the start of an array which contains the key that have to extract in a CSM-conforming format.
	dataLength	Length of the key in bytes.
Return Value	Error value.	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no asym public key extract computation has been started via Cry_ExtractECPub-KeyStart) yet, or if a NULL pointer is assigned as the data array
	CSM_E_BUSY	If the main function is currently processing a requested service.
	CSM_E_SMALL_BUFFER	If the dataLength size is greater then the expected public key size.
Description	This function requests the update of the as given data. The update is performed in Cry	

4.2.3.53. Cry_ExtractRsaPublicKeyFinish

Purpose	Finish RSA public key extract computation.	
Synopsis	Csm_ReturnType Cry_ExtractRsaPublicKeyFin-	
	ish (Csm_A	symPublicKeyType * keyPtr);
Parameters (in)	keyPtr	A pointer to the structure where to store the result.
Return Value	rn Value Error value.	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no RSA public key extract computation has been started via Csm_AsymPublicK-eyExtractStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the finishing of the RSA public key extract computation and the storing of the extracted key data in the given buffer. The finish is performed in Cry_ExtractRsaPublicKeyMainFunction ().	



4.2.3.54. Cry_ExtractRsaPublicKeyMainFunction

Purpose	Perform the RSA public key extract computation tasks.	
Synopsis	<pre>void Cry_ExtractRsaPublicKeyMainFunction (void);</pre>	
Description	This function performs the actual RSA public key extract computation tasks which have been requested by the service functions.	

4.2.3.55. Cry_ExtractRsaPublicKeyStart

Purpose	Start RSA public key extract computation.	
Synopsis	Csm_ReturnType Cry_ExtractRsaPub-	
	licKeyStart (con	st void * cfgPtr);
Parameters (in)	An identification of the configuration for which the start of the RSA public key extract computation should be requested.	
Return Value	Error value.	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	
	CSM_E_BUSY	If a service of the RSA public key extract computation is already running.
Description	This function requests the start of the RSA public key extract computation for the given configuration. The start is performed in Cry_ExtractRsaPublicKeyMainFunction() .	

4.2.3.56. Cry_ExtractRsaPublicKeyUpdate

Purpose	Update RSA public key extract computation.	
Synopsis	<pre>Csm_ReturnType Cry_ExtractRsaPublicKeyUpdate (const uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)		A pointer to the start of an array which contains the key that have to extract in a CSM-conforming format.



	dataLength	Length of the key in bytes.
Return Value	Error value.	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no RSA public key extract computation has been started via Csm_AsymPublicK-eyExtractStart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the RS given data. The update is performed in Cry	

4.2.3.57. Cry_HMACGenFinish

Purpose	Finish HMAC generation.	
Synopsis	<pre>Csm_ReturnType Cry_HMACGenFinish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean TruncationIsAllowed);</pre>	
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	TruncationIsAllowed	Is truncation of the result allowed or should an error be returned when the result buffer is too small.
Parameters (in,out)	resultLengthPtr	A pointer to a variable which contains the maximal allowed length for the HMAC in bits and where the actual length of the HMAC will be stored.
Parameters (out)	resultPtr	A pointer to the start of a buffer where the generated HMAC will be stored.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no HMAC generation has been started via Cry_HMACGenStart() yet or if the finishing of the HMAC computation is already requested.



Description	This function requests the finishing of the HMAC generation and the storing of the sig-
	nature in the given result buffer. The finishing is performed in Cry_HMACGenMain-
	Function().

4.2.3.58. Cry_HMACGenMainFunction

Purpose	Perform the HMAC generation tasks.
Synopsis	<pre>void Cry_HMACGenMainFunction (void);</pre>
Sync/Async	Asynchronous
Reentrancy	Not reentrant
Description	This function performs the actual HMAC generation tasks which have been requested by the service functions. When a task has finished, the function Csm_MacGenerateServiceCallbackNotification() is called to inform the CSM of the result. If the complete HMAC generation has finished, additionally the function Csm_MacGenerateServiceFinishNotification() is called.

4.2.3.59. Cry_HMACGenStart

Purpose	Start HMAC generation.		
Synopsis	Csm_ReturnType Cry_HMACGenStart (const void * cfgPtr , const Csm_SymKeyType * keyPtr);		
Sync/Async	Asynchronous	Asynchronous	
Reentrancy	Not reentrant		
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the signature generation should be requested.	
	keyPtr	A pointer to the key which should be used in the signature generation.	
Return Value	Error code		
	CSM_E_OK	If the start was successfully requested.	
	CSM_E_BUSY	If a service of the HMAC generation is already running.	
Description	This function requests the start of the HMAC generation for the given configuration and key. The start is performed in Cry_HMACGenMainFunction() .		



4.2.3.60. Cry_HMACGenUpdate

Purpose	Update HMAC generation.		
Synopsis	Csm_ReturnType Cry_HMACGenUpdate (con-		
	st uint8 * dataF	tr , uint32 dataLength);	
Sync/Async	Asynchronous		
Reentrancy	Not reentrant	Not reentrant	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the signature should be created.	
	dataLength	The amount of data in bytes.	
Return Value	Error code		
	CSM_E_OK	If the update was successfully requested.	
	CSM_E_BUSY	If the main function is processing a requested service at the moment.	
	CSM_E_NOT_OK	If no HMAC generation has been started via Cry_HMACGenStart() yet or if the finishing of the HMAC computation is already requested.	
Description	This function requests the update of the HMAC generation for the given data. The update is performed in Cry_HMACGenMainFunction ().		

4.2.3.61. Cry_HMACVrfyFinish

Purpose	Finish HMAC verification.	
Synopsis	Csm_ReturnType Cry_HMACVrfyFinish (const uint8 * authenticationPtr , uint32 authentication- Length , Csm_VerifyResultType * resultPtr);	
Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	authenticationPtr	A pointer to the start of a buffer where the generated signature should be stored.



	authenticationLength	A variable which contains the maximal allowed length for the signature and the actual length of the signature.
Parameters (out)	resultPtr	A pointer to a variable where the result of the HMAC verification will be stored.
Return Value	Error code	
	CSM_E_OK	If the finishing was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no HMAC verification has been started via Cry_HMACVrfyStart() yet, or if the finishing of the HMAC computation is already requested.
Description	This function requests the finishing of the HMAC verification and the storing of the signature in the given buffer. The finishing is performed in Cry_HMACVrfyMainFunction() .	

4.2.3.62. Cry_HMACVrfyMainFunction

Purpose	Perform the HMAC verification tasks.
Synopsis	void Cry_HMACVrfyMainFunction (void);
Sync/Async	Asynchronous
Reentrancy	Not reentrant
Description	This function performs the actual HMAC verification tasks which have been requested by the service functions. When a task has finished, the function Csm_MacVerifyServiceCallbackNotification() is called to inform the CSM of the signature. If the complete signature verification has finished, additionally the function Csm_MacVerifyServiceFinishNotification() is called.

4.2.3.63. Cry_HMACVrfyStart

Purpose	Start HMAC verification.
Synopsis	Csm_ReturnType Cry_HMACVrfyStart (const void
	* cfgPtr , const Csm_SymKeyType * keyPtr);



Sync/Async	Asynchronous	
Reentrancy	Not reentrant	
Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the signature verification is requested.
	keyPtr	A pointer to the key which will be used in the HMAC verification.
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of the HMAC verification is already running.
Description	This function requests the start of the HMAC verification for the given configuration and key. The start is performed in Cry_HMACVrfyMainFunction ().	

4.2.3.64. Cry_HMACVrfyUpdate

Purpose	Update HMAC verification.		
Synopsis	<pre>Csm_ReturnType Cry_HMACVrfyUpdate (con- st uint8 * dataPtr , uint32 dataLength);</pre>		
Sync/Async	Asynchronous		
Reentrancy	Not reentrant	Not reentrant	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the signature should be created.	
	dataLength	The amount of data in bytes.	
Return Value	Error code		
	CSM_E_OK	If the update was successfully requested.	
	CSM_E_BUSY	If the main function is processing a requested service at the moment.	
	CSM_E_NOT_OK	If no signature verification has been started via Cry_HMACVrfyStart() , yet or if the finishing of the HMAC computation is already requested.	
Description	This function requests the update of the HMAC verification for the given data. The update is performed in Cry_HMACVrfyMainFunction() .		



4.2.3.65. Cry_KEY_SYM_ExtractFinish

Purpose	Finish KEY_SYM extract computation.	
Synopsis	Csm_ReturnType Cry_KEY_SYM_ExtractFin-	
	ish (Csm_SymKey	Type * keyPtr);
Parameters (out)	keyPtr	A pointer to the structure where to store
		the result.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If no KEY_SYM extract computation has
		been started via Csm_SymKeyExtractS-
		tart(), yet.
	CSM_E_BUSY	If the main function is currently processing
		a requested service.
Description	This function requests the finishing of the KEY_SYM extract computation and the storing of the extracted key data in the given buffer. The finish is performed in Cry_KEY	
	SYM_ExtractMainFunction().	

4.2.3.66. Cry_KEY_SYM_ExtractMainFunction

Purpose	Perform the KEY_SYM extract computation tasks.
Synopsis	<pre>void Cry_KEY_SYM_ExtractMainFunction (void);</pre>
Description	This function performs the actual KEY_SYM extract computation tasks which have been requested by the service functions. The function calls the main function of the configured primitive to perform the tasks.

4.2.3.67. Cry_KEY_SYM_ExtractStart

Purpose	Start KEY_SYM extract computation.	
Synopsis	Csm_ReturnType Cry_KEY_SYM_Extrac-	
	tStart (const void * cfgPtr);	



Parameters (in)	cfgPtr	A pointer to the configuration for which the start of the symmetrical key extraction is requested.
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_NOT_OK	
	CSM_E_BUSY	If a service of the KEY_SYM extract computation is already running.
Description	This function requests the start of the KEY configuration. The start is performed in Cry	

4.2.3.68. Cry_KEY_SYM_ExtractUpdate

Purpose	Update KEY_SYM extract computation.	
Synopsis	Csm_ReturnType Cry_KEY_SYM_ExtractUpdate (con- st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	A pointer to the start of an array which contains the key that have to extract in a CSM-conforming format.
	dataLength	Length of the key in bytes.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If no KEY_SYM extract computation has been started via Csm_SymKeyExtractS-tart(), yet.
	CSM_E_BUSY	If the main function is currently processing a requested service.
Description	This function requests the update of the K data. The update is performed in Cry_KEY	EY_SYM extract computation for the given SYM_ExtractMainFunction() .

4.2.3.69. Cry_MD5AlgorithmId

Purpose Algorithm identifier of MD5 hash algorithm.	
---	--



Synopsis	<pre>const uint8 * Cry_MD5AlgorithmId (const void * cfgPtr , uint32 * AlgorithmIdLengthPtr);</pre>	
Parameters (in)	cfgPtr	a pointer to the configuration for which the algorithm identifier should be returned.
Parameters (out)	AlgorithmIdLengthPtr	a pointer to a variable where the actual length of the algorithm identifier should be stored.
Return Value	AlgorithmId A pointer to the start of a byte array which contains the algorithm identifier.	
Description	This function returns the algorithm identifier of the hash algorithm defined in the given configuration.	

4.2.3.70. Cry_MD5Finish

Purpose	Finish function of the MD5 algorithm.	
Synopsis	<pre>Csm_ReturnType Cry_MD5Finish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean TruncationIsAllowed);</pre>	
Parameters (in)	inout]	resultLengthPtr Holds a pointer to the memory location in where the length information is stored. On calling this function this parameter shall contain the size of the buffer provided by resultPtr. When the request has finished, the actual length of the returned value shall be stored.
	TruncationIsAllowed	This parameter states whether a truncation of the result is allowed or not. TRUE: truncation is allowed. FALSE: truncation is not allowed.
Parameters (in,out)	inout]	resultLengthPtr Holds a pointer to the memory location in where the length information is stored. On calling this function this parameter shall contain the size of the buffer provided by resultPtr. When the request has finished, the actual length of the returned value shall be stored.
Parameters (out)	resultPtr	Holds a pointer to the memory location which will hold the result of the hash value computation. If the result does not fit into



		the given buffer, and truncation is allowed, the result shall be truncated.
Return Value	whether the request was successful	
	CSM_E_OK	request successful
	CSM_E_NOT_OK	request failed
	CSM_E_BUSY	the request failed, the MD5 is busy
	CSM_E_SMALL_BUFFER	the provided buffer is too small to store the result, and truncation was not allowed.

4.2.3.71. Cry_MD5MainFunction

Purpose	
Synopsis	<pre>void Cry_MD5MainFunction (void);</pre>

4.2.3.72. Cry_MD5Start

Purpose	Init function of the MD5 algorithm.	
Synopsis	Csm_ReturnType Cry_MD5Start (const void * cfgPtr);	
Parameters (in)	cfgPtr	Pointer to a Cry MD5 Configuration
Return Value	whether the initialization of the MD5 algorithm was successful	
	CSM_E_OK	the initialization of the MD5 algorithm was successful
	CSM_E_NOT_OK	the initialization of the MD5 algorithm was failed
	CSM_E_BUSY	the initialization failed, the MD5 is busy

4.2.3.73. Cry_MD5Update

Purpose	Update function of the MD5 algorithm.	
Synopsis	Csm_ReturnType Cry_MD5Update (con-	
	st uint8 * dataPtr ,	uint32 dataLength);
Parameters (in)	dataPtr Holds a pointer to the data to be hashed	
	dataLength	Contains the number of bytes to be hashed.



Return Value	whether the request was success	whether the request was successful	
	CSM_E_OK	request successful	
	CSM_E_NOT_OK	request failed	
	CSM_E_BUSY	the request failed, the MD5 is busy	

4.2.3.74. Cry_RsaSsaPssVerifyFinish

Purpose	Finish signature verification.	
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaPssVerifyFinish (con- st uint8 * signaturePtr , uint32 signature- Length , Csm_VerifyResultType * resultPtr);</pre>	
Parameters (in)	signaturePtr	a pointer to the start of a buffer which holds the signature.
	signatureLength	Length of the signature in bytes.
Parameters (out)	resultPtr	Verification result.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no signature verification has been started via Cry_RsaSsaPssVerifyStart() , yet.
Description	This function requests the finishing of the RSASSA-PSS signature verification and the storing of the signature in the given signature buffer. The finishing is performed in Cry_RsaSsaPssVerifyMainFunction ().	

4.2.3.75. Cry_RsaSsaPssVerifyMainFunction

Purpose	Perform the RSASSA-PSS-Verify tasks.
Synopsis	<pre>void Cry_RsaSsaPssVerifyMainFunction (void);</pre>
Description	This function performs the actual RSASSA-PSS signature verification tasks which have been requested by the service functions. When a task has finished, the function Csm_SignatureVerifyServiceCallbackNotification() is called to inform the CSM of the signature. If the complete signature verification has finished, additionally the function Csm_SignatureVerifyServiceFinishNotification() is called.



4.2.3.76. Cry_RsaSsaPssVerifyStart

Purpose	Start signature verification.		
Synopsis	_	<pre>Csm_ReturnType Cry_RsaSsaPssVerifyStart (const void * cfgPtr , const Csm_AsymPublicKeyType * keyPtr);</pre>	
Parameters (in)	cfgPtr	a pointer to the configuration for which the start of the signature verification should be requested.	
	keyPtr	a pointer to the key which should be used in the signature verification.	
Return Value	Error code		
	CSM_E_OK	If the update was successfully requested.	
	CSM_E_BUSY	If a service of the RSASSA-PSS signature verification is already running.	
Description	·	RSASSA-PSS signature verification for the giverformed in Cry_RsaSsaPssVerifyMainFunc-	

4.2.3.77. Cry_RsaSsaPssVerifyUpdate

Purpose	Update signature verification.	
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaPssVerifyUpdate (con- st uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)	dataPtr	a pointer to the start of an array which contains a part of the data for which the signature should be created.
	dataLength	The amount of bytes of data.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no signature verification has been started via Cry_SigPKCS1VrfyStart(), yet.
Description	This function requests the update of the RSASSA-PSS signature verification for the given data. The update is performed in Cry_SigPKCS1VrfyMainFunction().	



4.2.3.78. Cry_RsaSsaV15GenFinish

Purpose	
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaV15GenFinish (uint8 * resultPtr , uint32 * resultLengthPtr);</pre>
Return Value	

4.2.3.79. Cry_RsaSsaV15GenMainFunction

Purpose		
Synopsis	<pre>void Cry_RsaSsaV15GenMainFunction (void);</pre>	

4.2.3.80. Cry_RsaSsaV15GenStart

Purpose	
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaV15GenStart (const void * cfgPtr , const Csm_AsymPrivateKeyType * keyPtr);</pre>
Return Value	

4.2.3.81. Cry_RsaSsaV15GenUpdate

Purpose		
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaV15GenUpdate (con- st uint8 * dataPtr , uint32 dataLength);</pre>	
Return Value		

4.2.3.82. Cry_RsaSsaV15VerifyFinish

Purpose	Finish signature verification.
---------	--------------------------------



Synopsis	<pre>Csm_ReturnType Cry_RsaSsaV15VerifyFinish (con- st uint8 * signaturePtr , uint32 signature- Length , Csm VerifyResultType * resultPtr);</pre>	
Parameters (in) signaturePtr a pointer to the sta		a pointer to the start of a buffer which holds the signature.
	signatureLength	Length of the signature in bytes.
Parameters (out)	resultPtr	Verification result.
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no signature verification has been started via Cry_SigPKCS1VrfyStart(), yet.
Description	This function requests the finishing of the RSASSA-PKCS1-v1_5 signature verification and the storing of the signature in the given signature buffer. The finishing is performed in Cry_SigPKCS1VrfyMainFunction().	

4.2.3.83. Cry_RsaSsaV15VerifyMainFunction

Purpose	Perform the RSASSA-PKCS1-v1_5 verification tasks.
Synopsis	<pre>void Cry_RsaSsaV15VerifyMainFunction (void);</pre>
Description	This function performs the actual RSASSA-PKCS1-v1_5 signature verification tasks which have been requested by the service functions. When a task has finished, the function Csm_SignatureVerifyServiceCallbackNotification() is called to inform the CSM of the signature. If the complete signature verification has finished, additionally the function Csm_SignatureVerifyServiceFinishNotification() is called.

4.2.3.84. Cry_RsaSsaV15VerifyStart

Purpose	Start signature verification.	
Synopsis	<pre>Csm_ReturnType Cry_RsaSsaV15VerifyStart (const void * cfgPtr , const Csm_AsymPublicKeyType * keyPtr);</pre>	
Parameters (in)	cfgPtr	a pointer to the configuration for which the start of the signature verification should be requested.



	keyPtr	a pointer to the key which should be used in the signature verification.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If a service of the RSASSA-PKCS1-v1_5 signature verification is already running.
Description	This function requests the start of the RSASSA-PKCS1-v1_5 signature verification for the given configuration and key. The start is performed in Cry RsaSsaV15VerifyMainFunction() .	

${\bf 4.2.3.85.} \ Cry_RsaSsaV15 Verify Update$

Purpose	Update signature verification.	
Synopsis	Csm_ReturnType Cry_RsaSsaV15VerifyUpdate (con- st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	a pointer to the start of an array which contains a part of the data for which the signature should be created.
	dataLength	The amount of bytes of data.
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment.
	CSM_E_NOT_OK	If no signature verification has been started via Cry_SigPKCS1VrfyStart(), yet.
Description	This function requests the update of the RSASSA-PKCS1-v1_5 signature verification for the given data. The update is performed in Cry_SigPKCS1VrfyMainFunction().	

4.2.3.86. Cry_SHA1Algorithmld

Purpose	Algorithm identifier of hash algorithm.	
Synopsis	const uint8 * Cry_SHA1AlgorithmId (const void	
	<pre>* cfgPtr , uint32 * AlgorithmIdLengthPtr);</pre>	



Parameters (in)	cfgPtr	an pointer to the configuration for which the algorithm identifier should be returned
Parameters (out)	AlgorithmIdLengthPtr	a pointer to a variable where the actual length of the algorithm identifier should be stored
Return Value	Algorithm Id	
Description	This function returns the algorithm identifier of the hash algorithm defined in the given configuration. See RFC 3279 for examples	

4.2.3.87. Cry_SHA1Finish

Purpose	Finish SHA1 computation.	
Synopsis	<pre>Csm_ReturnType Cry_SHA1Finish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean truncationAllowed);</pre>	
Parameters (in)	truncationAllowed	If this flag is TRUE and the hash digest is longer than the given result buffer, the hash is truncated to the buffer length. If this flag is FALSE and the hash digest is longer than the given result buffer, an error code of CSM_E_SMALL_BUFFER is returned
Parameters (in,out)	resultLengthPtr	a pointer to a variable which contains the maximal allowed length in bytes for the hash and where the actual length in bytes of the hash should be stored
Parameters (out)	resultPtr	Pointer to the start of a buffer where the hash digest should be stored
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	If no SHA computation has been started via Cry_SHA1Start() , yet.
Description	This function requests the finishing of the SHA computation and the storing of the hash digest in the given result buffer. The finishing is performed in Cry SHA1MainFunction() .	



4.2.3.88. Cry_SHA1MainFunction

Purpose	Perform the SHA1 tasks.
Synopsis	void Cry_SHA1MainFunction (void);
Description	This function performs the actual SHA computation tasks which have been requested by the service functions. When a task has finished, the function Csm_HashService-CallbackNotification() is called to inform the CSM of the result. If the complete SHA1 computation has finished, additionally the function Csm_HashServiceFinishNotification() is called.

4.2.3.89. Cry_SHA1Start

Purpose	Start SHA1 computation.	
Synopsis	Csm_ReturnType Cry_SHA1Start (const void * cfgPtr);	
Parameters (in)	A pointer to the configuration for which the start of the SHA computation should be requested.	
Return Value Error code		
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of the SHA computation is already running
Description	This function requests the start of the SHA computation for the given configuration. The start is performed in Cry_SHA1MainFunction()	

4.2.3.90. Cry_SHA1Update

Purpose	Update SHA1 computation.	
Synopsis	<pre>Csm_ReturnType Cry_SHA1Update (con- st uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the SHA digest should be created.
	dataLength	The amount of bytes of data
Return Value	rn Value Error code	
	CSM_E_OK	If the update was successfully requested.



		If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	If no SHA computation has been started via Cry_SHA1Start() , yet.
Description	This function requests the update of the SHA computation for the given data. The update is performed in Cry_SHA1MainFunction() .	

4.2.3.91. Cry_SHA2Algorithmld

Purpose	Algorithm identifier of hash algorithm.	
Synopsis	<pre>const uint8 * Cry_SHA2AlgorithmId (const void * cfgPtr , uint32 * AlgorithmIdLengthPtr);</pre>	
Parameters (in)	an pointer to the configuration for which the algorithm identifier should be returned	
Parameters (out)	AlgorithmIdLengthPtr	a pointer to a variable where the actual length of the algorithm identifier should be stored
Return Value	Algorithm Id	
Description	This function returns the algorithm identifier of the hash algorithm defined in the given configuration. See RFC 3279 for examples	

4.2.3.92. Cry_SHA2Finish

Purpose	Finish SHA2 computation.	
Synopsis	<pre>Csm_ReturnType Cry_SHA2Finish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean truncationAllowed);</pre>	
Parameters (in)	truncationAllowed	If this flag is TRUE and the hash digest is longer than the given result buffer, the hash is truncated to the buffer length. If this flag is FALSE and the hash digest is longer than the given result buffer, an error code of CSM_E_SMALL_BUFFER is returned
Parameters (in,out)	resultLengthPtr	a pointer to a variable which contains the maximal allowed length in bytes for the



		hash and where the actual length in bytes of the hash should be stored
Parameters (out)	resultPtr	Pointer to the start of a buffer where the hash digest should be stored
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	If no SHA computation has been started via Cry_SHA2Start(), yet.
Description	This function requests the finishing of the SHA computation and the storing of the hash digest in the given result buffer. The finishing is performed in CrySHA2MainFunction() .	

4.2.3.93. Cry_SHA2MainFunction

Purpose	Perform the SHA2 tasks.	
Synopsis	void Cry_SHA2MainFunction (void);	
Description	This function performs the actual SHA computation tasks which have been requested by the service functions. When a task has finished, the function Csm_HashService-CallbackNotification() is called to inform the CSM of the result. If the complete SHA2 computation has finished, additionally the function Csm_HashServiceFinishNotification() is called.	

4.2.3.94. Cry_SHA2Start

Purpose	Start SHA2 computation.	
Synopsis	Csm_ReturnType Cry_SHA2Start (const void * cfgPtr);	
Parameters (in)	A pointer to the configuration for which the start of the SHA computation should be requested.	
Return Value	Error code	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of the SHA computation is already running



Description	This function requests the start of the SHA computation for the given configuration.
	The start is performed in Cry_SHA2MainFunction())

4.2.3.95. Cry_SHA2Update

Purpose	Update SHA2 computation.	
Synopsis	<pre>Csm_ReturnType Cry_SHA2Update (con- st uint8 * dataPtr , uint32 dataLength);</pre>	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the SHA digest should be created.
	dataLength	The amount of bytes of data
Return Value Error code		
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	If no SHA computation has been started via Cry_SHA2Start(), yet.
Description	This function requests the update of the SHA computation for the given data. The update is performed in Cry_SHA2MainFunction()).	

4.2.3.96. Cry_SHA3Algorithmld

Purpose	Algorithm identifier of hash algorithm.	
Synopsis	<pre>const uint8 * Cry_SHA3AlgorithmId (const void * ConfigPtr , uint32 * AlgorithmIdLengthPtr);</pre>	
Parameters (in)	ConfigPtr	an pointer to the configuration for which the algorithm identifier should be returned
Parameters (out)	AlgorithmIdLengthPtr	a pointer to a variable where the actual length of the algorithm identifier should be stored
Return Value	Algorithm Id	
Description	This function returns the algorithm identifier of the hash algorithm defined in the given configuration. See RFC 3279 for examples	



4.2.3.97. Cry_SHA3Finish

Purpose	Finish SHA3 computation.	
Synopsis	Csm_ReturnType Cry_SHA3Finish (uint8 * resultPtr , uint32 * resultLengthPtr , boolean truncationAllowed);	
Parameters (in)	truncationAllowed	If this flag is TRUE and the hash digest is longer than the given result buffer, the hash is truncated to the buffer length. If this flag is FALSE and the hash digest is longer than the given result buffer, an error code of CSM_E_SMALL_BUFFER is returned
Parameters (in,out)	resultLengthPtr	a pointer to a variable which contains the maximal allowed length in bytes for the hash and where the actual length in bytes of the hash should be stored
Parameters (out)	resultPtr	Pointer to the start of a buffer where the hash digest should be stored
Return Value	Error code	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	If no SHA computation has been started via Cry_SHA3Start() , yet.
Description	This function requests the finishing of the SHA computation and the storing of the hash digest in the given result buffer. The finishing is performed in Cry - SHA3MainFunction ().	

4.2.3.98. Cry_SHA3MainFunction

Purpose	Perform the SHA3 tasks.	
Synopsis	void Cry_SHA3MainFunction (void);	
Description	This function performs the actual SHA computation tasks which have been requested by the service functions. When a task has finished, the function Csm_HashService-CallbackNotification() is called to inform the CSM of the result. If the complete SHA3	



	computation has finished, additionally the function Csm_HashServiceFinishNotifica-
	tion() is called.

4.2.3.99. Cry_SHA3Start

Purpose	Start SHA3 computation.	
Synopsis	<pre>Csm_ReturnType Cry_SHA3Start (const void * ConfigPtr);</pre>	
Parameters (in)	ConfigPtr A pointer to the configuration for which the start of the SHA computation should be requested.	
Return Value Error code		
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of the SHA computation is already running
Description	This function requests the start of the SHA computation for the given configuration. The start is performed in Cry_SHA3MainFunction ()	

4.2.3.100. Cry_SHA3Update

Purpose	Update SHA3 computation.	
Synopsis	Csm_ReturnType Cry_SHA3Update (con- st uint8 * dataPtr , uint32 dataLength);	
Parameters (in)	dataPtr	A pointer to the start of an array which contains a part of the data for which the SHA digest should be created.
	dataLength	The amount of bytes of data
Return Value	Error code	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_BUSY	If the main function is processing a requested service at the moment
	CSM_E_NOT_OK	On invalid input (dataLength != 0 && NULL_PTR == dataLength) or if the SHA3 computation is in the idle state
Description	This function requests the update of the SHA computation for the given data. The update is performed in Cry_SHA3MainFunction()).	



4.2.3.101. Cry_SSGGenerate

Purpose	Generate pseudo random bytes.	
Synopsis	<pre>Csm_ReturnType Cry_SSGGenerate (const void * cfg- Ptr , uint8 * resultPtr , uint32 resultLength);</pre>	
Parameters (in)	cfgPtr	A pointer to the configuration which should be used in the pseudo random byte generation. This configuration contains, among others, a pointer to the state which should be used for the generation.
Parameters (out)	resultPtr	A pointer to the start of a buffer where the generated pseudo random bytes should be stored
	resultLength	Holds the amount of bytes which should be generated
Return Value	Generation operation state	
	CSM_E_OK	If the byte generation was successfully requested
	CSM_E_BUSY	If another service of the SSG is already running
Description	This function requests the generation of pseudo random bytes. The byte generation is performed in Cry_SSGMainFunction()	

4.2.3.102. Cry_SSGGenerateMainFunction

Purpose	This function performs the actual SSG tasks which have been requested by the service functions. When a task has finished, the function Csm_RandomCallbackNotifica-	
	tion() is called to inform the CSM of the result.	
Synopsis	<pre>void Cry_SSGGenerateMainFunction (void);</pre>	

4.2.3.103. Cry_SSGSeedFinish

Purpose	This function requests the finishing of the seeding of the SSG. The finishing of the	
	seeding is performed in Cry_SSGMainFunction().	



Synopsis	Csm_ReturnType Cry_SSGSeedFinish (void);	
Return Value	Request result	
	CSM_E_OK	If the finish was successfully requested.
	CSM_E_NOT_OK	If there was an error
	CSM_E_BUSY	If the SSGSeed Service computation is already running.

4.2.3.104. Cry_SSGSeedMainFunction

	This function performs the actual SSG tasks which have been requested by the service functions. When a task has finished, the function Csm_RandomCallbackNotification() is called to inform the CSM of the result.
Synopsis	<pre>void Cry_SSGSeedMainFunction (void);</pre>

4.2.3.105. Cry_SSGSeedStart

Purpose	This function requests the initialization of the SSG state which has been given with the passed configuration pointer. The initialization is performed in Cry_SSGMainFunction().	
Synopsis	<pre>Csm_ReturnType Cry_SSGSeedStart (const void * cfgPtr);</pre>	
Parameters (in)	cfgPtr	Pointer to the configuration which should be used in the state initialization. This configuration contains, among others, a pointer to the state which should be initialized.
Return Value	Request result	
	CSM_E_OK	If the start was successfully requested.
	CSM_E_BUSY	If a service of SSGSeed is already running.

4.2.3.106. Cry_SSGSeedUpdate

Purpose	This function requests the seeding of the SSG state which has been given with the	
	passed configuration pointer. The seeding is performed in Cry_SSGMainFunction().	



Synopsis	<pre>Csm_ReturnType Cry_SSGSeedUpdate (con- st uint8 * seedPtr , uint32 seedLength);</pre>	
Parameters (in)	seedPtr	Pointer to the start of an array which contains the seed.
	seedLength	The length of the seed in byte
Return Value	Rquest result	
	CSM_E_OK	If the update was successfully requested.
	CSM_E_NOT_OK	If there was an error
	CSM_E_BUSY	If the SSGSeed Service computation is already running.

4.3. Integration notes

4.3.1. Integration requirements

WARNING

Integration requirements list is not exhaustive



The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

Integration requirements are not listed for the Cry module.