




Pre-Amp Stage




LOGIC LEVEL SHIFTER 3.3V










TFT_SCREEN




LMC835N




Gyrators(63Hz – 16Khz)




ATTENUATED AUDIO SIGNAL




MSGEQ7




Power



TEENSY 4.1 (Microcontroller)



SPEAKER AMP



7-Band Control

