

Brisa Air Purifier AP-200 and AP-400

User Manual, revision 1.1

About this manual

This manual covers two models: the compact AP-200 and the larger AP-400. Read the setup section for your model before first use. Specifications, operating modes and maintenance are described for both models.

Safety instructions

Use the purifier indoors only. Do not use the purifier in bathrooms or other rooms where water may splash on the unit.

Always unplug the purifier before cleaning it or replacing a filter.

Do not cover the air inlet or the air outlet. Do not insert objects into the fan opening.

Keep the power cable away from heat sources. If the cable is damaged, stop using the purifier and contact Brisa support.

Setup: AP-200

Setup of the AP-200 takes about 5 minutes.

Step 1. Remove the purifier from the box and open the back cover.

Step 2. Remove the plastic wrap from the HEPA filter and put the filter back with the arrow pointing towards the unit.

Step 3. Place the AP-200 on a flat surface at least 30 cm away from walls and furniture.

Step 4. Plug in the power cable and press the power button once.

The AP-200 starts in Auto mode. No calibration is needed.

Setup: AP-400

Setup of the AP-400 takes about 15 minutes, including sensor calibration.

Step 1. Remove the purifier from the box and open the front panel.

Step 2. Remove the plastic wrap from both the pre-filter and the HEPA filter, then close the front panel.

Step 3. Place the AP-400 on a flat surface at least 50 cm away from walls and furniture.

Step 4. Plug in the power cable and hold the power button for 3 seconds.

Step 5. Wait for sensor calibration. The air quality ring blinks white for 10 minutes. Do not move the purifier during calibration.

When the ring stops blinking, the AP-400 switches to Auto mode.

Specifications

AP-200

Recommended room size: up to 20 sq m.

Clean air delivery rate (CADR): 150 m³/h.

Noise level: 24 dB in Sleep mode, 48 dB at maximum speed.

Power consumption: 25 W.

Timer options: 1, 4 or 8 hours.

AP-400

Recommended room size: up to 45 sq m.

Clean air delivery rate (CADR): 320 m³/h.

Noise level: 22 dB in Sleep mode, 52 dB at maximum speed.

Power consumption: 45 W.

Timer options: 2, 4, 8 or 12 hours.

Filter (both models)

Both models use an H13 HEPA filter that captures 99.95% of particles of 0.3 microns.

Operating modes

Sleep mode runs the fan at the lowest speed and turns off the display lights.

Auto mode adjusts the fan speed to the air quality measured by the sensor.

Turbo mode runs the fan at maximum speed to clean the room quickly.

All modes can run continuously on both models.

Exception: AP-400 Turbo mode

Exception: on the AP-400, Turbo mode stops automatically after 2 hours of continuous use. Turbo mode cannot be turned on again for 30 minutes. During this pause the AP-400 runs in Auto mode. This limit does not apply to the AP-200.

Maintenance

Pre-filter

Clean the pre-filter every 2 weeks with a vacuum cleaner or a soft brush. The AP-200 does not have a separate pre-filter.

HEPA filter replacement

Replace the HEPA filter of the AP-200 every 6 months.

Replace the HEPA filter of the AP-400 every 6 months.

The filter indicator turns red when the filter needs to be replaced. After replacing the filter, hold the filter button for 5 seconds to reset the indicator.

Do not wash the HEPA filter. Washing damages the filter material.

Support

For help, contact Brisa support at support@brisa-home.example.