



1. SEE SHEET G-0004A FOR GENERAL REMOVALS NOTES.
2. COORDINATE REMOVALS WITH HAZARDOUS MATERIALS REMOVALS SHEETS.
3. REMOVE AND SALVAGE HISTORIC BEADBOARD FROM AREAS THAT WILL BE CONCEALED BY A CEILING SYSTEM FOR LATER PATCHING. FOR BIDDING ASSUME 200 SQUARE FEET OF REMOVING AND REINSTALLING EXISTING BEADBOARD CEILING.

- 1 REMOVE WOOD FRAMED MEZZANINE FLOOR, SEE STRUCTURAL SHEETS.
- 2 REMOVE STUD FRAMED GYPSUM BOARD INTERIOR PARTITION.
- 3 REMOVE WOOD GUARDRAIL SYSTEM.
- 4 REMOVE STAIR STRUCTURE IN ITS ENTIRETY, INCLUDING RAILINGS.
- 5 REMOVE GYPSUM BOARD CEILING.
- 6 REMOVE AND SALVAGE BEADBOARD (ABOVE GYPSUM BOARD CEILING) CEILING FOR PATCHING, SEE GENERAL NOTE 3.
- 7 REMOVE WOODEN LADDER AND FIX ATTIC HATCH IN CLOSED POSITION.
- 8 REMOVE ABANDONED DUCTWORK/EQUIPMENT.
- 9 REMOVE 2x WOOD STORAGE RACK ABOVE CRANE RAIL.

REMOVE FLOOR SYSTEM. SEE STRUCTURAL SHEETS.

REMOVE AND SALVAGE BEAD BOARD CEILING

1/8" = 1' - 0"



A horizontal graphic scale bar with tick marks at 0, 5', 10', 15', and 30 feet. The bar is divided into alternating black and white segments.