

APPENDIX B DEFINITIONS

1. Area of Operation. Areas that are or may be affected by the movement of the load.
2. Blind Areas. Areas involved, or that will be involved in operations where the operator cannot see. These are not just the lift and the set down area, but also where the movement of the equipment or load may subject personnel or material and equipment to risk of injury or damage.
3. Center of Balance (COB). Is a point in which the object in question is balanced with respect to the applied force.
4. Center of Gravity (COG). The central point about which the lifted object is balanced in all directions.
5. Cognizant Supervisor. The supervisor assigning or overseeing personnel involved with the MHE operations, including operators borrowed from a different crew, and shop or code.
6. Cognizant Shop. The lead shop responsible for the material and personnel.
7. Complex Lifts. Lifts that involve a high level of risk and thereby dictate the need to follow special requirements. A lift must be considered complex when conditions warrant the use of measures per of this instruction.
8. Congested Area. An area where safe, unencumbered MHE operations are jeopardized by limited radial clearances due to obstacles or personnel, including, but not limited to burn boundaries, keel blocks, vehicular traffic, overhead clearances (sub-roofs, shelving, staging, overhead roll-up doors, etc.), pallets, manifolds, etc. These areas must be posted with warning signs appropriated by the cognizant organization or project.
9. Extendible and Telescoping Boom Forklifts. These are typically rough terrain forklift trucks with extendible booms, which allow loads to be reached and lifted at various heights and angles (commonly referred to as “zoom booms” or “high reach”).
10. Forklift. A powered industrial truck used to hoist and transport materials by means of steel forks inserted under the load.
11. Forklift Attachments. An adaptation, extension, modification, or device added to the forklift to use for multiple load handling applications, to include lifting of suspended loads in a crane-like manner.
12. Interactive Pre-Lift Brief. A procedure for preventing work injuries and accidents that includes a review of job practice methods, and uncovers hazards and develops recommended safety procedures.
13. Load Center. The COB of the load in the horizontal plane.

5 Apr 22

14. Load-Restraining Devices. Materials common to the trade that are used to secure the load to the MHE, such as chains, binders, wire rope, synthetic fiber ropes, nylon straps, etc. The restraint should be adequate and designed to secure the load in all situations (emergency stop, travel, etc.).
15. Material Handling Equipment (MHE). A powered industrial truck or mechanical equipment used to lift and move materials, goods, and products (i.e., for storage, control, and protection) over short distances. The different types of handling equipment can be classified into four major categories: transport equipment, positioning equipment, unit load formation equipment, and storage equipment. For the purpose of this instruction, this includes covered equipment under the cognizance and control of NNSY.
16. Material Handling Operators. Personnel operating MHE who have successfully completed one or more of the forklift operator licensing courses (category 1, 2, or 3), with a valid state driver's license.
17. MHE Manager. This designation pertains to the official manager in charge of MHE operations conducted within the Controlled Industrial Area of NNSY. The MHE Manager falls under the cognizance of Code 900F.
18. Near Miss. An event where an injury or damage was avoided merely by chance.
19. No Zone. Refers to the blind spot areas around MHE, or the areas where objects are so close to the MHE that the driver's ability to stop or maneuver safely is restricted.
20. Spotters. Personnel who are assigned to assist the operator conduct safe operations. Qualifications may be required.
21. Tandem Lifts. Operations where two or more forklifts work simultaneously to perform a lift.