MAXRACING

DEALER SUPPORT PORTAL

INSTALLATION MANUALS

1125 R

300 SX

300 SX 1. Release the handlebars and remove the risers; 2. Fix the clamp on the bearing box post under the dust cover; 3. Fix the shock absorber base on the table with the screws that come with the kit; 4. Fix the shock absorber on the table (No need to tighten it too much); 5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws; 6. Tighten the tower side screw.

350 EXC F 350 SX F

350 EXC -F / 350 SX -F 1. Release the handlebars and remove the risers; 2. Fix the clamp on the bearing box post under the dust cover; 3. Fix the shock absorber base on the table with the screws that come with the kit; 4. Fix the shock absorber on the table (No need to tighten it too much); 5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws; 6. Tighten the tower side screw.

690 ENDURO

KTM 690 ENDURO 1. Remove the original handlebars and risers; 2. Remove the rubber finish that surrounds the ignition; 3. Attach the base (silver) that comes with the kit to the table; 4. Position the boomerang-shaped piece under the frame tubes and use the larger piece to fix it with the screws that come with the kit, fitting its hole into the ignition; 5. Fix the tower with the screws that come with the kit; 6. Fix the shock absorber to the previously fixed base, fitting the rod slot to the tower pin; 7. Adjust the height of the pin with light taps and tighten the 2 screws on the side of the tower; 8. Replace the handlebars using the risers that come with the kit.

990 ADVENTURE

BANDIT 1200

BANDIT 1200 E 1250 FAT BAR

BANDIT 1200 AND 1250 – FAT BAR 1. Loosen the half-moons that fix the handlebar and remove it; 2. Attach the FAT BAR handlebar using the table and handlebar extenders that come with the kit; 3. Position the piece in the shape of an inverted T and mark the positions of the holes; 4. Drill 2 6 mm holes in the frame's finishing plate; 5. Fix the T-piece with the beam that comes with the kit under the frame's finishing plate; 6. Fix the shock absorber on the table by fitting the rod into the slot in the support (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw); 7. Tighten the side screw.

BANDIT 1200 FAT BAR

BANDIT 1200 FAT BAR 1. Remove the 2 upper half-moons from the riser; 2. Install the stretchers; 3. Fix the base with the screws that come with the kit; 4. Position the piece in the shape of an inverted T and mark the positions of the holes; 5. Drill 2 6 mm holes in the frame's finishing plate; 6. Fix the T-piece with the nuts under the frame's finishing plate; 7. Fix the shock absorber to the base fixed to the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod; 8. Level the pin to the rod with light taps; 9. Tighten the side screws to secure the pin.

BANDIT 1200 S

BANDIT 1200 S 1. Remove the 2 upper half-moons from the riser; 2. Fix the handlebars using the table that comes with the kit; 3. Remove 2 finishes from the holes on the side of the frame; 4. Release the tank and move it away; 5. Position the aluminum nut inside the frame and fix the tower clips in an inverted “T” shape on both sides, without tightening them definitively; 6. Fix the tower in an inverted “T” shape to the clips; 7. Fix the shock absorber on the table (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower; 8. Align the parts fixed to the frame and tighten the screws; 9. Tighten the side screw l to secure the rod and replace the tank.

BANDIT 1250S

BANDIT 1250 2008 2013

BANDIT 1250 FA 2014 2016

BANDIT 600N

BANDIT 650N

BLT C500

BLT C500 1. Position the clamp on the seat post WITHOUT tightening the screws; 2. Remove the 2 upper screws that fix the handlebars; 3. Fix the cup that comes with the kit in this location with the motorcycle screws; 4. Fix the shock absorber on the cup; 5. Align the clamp with the longitudinal axis of the motorcycle so that the shock absorber rod fits into the clamp tower; 6. Tighten all screws.

BRUTALE 800

BRUTALE 800 1. Loosen the crescents that fix the handlebars; 2. Fix the handlebars to the table using the screws that come with the kit; 3. Loosen and remove the 2 screws and washers that fix the tank to the frame; 4. Fix the feet to the frame using the crosspiece for alignment and remove the crosspiece after assembling them; 5. Attach the tower to the feet, ensuring that the recess faces the table; 6. Fix the shock absorber on the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 7. Tighten the tower side screw.

B KING

CBR 1000 RR 2007 A 2016

CBR 1000 RR 1. Loosen the table nut and remove the washer; 2. Fix the cup that comes with the kit with the original nut; To do this, the pipe wrench must be turned to reduce the external diameter to fit inside the cup. 3. Remove the plastic cover from the tank; 4. Disconnect and remove the original shock absorber; 5. Attach the support that comes with the kit using the same fixing points as the original shock absorber; 6. Screw the shock absorber onto the cup installed on the table, fitting the support rod attached to the frame (it is not necessary to tighten it too much); 7. Tighten the side screw. NOTE: To eliminate the original steering damper alarm on the panel after removing it, simply connect one wire to the other.

CBR 500 R 2014 2016

CBR 600 F

CBR 600 F2 F3 F4

CBR 600 RR 2003 2006

CBR 600 RR 2007 A 2016

CBR 600 RR 2007 TO 2016 1. Loosen the table nut and remove the washer; 2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer; 3. Completely remove the original steering damper; 4. Attach the “U” shaped piece to the frame; 5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much); 6. Tighten the screws on the sides to avoid loosening of the rod; 7. Replace the fairings. NOTE: To eliminate the original steering damper alarm on the panel after removing it, simply connect one wire to the other.

CBR 650 F 2015 2016

CBR 650 R

CBR 650 R 1. Loosen the table nut and remove the washer; 2. Fix the cup that comes with the kit using the nut WITHOUT the washer; 3. Fix the clamp on the bearing box, aligning the tower; 4. Install the shock absorber to the cup by fitting the rod to the slot in the tower (DO NOT over-tighten the screws); 5. Tighten the tower side screws.

CBR 900 RR

CBR 929 RR

CBR 954 RR

CBX 250 TWISTER 2002 2014

CB 1000R 2012 2016

CB 1000 NEO CAFE

CB 1000 NEO CAFÉ 1. Remove the original table on the handlebars and reattach it with the base that comes with the kit; 2. Remove the plastic cover that covers the ignition; 3. Move the tank aside to access the ignition assembly; 4. Position the piece in an inverted “U” shape in the space between the ignition and the table; 5. Fix the inverted “U” with the 2 “L” shaped pieces on the round ignition beam; 6. Fix the shock absorber to the base on the handlebars by fitting the shock absorber rod to the inverted “U” pin; 7. Replace the tank; 8. Make a cut in the plastic ignition cover to fit it into the original space.

CB 1000 NEO CAFE■ INGLES

CB 1000 NEO CAFÉ 1. Remove the original to p triple tree on the handle bar and use the yoke which goes with the kit to attach it again; 2. Remove the ignition plastic cover; 3. Move the tank away in order to have access to the ignition set; 4. Place the inverted U -shaped part in the space between the ignition and the yoke; 5. Attach the inverted U -shaped part using the L -shaped parts on the ignition lock; 6. Attach the steering damper on the yoke fitting the steering damper bar to the pin of the U-shaped part; 7. Replace the tank; 8. Cut the ignition plastic cover so that it fits in the original space.

CB 1000 NEO CAFE■ INGLES 1

CB 1000 NEO CAFÉ 1. Remove the original to p triple tree on the handle bar and use the yoke which goes with the kit to attach it again; 2. Remove the ignition plastic cover; 3. Move the tank away in order to have access to the ignition set; 4. Place the inverted U -shaped part in the space between the ignition and the yoke; 5. Attach the inverted U -shaped part using the L -shaped parts on the ignition lock; 6. Attach the steering damper on the yoke fitting the steering damper bar to the pin of the U-shaped part; 7. Replace the tank; 8. Cut the ignition plastic cover so that it fits in the original space.

CB 1000 R INGLES

CB 1000 R 1. Remove the yoke that fastens the handle bar and fasten it again with the yoke that goes along with the kit; 2. Release the scre ws that attach the handle bar by removing the washers; 3. Use the inverted “T-shaped “ mounting bracket to attach the tank back with the screws that go along with the kit; 4. Fasten the steering damper on the yoke previously attached on the handle bar fitt ing the bar to the to wer pin; 5. Level the pin with light beats; 6. Tighten the tower side screw.

CB 1000 R INGLES 1

CB 1000 R 1. Remove the yoke that fastens the handle bar and fasten it again with the yoke that goes along with the kit; 2. Release the scre ws that attach the handle bar by removing the washers; 3. Use the inverted “T-shaped “ mounting bracket to attach the tank back with the screws that go along with the kit; 4. Fasten the steering damper on the yoke previously attached on the handle bar fitt ing the bar to the to wer pin; 5. Level the pin with light beats; 6. Tighten the tower side screw.

CB 1300 SF

CB 300R 2009 2015

CB 500F 2014 2016

CB 500X 2014 2016

CB 500X ATE■ 2019

CB 500 1998 2005

CB 500 - 1998/200 5 1. Release the handlebars; 2. Attach the table that comes with the kit to the handlebars; 3. Move the tank away; 4. Fix the base of the support to the frame. To do this, remove the screw that fixes the plate and also remove the nut; 5. Attach the tower to the base previously fixed to the frame so that the tower's chamfers face the handlebars; 6. Replace the tank; 7. Fix the shock absorber to the table fixed over the handlebars and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 8. Tighten the tower side screw

CB 500 2020 EM DIANTE

CB 500 – 2020 ONwards 1. Release the handlebars; 2. Loosen the central nut and remove the washer; 3. Fix the cup to the central screw of the table using the original nut and washer; 4. Loosen the screws that fix the tank to the frame; 5. Fix the inverted T-shaped tower using the screws that come with the kit; 6. Fix the shock absorber on the cup (it is not necessary to tighten it too much), fitting the rod to the slot in the tower, and tighten the screw on the side of the tower; 7. Replace the handlebar using the shims that come with the handlebar raising kit.

CB 600 F HORNET 2005 2007 ATUAL

HORNET 2005 -2007 1. Remove the bushings that fix the handlebars; 2. Fix the handlebars with the table that comes with the kit; 3. Move the tank away to access the panel (it is not necessary to remove the tank); 4. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit; 5. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

CB 600 F HORNET 2005 2007 NOVO FAT BAR

HORNET 2005 -2007 – FAT BAR 1. Remove the bushings that fix the handlebar and remove it; 2. Fix the risers (handlebar extenders) 3. Fix the handlebars over the risers with the table that comes with the kit; 4. Move the tank aside to access the panel (it is not necessary to remove the tank); 5. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit; 6. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

CB 600 F HORNET 2008 2014

CB 600 F HORNET 2008 2014 FAT BAR

CB 600 F HORNET 2008 2014 INGLES

HORNET 1. Release the half-moon shape d mounting brackets that fasten the handle bar; 2. Fasten the handle bar with the yoke which goes along with the kit; 3. Release and remove the 2 screws and the washers that fasten the tank to the frame; 4. Use the inverted “T”- shape d mounting bracket to attach the tank back with the screws which go along with the kit; -Fasten the steering damper on the yoke previously usly attached on the handle bar fittin g the bar to the tower opening (it’s not necessary to tight fastening) , -Tighten the tower side screw .

CB 600 F HORNET 2008 2014 INGLES 1

HORNET 1. Release the half-moon shape d mounting brackets that fasten the handle bar; 2. Fasten the handle bar with the yoke which goes along with the kit; 3. Release and remove the 2 screws and the washers that fasten the tank to the frame; 4. Use the inverted “T”- shape d mounting bracket to attach the tank back with the screws which go along with the kit; -Fasten the steering damper on the yoke previously usly attached on the handle bar fittin g the bar to the tower opening (it’s not necessary to tight fastening) , -Tighten the tower side screw .

CB 650 F 2015 2016

CB 650 F FAT BAR

CB 650 F Fat Bar 1. Release the handlebars; 2. Remove the original risers; 3. Remove the table, loosen the bearing nut and remove the bearing cover; 4. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently; 5. Replace the bearing cover, adjusting nut and adjust the bearing clearance; 6. Replace the table and tighten; 7. Place the risers that come with the kit; 8. Reattach the handlebars to the base that comes with the kit using the M8x 30 screws; 9. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower; 10. Position the clamp definitively and tighten the screws; 11. Tighten the tower side screw.

CB 650 R

CB 650 R 1. Remove the original table on the handlebars and reattach it with the base that comes with the kit; 2. Remove the plastic cover that covers the ignition; 3. Move the tank aside to access the ignition assembly; 4. Position the piece in an inverted “U” shape in the space between the ignition and the table; 5. Attach the inverted “U” with the 2 “L” shaped pieces to the round ignition beam, 6. Attach the shock absorber to the base on the handlebars, fitting the shock absorber rod to the inverted “U” pin; 7. Replace the tank; 8. Make a cut in the plastic ignition cover to fit it into the original space.

CB TWISTER 2015 2016

CG 150

CG 160 START

CG 160 START 1. Release the handlebars; 2. Remove the table and loosen the bearing nut and remove the bearing cover; 3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently; 4. Replace the bearing cover, adjusting nut and adjust the bearing clearance; 5. Replace the table and tighten; 6. Reattach the handlebars to the base that comes with the kit using the M8x 25 screws; 7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower; 8. Position the clamp definitively and tighten the screws; 9. Tighten the tower side screw.

COMET GTR 250

COMET GTR 650

COMET GT 250 NAKED

COMET GT 650 NAKED

CRF 1000 L AFRICA TWIN

CRF 1000 L - AFRICA TWIN 1. Loosen the crescents that fix the handlebars; 2. Remove the handlebars to access the central nut of the table; 3. Remove the central nut; 4. Secure the cup that comes with the kit with the original nut; 5. Remove the screw that fixes the tank to the frame; 6. Fix the tower to the frame in such a way that the slots in the tower fit the plastic tabs on the tank support; 7. Fix the shock absorber to the cup by fitting the rod into the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 8. Tighten the tower side screw; Replace the handlebars.

CRF 250

CRF 250 1. Release the handlebars and remove the original risers; 2. Remove the table; 3. Position the clamp WITHOUT final tightening; 4. Replace the table; 5. Fix the base that comes with the kit on the table; 6. Fix the shock absorber on the table by fitting its rod into the previously installed clamp tower (no excessive tightening is necessary); 7. Align the clamp and definitively tighten the screw on the clamp and on the side of the tower; 8. Attach the risers that come with the kit and replace the handlebars.

CRF AFRICA TWIN1100

CRF 1100 – AFRICA TWIN 1. Loosen the half-moons that fix the handlebars; 2. Remove the handlebars to access the central nut of the table; 3. Remove the central nut; 4. Secure the cup that comes with the kit with the original nut; 5. Remove the screw that fixes the tank to the frame; 6. Fix the tower to the frame so that the slots in the tower fit into the plastic tabs on the tank support; 7. Attach the shock absorber to the cup by fitting the rod to the tower pin; 8. Adjust the height of the pin until it is flush with the rod (this pin is movable), tapping the top of it lightly.

DAYTONA 675R 2013 2016

DAYTONA 675 2008 2012

DAYTONA 955

DL 1000 V STROM 2003 2014

DL 1000 V STROM 2015 2016

DL 650 V STROM 2008 2014

DRZ 400 E

DRZ 400 E 1. Release the handlebars; 2. Attach the cup that comes with the kit to the central nut WITHOUT the washer; 3. Fix the clamp on the steering gear; 4. Place the risers that come with the kit in order to raise the handlebars; 5. Fix the shock absorber on the cup by fitting the pin into the groove in the rod (excessive tightening is not necessary); 6. Adjust the height of the pin until it is flush with the rod (the pin is movable), tapping the top of it lightly.

DUCATI 959

DUCATI 959 1. Release the table; 2. Replace the original central nut with the nut that comes with the kit; 3. Fix the cup to the nut by tightening the side screws; 4. Remove the screws that secure the plastic cover around the ignition; 5. Fix the 2 threaded bushings that come with the kit in place; 6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much); 7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot; 8. Tighten the boomerang side screw.

DUCATI V4

DUCATI V4 1. Release the table; 2. Replace the original central nut with the nut that comes with the kit; 3. Fix the cup to the nut by tightening the side screws; 4. Remove the screws that secure the plastic cover around the ignition; 5. Fix the 2 threaded bushings that come with the kit in place; 6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much); 7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot; 8. Tighten the boomerang side screw.

DYNA GLIDE

DYNA GLIDE 1. Loosen the central nut of the table and remove the washer; 2. Attach the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer; 3. Remove the screw and washer that fix the tank and place the support in the shape of an inverted “T” with the screw that comes with the kit, observing that the support's inclination must be towards the table; 4. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (excessive tightening is not necessary); 5. Tighten the side screw of the tower fixed to the frame.

DYNA GLIDE EM INGLES

DYNA GLIDE 1. Loosen the screw nut of the top triple tree and remove the washer; 2. Attach the cup-shaped part to the center screw of the top triple tree using the screw nut that goes along with the kit WITHOUT the washer; 3. Remove the screw and washer that secures the tank and place the inverted "T"-shaped part with the screw that goes along with the kit, observing that the angle of the inc lination must be directed towards the top triple tree; 4. Fasten the damper over the cup -shaped part by fitting the bar of the damper into the holder opening of the “T” bracket (it is not necessary too much fastening); 5. Tighten the “T” tower side screw.

DYNA GLIDE EM INGLES 1

DYNA GLIDE 1. Loosen the screw nut of the top triple tree and remove the washer; 2. Attach the cup-shaped part to the center screw of the top triple tree using the screw nut that goes along with the kit WITHOUT the washer; 3. Remove the screw and washer that secures the tank and place the inverted "T"-shaped part with the screw that goes along with the kit, observing that the angle of the inc lination must be directed towards the top triple tree; 4. Fasten the damper over the cup -shaped part by fitting the bar of the damper into the holder opening of the “T” bracket (it is not necessary too much fastening); 5. Tighten the “T” tower side screw.

ER6N VARETA

ER6N (DIPSTICK MODEL) 1. Remove the plastic cover from the tank; 2. Remove the screws that secure the ignition; 3. Attach the boomerang-shaped support to the ignition; 4. Attach the “L” shaped support to the front brake hose; 5. Fix the shock absorber rod on the “L” shaped support; 6. Position the shock absorber inside the clamp in such a way that it does not prevent the handlebars from fully steering on both sides; 7. Tighten the clamp screws; 8. Cut the plastic tank cover to fit it back onto the motorcycle; 9. Replace the plastic tank cover.

ER 6N 2010 2012

EXC 250 EXC 350 EXC 450

EXC 250/ EXC 350/ EXC 450 1. Release the handlebars and remove the risers; 2. Fix the clamp on the bearing box post under the dust cover; 3. Fix the shock absorber base on the table with the screws that come with the kit; 4. Fix the shock absorber on the table (No need to tighten it too much); 5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws; 6. Tighten the tower side screw.

F3

FACTOR 125

FACTOR 125 1. Release the handlebars; 2. Remove the table and loosen the bearing nut and remove the bearing cover; 3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently; 4. Replace the bearing cover, adjusting nut and adjust the bearing clearance; 5. Replace the table and tighten; 6. Reattach the handlebars to the base that comes with the kit using the M8x 25 screws; 7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower; 8. Position the clamp definitively and tighten the screws; 9. Tighten the tower side screw.

FACTOR 150

FAZER 1000

FAZER 150

FAZER 250 2018 NORMAL E FAT BAR

FAZER 250 - 2018 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original nut WITHOUT the washer; 4. Move the tank away; 5. Fix the support to the frame by positioning the cross member through the frame; 6. Replace the tank; 7. Fix the shock absorber to the cup by fitting the rod into the slot in the tower (it is not necessary to tighten it too much); 8. Tighten the tower side screw; 9. Replace the handlebar using the stretchers that come with the kit.

FAZER 250 FAT BAR 2008 2016

FAZER 600 2007 2009

FC 450

FC 450 1. Release the handlebars and remove the risers; 2. Fix the clamp on the bearing box post under the dust cover; 3. Fix the shock absorber base on the table with the screws that come with the kit; 4. Fix the shock absorber on the table (No need to tighten it too much); 5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws; 6. Tighten the tower side screw.

F 650 GS TWIN ATE■ 2010

F 800 GS

GLADIUS

GLADIUS 1. Loosen the crescents that fix the handlebars; 2. Fix the handlebars to the base using the screws that come with the kit; 3. Loosen and remove the 2 screws and washers that fix the tank to the frame; 4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit; 5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient); 6. Tighten the side screw.

GSR 750 A 2011 2016

GSR 750 A ZA FAT BAR

GSR 750 A /ZA – FAT BAR 1. Loosen the half-moons that fix the handlebar; 2. Fix the risers (handlebar extenders) 3. Fix the handlebars over the risers with the table that comes with the kit; 4. Loosen the longest screw on the inverted fork-shaped support that comes with the kit; 5. Position this support in front of the plastic tank cover above the ignition assembly; 6. Replace the longer screw in its original place, but do not tighten it; 7. Tighten the smaller screw and only then tighten the larger screw; 8. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 9. Tighten the side screw.

GSR 750 A ZA INGLES

GSR 750 A / ZA 1. Release the hal f-moon shaped pair that fasten the handle bar; 2. Attach the handle bar with the yoke that goes along with the kit using the motorcycle original screws; 3. Release the longest screw of the inverte d fork -shaped mounting bracket of the kit; 4. Place the inverted d fork-shaped mounting bracket in front of the plastic cover of the ignition set; 5. Replace the longest screw at its original place, however, do not fasten it yet; 6. Fasten the shortest screw and ONLY THEN fasten the longest screw; 7. Fasten the steering damper on the yoke which was previously usly attached to the handle bar fittin g the bar to the tower opening (it’s not necessary too tight fastening); 8. Tighten the tower side screw.

GSR 750 A ZA INGLES 1

GSR 750 A / ZA 1. Release the hal f-moon shaped pair that fasten the handle bar; 2. Attach the handle bar with the yoke that goes along with the kit using the motorcycle original screws; 3. Release the longest screw of the inverte d fork -shaped mounting bracket of the kit; 4. Place the inverted d fork-shaped mounting bracket in front of the plastic cover of the ignition set; 5. Replace the longest screw at its original place, however, do not fasten it yet; 6. Fasten the shortest screw and ONLY THEN fasten the longest screw; 7. Fasten the steering damper on the yoke which was previously usly attached to the handle bar fittin g the bar to the tower opening (it’s not necessary too tight fastening); 8. Tighten the tower side screw.

GSR 750 ZA 2011 2016

GSX 1000 R SRAD 2000 2007

GSX 1000 R SRAD 2008 2010

GSX 1000 R SRAD 2011 2017

GSX 650 F 2011 2013

GSX 750 R SRAD 1998 2007

GSX 750 R SRAD 2011 2014

GSX 750 R SRAD 2015 2016

GSX 750 SRAD 2008 2010

GSX 750 S 2018 INGLES

GSX 750 S 2018 / 2020 1. Release the parts that secure the handle bar; 2. Fasten the handle bar with the yoke which goes along with the kit; 3. Remove the side fairings, the tank plastic cover and the plastic ignition key cover; 4. Cut the plastic ignition key cover using a stiletto according to the image below; 5. Remove the screws and washers that fasten the tank to the top triple tree; 6. Use the boomerang -shaped tower to fasten the tank again; 7. Fasten the steering damper to the top triple tree by attaching the bar to the holder opening (it is not necessary too much fastening) 8. Tighten the tower side screw, 9. Replace the ignition cover and side fairings.

GSX 750 S 2018 INGLES 1

GSX 750 S 2018 / 2020 1. Release the parts that secure the handle bar; 2. Fasten the handle bar with the yoke which goes along with the kit; 3. Remove the side fairings, the tank plastic cover and the plastic ignition key cover; 4. Cut the plastic ignition key cover using a stiletto according to the image below; 5. Remove the screws and washers that fasten the tank to the top triple tree; 6. Use the boomerang -shaped tower to fasten the tank again; 7. Fasten the steering damper to the top triple tree by attaching the bar to the holder opening (it is not necessary too much fastening) 8. Tighten the tower side screw, 9. Replace the ignition cover and side fairings.

GSX 750 S A PARTIR 2018

GSX 750 S 1. Loosen the bushings that fix the handlebars; 2. Fix the handlebars with the table that comes with the kit; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key; 4. Cut out the plastic ignition cover as shown in the image; 5. Remove the screws and washers that fix the tank to the frame; 6. Reattach the tank, using the boomerang-shaped turret; 7. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 8. Tighten the tower side screw; 9. Replace the ignition cover and side fairings

GSX 750 S VARETA

GSX 750 S - DIPSTICK 1. Remove the screws from the bushings on the right side that fix the handlebar and fix the “L” shaped part in place; 2. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key; 3. Cut out the plastic ignition cover as shown in the image; 4. Remove the screws and washers that fix the tank to the frame; 5. Reattach the tank, using the boomerang-shaped tower; 6. Fix the shock absorber rod to the “L” shaped part; 7. Center the shock absorber body so that it does not touch the end of the stroke when steering the handlebars; 8. Tighten the clamp; 9. Replace the ignition cover and side fairings.

GSX S1000 A F FA INGLES

ASSEMBLY INSTRUCTIONS GSX S 1000 A | GSX S 1000 FA | GSX 1000 F 1. Release the yoke that secures the handlebars; 2. Fasten the handlebar with the yoke which goes along with the kit using the original screws; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic key cover; 4. Position the rectangular bar with the M6 ■■threaded holes under the ignition assembly observing that the bar dent faces upward with the relief chamfer facing the ignition assembly; 5. Attach the inverted T-tower to the previously positioned bar, observing that the angle of the inclination is directed towards the front of the motorcycle, visually align this tower to the center of the yoke; 6. Fasten the steering damper to the yoke by attaching the bar to the holder opening (it is not necessary too much fastening); 7. Tighten the tower side screw. Note: cut the ignition key cover with a stiletto according to the illustration

GSX S 1000 A F FA

GSX S 1000 A | GSX S 1000 F | GSX S 1000 FA 1. Loosen the bushings that fix the handlebars; 2. Fix the handlebars with the table that comes with the kit using the original screws; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key; 4. Position the rectangular bar with M6 threaded holes under the ignition assembly, ensuring that the recess in the bar is facing upwards with the relief chamfer facing the ignition assembly; 5. Attach the inverted T-shaped tower to the previously positioned bar, ensuring that the angle of inclination is directed towards the front of the motorcycle, visually align this tower with the center of the table; 6. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 7. Tighten the tower side screw. Note: cut the ignition switch cover with a utility knife as shown in the image

GSX S 1000 A F FA INGLES

ASSEMBLY INSTRUCTIONS GSX S 1000 A | GSX S 1000 FA | GSX 1000 F 1. Release the yoke that secures the handlebars; 2. Fasten the handlebar with the yoke which goes along with the kit using the original screws; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic key cover; 4. Position the rectangular bar with the M6 ■■threaded holes under the ignition assembly observing that the bar dent faces upward with the relief chamfer facing the ignition assembly; 5. Attach the inverted T-tower to the previously positioned bar, observing that the angle of the inclination is directed towards the front of the motorcycle, visually align this tower to the center of the yoke; 6. Fasten the steering damper to the yoke by attaching the bar to the holder opening (it is not necessary too much fastening); 7. Tighten the tower side screw. Note: cut the ignition key cover with a stiletto according to the illustration

GSX S 1000 A F FA INGLES 1

ASSEMBLY INSTRUCTIONS GSX S 1000 A | GSX S 1000 FA | GSX 1000 F 1. Release the yoke that secures the handlebars; 2. Fasten the handlebar with the yoke which goes along with the kit using the original screws; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic key cover; 4. Position the rectangular bar with the M6 ■■threaded holes under the ignition assembly observing that the bar dent faces upward with the relief chamfer facing the ignition assembly; 5. Attach the inverted T-tower to the previously positioned bar, observing that the angle of the inclination is directed towards the front of the motorcycle, visually align this tower to the center of the yoke; 6. Fasten the steering damper to the yoke by attaching the bar to the holder opening (it is not necessary too much fastening); 7. Tighten the tower side screw. Note: cut the ignition key cover with a stiletto according to the illustration

GSX S 750

GSX 750 S 1. Loosen the half-moons that fix the handlebars; 2. Fix the handlebars to the base using the original screws; 3. Loosen the longest screw on the inverted fork-shaped support that comes with the kit; 4. Position this support in front of the plastic tank cover above the ignition assembly; 5. Replace the longer screw in its original place, but do not tighten it; 6. Tighten the smaller screw and only then tighten the larger screw; 7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 8. Tighten the side screw.

GSX S 750 2018

GSX S 750 2018/ 2019 1. Loosen the bushings that fix the handlebars; 2. Fix the handlebars with the table that comes with the kit; 3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key; 4. Cut the plastic ignition cover according to the image; 5. Remove the screws and washers that fix the tank to the frame; 6. Reattach the tank, using the boomerang-shaped turret; 7. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 8. Tighten the tower side screw; 9. Replace the ignition cover and side fairings.

GS 500 E 2004 2009

G 310 GS

G 310 GS 1. Remove the table that surrounds the canes; 2. Remove the dust cover from the bearing; 3. Position the clamp on the bearing box WITHOUT tightening the screws; 4. Replace the dust cover and the table that surrounds the canes; 5. Replace the part that fixes the handlebars with the table that comes with the kit; 6. Align the handlebars and fix the shock absorber on the table, fitting the stem into the slot; 7. After aligning all parts, tighten all screws definitively.

HAYABUSA 2005

HAYABUSA 2009 2014

HORNET 2005 2007 NOVO

HORNET 2005 -2007 1. Remove the bushings that fix the handlebar; 2. Fix the handlebars with the table that comes with the kit; 3. Move the tank away to access the panel (it is not necessary to remove the tank); 4. Attach the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit; 5. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

HORNET 2005 2007 NOVO FAT BAR

HORNET 2005 -2007 – FAT BAR 1. Remove the bushings that fix the handlebar and remove it; 2. Fix the risers (handlebar extenders) 3. Fix the handlebars over the risers with the table that comes with the kit; 4. Move the tank aside to access the panel (it is not necessary to remove the tank); 5. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit; 6. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

HYPERMOTARD 1100

HYPERMOTARD 796

HYPERMOTARD 821

HYPERMOTARD 821 1. Release the handlebars and remove the risers; 2. Fix the base of the kit on the table with the risers, replacing the original screws with the larger screws that come with the kit; 3. Remove the 2 screws located next to the ignition key; 4. Attach 2 threaded bushings that come with the kit to the visible screws; 5. Fix the tower that comes with the kit onto the bushings using the screws provided; 6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the support pin previously affixed to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 turn of tightening the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 7. Replace the handlebars.

HYPERMOTARD 821 INGLE■S

HYPERMOTARD 821 1. Release the handlebar and remove the risers; 2. Fasten the base on the top triple tree with the risers by substituting the original screws for the larger ones that come along with the kit; 3. Remove the 2 screws that are placed next to the ignition key; 4. Fasten the screws with th and 2 threaded plugs which comes along with the kit; 5. Fasten the “tower-shaped” part of the plugs using the screws that have been sent; 6. Fasten the stee ring damper to the top triple tree by attaching the stem to the bracket pin previously attached to the ignition set by leveling the pin so that it is close to the stem (NOTE: It’s not necessary too much tightening, just 1/8 turn tightening on the screw is enoug h). Excessive tightening on the 2 screws that secure the steering damper may cause extra hardening and subsequent damage to the damper; 7. Replace the handlebar.

HYPERMOTARD 821 INGLE■S 1

HYPERMOTARD 821 1. Release the handlebar and remove the risers; 2. Fasten the base on the top triple tree with the risers by substituting the original screws for the larger ones that come along with the kit; 3. Remove the 2 screws that are placed next to the ignition key; 4. Fasten the screws with th and 2 threaded plugs which comes along with the kit; 5. Fasten the “tower-shaped” part of the plugs using the screws that have been sent; 6. Fasten the stee ring damper to the top triple tree by attaching the stem to the bracket pin previously attached to the ignition set by leveling the pin so that it is close to the stem (NOTE: It’s not necessary too much tightening, just 1/8 turn tightening on the screw is enoug h). Excessive tightening on the 2 screws that secure the steering damper may cause extra hardening and subsequent damage to the damper; 7. Replace the handlebar.

HYPERSTRADA

HYPERSTRADA 1. Release the handlebars and remove the risers; 2. Fix the base of the kit on the table with the risers, replacing the original screws with the larger screws that come with the kit; 3. Remove the 2 screws located next to the ignition key; 4. Attach 2 threaded bushings that come with the kit to the visible screws; 5. Fix the tower that comes with the kit onto the bushings using the screws provided; 6. Fix the shock absorber on the handlebar table by fitting the slot in the stem to the support pin previously affixed to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 7. Replace the handlebars.

KTM 1050 1090 1190 1290

KTM 1050/1090/ 1190/1290 1. Remove the handlebars and risers (risers are the parts that raise the handlebars on the table); 2. Fix the shock absorber base on the table, using the risers that come with the kit; 3. Remove the rubber trim located between the tank and the steering gear; 4. Attach the support to the frame, hugging the frame; 5. Fix the tower on the support; 6. Fix the steering damper on the base of the table, fitting the slot in the rod to the pin of the tower fixed to the frame (it is not necessary to tighten it too much); 7. Reattach the handlebars.

KTM 990 ADVENTURE

KTM 990 ADVENTURE 1. Remove 2 plastic covers positioned between the tank and the table; 2. Attach the tower in the shape of an inverted “T” at this point with the recess facing the table; 3. Release the handlebars and remove the plastic covers positioned between the handlebars and the headlight; 4. Attach the crescent-shaped base at this point with the recess facing the handlebars; 5. On the base, fix the steering damper by fitting the slot in the rod to the pin of the tower fixed to the frame (it is not necessary to tighten it too much); Reattach the handlebars.

KTM 990 ADVENTURE INGLES

KTM 990 ADVENTURE 1. Remove the two plastic caps positioned between the tank and the top triple tree; 2. Fasten the inverted "T" shaped tower at this place with the recess facin g the top triple tree; 3. Release the handlebar and remove the plastic covers positioned between the handlebar and the headlamp; 4. Fasten the half-moon shape d base with the recess facing the handlebars at this place; 5. Fasten the steering damper to the base by attaching the bar to the h older opening (it is not necessary to fasten it too tightly)); 6. Put the handlebar back , 7. Tighten the tower side screw.

KTM 990 ADVENTURE INGLES 1

KTM 990 ADVENTURE 1. Remove the two plastic caps positioned between the tank and the top triple tree; 2. Fasten the inverted "T" shaped tower at this place with the recess facin g the top triple tree; 3. Release the handlebar and remove the plastic covers positioned between the handlebar and the headlamp; 4. Fasten the half-moon shape d base with the recess facing the handlebars at this place; 5. Fasten the steering damper to the base by attaching the bar to the h older opening (it is not necessary to fasten it too tightly)); 6. Put the handlebar back , 7. Tighten the tower side screw.

KTM SMT 990

KTM SMT 990 1. Remove 2 plastic covers positioned between the tank and the table; 2. Attach the tower in the shape of an inverted “T” at this point; 3. Release and remove the handlebars; 4. Loosen the table screw, it is not necessary to loosen the table side screw; 5. Fix the cup with the screw that comes with it, without using a washer; 6. Remove the risers and replace them using the shims and screws that come with the kit; 7. Fix the steering damper to the cup by fitting the slot in the rod to the pin of the tower fixed to the frame (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 bolts that fix the damper to the cup causes excessive hardness when steering the handlebars; 8. Reattach the handlebars using the screws that come with the kit.

LANDER

LANDER 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer; 4. Fix the tower to the frame using the cylindrical bar that must cross it; 5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars); 6. Tighten the tower side screw; 7. Secure the handlebars using the handlebar riser.

LANDER FAT BAR

LANDER – FAT BAR 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer; 4. Fix the tower to the frame using the cylindrical bar that must cross it; 5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars); 6. Tighten the tower side screw; 7. Secure the handlebars using the handlebar riser.

LOW RIDER

LOW RIDER 1. Remove the original risers and fix the table in place, positioning the risers on it with the screws that come with the kit; 2. Remove the hub nut and the transverse screw that fixes the tank to the frame; 3. Fix the tower in the shape of an inverted fork using the washers on the internal and external side of each “leg” of the fork; 4. Pass through both “legs” of the fork and the respective washers with the long screw pair that comes with the kit and use the cap nut to tighten it; 5. Fix the shock absorber on the previously installed table by fitting the rod to the slot in the tower (it is not necessary to tighten it too much); 6. Tighten the screw on the side of the tower.

MONSTER 1100

MONSTER 1200

MONSTER 1200 1. Remove the original table that fixes the handlebars; 2. Reattach the handlebars using the table that comes with the kit; 3. Remove the 2 screws located next to the ignition key; 4. Attach 2 threaded bushings that come with the kit to the visible screws; 5. Fix the tower that comes with the kit onto the bushings using the screws provided; 6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the pin of the support previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn of tightening the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

MONSTER 696

MONSTER 796

MONSTER 797

MONSTER 1200 1. Remove the original table that fixes the handlebars; 2. Reattach the handlebars using the table that comes with the kit; 3. Remove the 2 screws located next to the ignition key; 4. Attach 2 threaded bushings that come with the kit to the visible screws; 5. Fix the tower that comes with the kit onto the bushings using the screws provided; 6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the pin of the support previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn of tightening the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

MONSTER 821

MONSTER 821 1. Remove the original table that fixes the handlebars; 2. Reattach the handlebars using the table that comes with the kit; 3. Remove the 2 screws located next to the ignition key; 4. Attach 2 threaded bushings that come with the kit to the visible screws; 5. Fix the tower that comes with the kit onto the bushings using the screws provided; 6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the support pin previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

MT 03

MT 03 1. Loosen the half-moons that fix the handlebars; 2. Reattach the handlebars to the table that comes with the kit; 3. Fix the tower base to the frame; 4. Fix the tower (piece shaped like an inverted fork) to the base previously fixed to the frame; 5. Fix the shock absorber on the table by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much); 6. Tighten the tower side screw.

MT 03 660 CC

MT 03 660 CC 1. Remove the original handlebars and risers; 2. Remove the side screws from the plastic finish and fix the tower in the threaded holes in the frame; 3. Tighten the upper tower screws; 4. Position the table that comes with the kit on the motorcycle table and tighten the screws (it is not necessary to overtighten) ç 5. Replace the handlebars using the risers that come with the kit.

MT 03 FAT BAR

MT 03 FAT BAR 1. Loosen the half-moons that fix the handlebars; 2. Remove the original risers; 3. Fix the tower base to the frame; 4. Fix the tower (piece shaped like an inverted fork) to the base previously fixed to the frame; 5. Attach the risers that come with the kit to the motorcycle table; 6. Fix the handlebars with the table that comes with the kit; 7. Fix the shock absorber on the table by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much); 8. Tighten the tower side screw.

MT 07

MT 07 INGLES

MT 07 1. Release the panel and the handle bar; 2. Remove the risers from the top triple tree, releasing the washers underneath; 3. Attach the yoke and the risers that go along with the kit on the top triple tree; 4. Fasten the tower -shaped part to the frame. Be sure that the screws used for this fastening are very close to the plate welded to the frame (if necessary put the tank cover away); 5. Fasten the steering damper to the yoke fitting the bar to the tower - shaped part opening; 6. Tighten the side sc rew; 7. Reassemble the handle bar and the panel.

MT 07 INGLES 1

MT 07 1. Release the panel and the handle bar; 2. Remove the risers from the top triple tree, releasing the washers underneath; 3. Attach the yoke and the risers that go along with the kit on the top triple tree; 4. Fasten the tower -shaped part to the frame. Be sure that the screws used for this fastening are very close to the plate welded to the frame (if necessary put the tank cover away); 5. Fasten the steering damper to the yoke fitting the bar to the tower - shaped part opening; 6. Tighten the side sc rew; 7. Reassemble the handle bar and the panel.

MT 09 2014 2016

MT 09 INGLES

MT 09 1. Remove the tank cover; 2. Release the screw that attaches the tank to the frame; 3. Attach the ‘T’ shaped mounting bracket in the hole with the screw that goes along with the kit (do not use the ferrule); 4. Release the 2 half-moon shaped parts that fast en the handle bar; 5. Fasten the handle bar with the yoke that goes along with the kit; 6. Fasten the steering damper to the yoke by attaching the bar to the ‘T’ shaped mounting bracket opening (it is not necessary too tight fastening); 7. Tighten the side screw; 8. Put the tank cover back.

MT 09 INGLES 1

MT 09 1. Remove the tank cover; 2. Release the screw that attaches the tank to the frame; 3. Attach the ‘T’ shaped mounting bracket in the hole with the screw that goes along with the kit (do not use the ferrule); 4. Release the 2 half-moon shaped parts that fast en the handle bar; 5. Fasten the handle bar with the yoke that goes along with the kit; 6. Fasten the steering damper to the yoke by attaching the bar to the ‘T’ shaped mounting bracket opening (it is not necessary too tight fastening); 7. Tighten the side screw; 8. Put the tank cover back.

MT 09 TRACER

MT 09 TRACER ATUAL

MT 09 TRACER 1. Remove the handlebars to access the central nut of the stem; 2. Remove the nut and washer; 3. Fix the bearing to the central screw using the nut that comes with the kit; 4. Fix the boomerang on the bearing; 5. Loosen the screw that fixes the tank; 6. Fix the support in the shape of a “T” in the threaded hole with the screw that comes with the kit (WITHOUT the washer); 7. Install the steering damper onto the boomerang (excessive tightening is not necessary) by fitting the rod into the slot in the “T”-shaped support; 8. Tighten the side screw of the tower fixed to the frame; 9. Replace the handlebars.

MT 09 TRACER ATUAL INGLES

MT 09 TRACER 1. Remove the handle bars in order to have access to the central screw of the top triple tree; 2. Remove the screw and the washer; 3. Attach the bearing on the central screw machining the screw that goes along with the kit; 4. Attach the boomerang on the bearing; 5. Release the screw that attaches the tank to the frame; 6. Attach the T-shaped mounting bracket in the hole with the screw that goes long with the kit (WITHOUT using the wa sher); 7. Attach the steering damper to the boomerang fitting the bar to the T-shaped opening (it’s not necessary t oo tight fastening); 8. Tighten the side screw; 9. Replace the handle bars.

MT 09 TRACER ATUAL INGLES 1

MT 09 TRACER 1. Remove the handle bars in order to have access to the central screw of the top triple tree; 2. Remove the screw and the washer; 3. Attach the bearing on the central screw machining the screw that goes along with the kit; 4. Attach the boomerang on the bearing; 5. Release the screw that attaches the tank to the frame; 6. Attach the T-shaped mounting bracket in the hole with the screw that goes long with the kit (WITHOUT using the wa sher); 7. Attach the steering damper to the boomerang fitting the bar to the T-shaped opening (it’s not necessary t oo tight fastening); 8. Tighten the side screw; 9. Replace the handle bars.

MT 09 TRACER INGLES

MT 09 TRACER 1. Remove the handle bars and the risers; 2. Release the screw that attaches the tank to the frame; 3. Attach the T-shaped mounting bracket in the hole with the screw that goes along with the kit (WITHOUT using the ferrule); 4. Attach the top triple tree and the risers that go along with the kit on the yoke fastening them under the top triple tree with the M 10 screw; 5. Fasten the steering damper to the yoke previously attached to the top triple tree (it is not necessary to tight fastening); 6. Tighten the side sc rew; 7. Replace the handle bars.

MT 09 TRACER INGLES 1

MT 09 TRACER 1. Remove the handle bars and the risers; 2. Release the screw that attaches the tank to the frame; 3. Attach the T-shaped mounting bracket in the hole with the screw that goes along with the kit (WITHOUT using the ferrule); 4. Attach the top triple tree and the risers that go along with the kit on the yoke fastening them under the top triple tree with the M 10 screw; 5. Fasten the steering damper to the yoke previously attached to the top triple tree (it is not necessary to tight fastening); 6. Tighten the side sc rew; 7. Replace the handle bars.

MULTISTRADA 2016 2017

DUCATI MULTISTRADA – 2016/2017 1. Release the handlebars, removing the risers; 2. Fix the base with the risers, taking care to position the circular support facing downwards using the original screws, but replacing the round shim with the shim that comes with the kit; 3. Remove the plastic cover from the tank and attach the split clamp to the ignition assembly; 4. Fix the shock absorber to the base by fitting the rod into the slot in the clamp (it is not necessary to tighten it too much); 5. Tighten the screw on the side of the clamp to secure the rod; 6. Replace the plastic cover and handlebars.

MULTISTRADA ATE■ 2015

MV AGUSTA RIVALE

MV AGUSTA RIVALE 1. Remove the table and replace the central nut with the nut included in the kit; 2. Replace the table; 3. Remove 2 screws that secure the ignition to the frame; 4. Fix the ignition tower; 5. Attach the clamp to the previously replaced nut by tightening the side screw l; 6. Fix the shock absorber head on the clamp, fitting the rod to the slot in the support fixed to the frame; NOTE: the screws that fix the shock absorber should only be tightened by 1/8 of a turn to avoid crushing the internal chamber of the shock absorber; 7. Adjust the height of the tower pin, so that it is not higher than the torn rod. 8. Tighten the side screw of the support fixed to the frame.

NC 700 NC 750

NC 700/ NC 750 1. Remove the table; 2. Remove the 2 bearing nuts, the lock and the bearing cover; 3. Place the clamp under the bearing; 4. Replace the nuts, lock and bearing cover; 5. Replace the table; 6. Replace the base on the handlebars with the base that comes with the kit and secure it using the screws on the motorcycle itself; 7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 8. Tighten the side screw.

NEXT 250

NINJA 1000 2010 20013

NINJA 1000 INGLES

NINJA 1000 1. Remove the washer from the top triple tree; 2. Fasten the cup -shaped part that goes along with the kit on the top triple tree using the original screw WITHOUT the washer; 3. Release the screws that fasten the tank removing the washers, then fasten the tank again using the T -shaped part using the sc rews that go along with the kit; 4. Fasten the steering damper on the cup -shaped part fitting the bar to the tower gap (DO NOT apply too much tightening); 5. Fasten the tower side screw.

NINJA 1000 INGLES 1

NINJA 1000 1. Remove the washer from the top triple tree; 2. Fasten the cup -shaped part that goes along with the kit on the top triple tree using the original screw WITHOUT the washer; 3. Release the screws that fasten the tank removing the washers, then fasten the tank again using the T -shaped part using the sc rews that go along with the kit; 4. Fasten the steering damper on the cup -shaped part fitting the bar to the tower gap (DO NOT apply too much tightening); 5. Fasten the tower side screw.

NINJA 250 2008 2012

NINJA 300 2013 2016

NINJA 400

NINJA 400 1. Loosen the table nut and remove the washer; 2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer; 3. Move the tank aside to access the holes in the frame; 4. Fix the tower to the frame using the cross member under the frame plate; 5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much); 6. Tighten the tower side screw; 7. Put the tank back in place.

NINJA 650 R 2010 2012

NINJA 650 VARETA

NINJA 650 (STICK MODEL) 1. Remove the plastic cover from the tank; 2. Remove the screws that secure the ignition; 3. Attach the boomerang-shaped support to the ignition; 4. Attach the “L” shaped support to the front brake hose; 5. Fix the shock absorber rod on the “L” shaped support; 6. Position the shock absorber inside the clamp in such a way that it does not prevent the handlebars from fully steering on both sides; 7. Tighten the clamp screws; 8. Cut the plastic tank cover to fit it back onto the motorcycle; 9. Replace the plastic tank cover.

NX 400 FALCON

NX 400 FALCON 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer; 4. Attach the clamp to the steering bearing housing; 5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw. Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars); 6. Tighten the tower side screw; 7. Fix the handlebars using the risers that come with the kit.

PANIGALI 1199

PANIGALI 1199 1. Release the table; 2. Replace the original central nut with the nut that comes with the kit; 3. Fix the cup to the nut by tightening the side screws; 4. Remove the screws that secure the plastic cover around the ignition; 5. Fix the 2 threaded bushings that come with the kit in place; 6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much); 7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot; 8. Tighten the boomerang side screw.

PANIGALI 1299

PANIGALI 1299 1. Release the table; 2. Replace the original central nut with the nut that comes with the kit; 3. Fix the cup to the nut by tightening the side screws; 4. Remove the screws that secure the plastic cover around the ignition; 5. Fix the 2 threaded bushings that come with the kit in place; 6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much); 7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot; 8. Tighten the boomerang side screw.

RD 350

RD 350 1. Remove the table by removing the central screw and loosening the table clamps that fix the canes; 2. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock); 3. Remove the dust cover from the bearings; 4. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it; 5. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear; 6. Replace the table without the central screw; 7. Place the cup that comes with the kit, fixing it with the central screw; 8. Attach the inverted “T” shaped support to the clamp previously attached to the seatpost; 9. Align and position the clamp so that it does not rub against the dust cover and tighten the screw to secure it; 10. Fix the shock absorber to the cup, fitting the rod into the slot (it is not necessary to tighten it too much); 11. Tighten the side screw.

R 1200 GS ATE■ 2012

R 1200 GS A PARTIR 2013

SPEED TRIPLE 1050 2013 2016

STREER TRIPLE 675 2013 2016

STREET TRIPLE 675

STREET TRIPLE 765

STREET TRIPLE 765 1. Release the crescents from the risers that fix the handlebars; 2. Fix the handlebars with the base that makes up the installation kit using the original screws; 3. Remove the screws that fix the tank and fix the “T” support to the frame in place, refixing the tank with the screws that come with the kit; 4. Install the shock absorber on the previously fixed base (it is not necessary to tighten it too much); 5. Fit the shock absorber rod to the slot in the “T” support; 6. Tighten the side screw of the support fixed to the frame.

SUPER TENERE 1200

SUPER TENERE 1200 2015 EM DIANTE

SUPER TENERE 1200 – 2015 ONwards 1. Release the handlebars by removing the crescents; 2. Remove the table nut and washer; 3. On the table screw, secure the cup using the nut that comes with the kit; 4. Open 2 pre-existing holes in the frame close to the tank to ø 8.5mm; 5. Open M10 thread pitch 1.5 in these holes (preferably use an individual machine tap); 6. Fix the support that comes with the kit in these threaded holes (it is not necessary to tighten too much, although the screws are reasonably large, pay close attention when tightening so as not to strip the threads); 7. Invert the position of the risers, positioning the left riser on the right side and vice versa; 8. Fix the shock absorber on the cup by fitting its rod into the slot in the support fixed to the frame (it is not necessary to tighten it too much); 9. Replace the handlebars.

SV 650

SV 650 1. Loosen the half-moons that fix the handlebars; 2. Fix the handlebars to the base using the screws that come with the kit; 3. Loosen and remove the 2 screws and washers that fix the tank to the frame; 4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit; 5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 6. Tighten the side screw.

S 1000 RR 2012 2017

S 1000 RR ATE■ 2011

S 1000 R NAKED

S 1000 XR

S1000 XR 1. Loosen the half-moons that fix the handlebars; 2. Fix the handlebars to the base using the original screws; 3. Remove the plastic cover that surrounds the ignition 4. Fix the Tower base to the frame (slanted screws), 5. Replace the ignition cover 6. Fix the Tower to the base previously fixed to the frame 7. Fix the shock absorber to the base fixed to the table, fitting the rod into the slot in the support (it is not necessary to tighten it too much); 8. Tighten the side screw.

TENERE 250

TENERE■ 250

TENERÉ 250 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer; 4. Fix the tower to the frame using the cylindrical bar that must cross it; 5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars); 6. Tighten the tower side screw; 7. Secure the handlebars using the handlebar riser.

TENERE■ 250 FAT BAR

TENERÉ 250 – FAT BAR 1. Release the handlebars; 2. Loosen the table nut and remove the washer; 3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer; 4. Fix the tower to the frame using the cylindrical bar that must cross it; 5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars); 6. Tighten the tower side screw; 7. Secure the handlebars using the handlebar riser.

TIGER 1050 SPORT

TIGER 1050 SPORT 1. Release the handlebars and remove the risers from the table; 2. Position the table that comes with the kit on the original table, fixing it with the risers removed previously using the screws from the kit; 3. Remove the screw and washer that secures the tank to the frame; 4. Fix the tower in the shape of an inverted “T”; 5. Adjust the height of the tower pin so that it is 1 mm below the shock absorber; 6. Fix the shock absorber on the previously installed table in such a way that the pin fits into the slot in the rod; 7. Attach the handlebars.

TIGER 1200 ATUAL

TIGER 1200 1. Remove the handlebars; 2. Remove the original nut and the central washer from the table 3. Fix the special nut with a square hole on the central screw of the table using a ½’’ ratchet wrench extender; 4. Fit the cup onto the special nut and tighten the horizontal screws; 5. Move the tank away; 6. Fix the support to the frame in two inclined slots next to the rubber where the tank is fitted, passing the screws through the slots and placing 2 nuts under this plate; 7. Fix the shock absorber to the cup, fitting the shock absorber rod to the slot in the support (it is not necessary to tighten it too much); 8. Replace the handlebars; 9. Tighten the side screw of the support fixed to the frame.

TIGER 800

TIGER 800XC 2014 2016

TIGER 800 ATUAL

TIGER 8 00 1. Release the handlebars; 2. Remove the central nut from the table and replace it with the nut with a square hole that comes with the kit and tighten; 3. Fit the cup into the slot with the square hole, aligning it with the table and tighten the horizontal screws tightly; 4. Loosen the 4 screws on the “V” shaped clamp in order to position it on the pipe that holds the front fairing (DO NOT tighten the screws permanently); 5. Position the pin tower with the extensions on the “V”-shaped clamp; 6. Install the shock absorber on the cup, fitting the slot in the rod to the pin and adjusting the height of the pin with light taps (it is not necessary to overtighten the screws); 7. If you consider it necessary to raise the handlebars, install the 2 oval silver-colored shims under the risers; 8. Tighten all screws after making sure that all parts are properly aligned.

TIGER 800 XCX 2014 2016

TIGER 800 XRX

TIGER 900

TIGER 900 1. Remove the handlebars and risers; 2. Loosen the central nut of the table and remove the washer; 3. Fix the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer; 4. Move the tank away and remove the plastic cover that surrounds the ignition; 5. Remove the electrical component from the plate that fixes the plastic cover to access 2 hexagonal screws; 6. Remove the hexagonal screws and fix the tower by fitting its hole into the ignition using the screws that come with the kit; 7. Replace the electrical component; 8. Fix the shock absorber on the cup by fitting the rod to the slot in the tower (excessive tightening is not necessary); 9. Attach the risers that come with the kit; 10. Replace the handlebars; 11. Make a cut in the plastic cover that surrounds the ignition with a width of 26 mm, leaving 10 mm in the original height; 12. Reassemble the motorcycle; 13. Tighten the tower side screw.

TIGER EXPLORER 1200 ATUAL INGLES

TIGER EXPLORER 1200 1. Remove the handle bar; 2. Remove the screw and the washer; 3. Attach the special screw with a square hole on the central screw of the top triple tree using a ratchet wren of ½"; 4. Fit the cup -shaped part on the special screw and fasten the horizontal screws; 5. Move the tank away a little bit; 6. Fix the bracket to the frame in two inclined slots on the side of the rubber where the tank is fitted, passing the screws through the slots and placing the 2 nuts underneath the plate; -Fasten the steering d amper on the cup-shaped part fitting the bar to the holder opening (it’s not necessary too tight fastening g);

TIGER EXPLORER 1200 ATUAL INGLES 1

TIGER EXPLORER 1200 1. Remove the handle bar; 2. Remove the screw and the washer; 3. Attach the special screw with a square hole on the central screw of the top triple tree using a ratchet wren of ½"; 4. Fit the cup -shaped part on the special screw and fasten the horizontal screws; 5. Move the tank away a little bit; 6. Fix the bracket to the frame in two inclined slots on the side of the rubber where the tank is fitted, passing the screws through the slots and placing the 2 nuts underneath the plate; -Fasten the steering d amper on the cup-shaped part fitting the bar to the holder opening (it’s not necessary too tight fastening g);

TIGER EXPLORER 1200 INGLES

TIGER EXPLORER 1200 1. Remove the handlebar; 2. Release the risers; 3. Remove the two elastic pins from the top triple tree; 4. Fasten the base which goes along with the installation kit on the top triple tree with the screws that go along with it; 5. Move the tank away a little bit; 6. Fix the bracket to the frame in two inclined slots on the side of the rubber where the tank is fitted, passing the screws through the slots and placing the 2 nuts underneath this plate; -Fasten the steering damper to the base previously secured to the top triple tree by attaching the bar to the holder opening (it’s not necessary too much fastening) -Replace the risers and secure the handlebar; 9. Tighten the side screw of the bracket attached to the frame.

TIGER EXPLORER 1200 INGLES 1

TIGER EXPLORER 1200 1. Remove the handlebar; 2. Release the risers; 3. Remove the two elastic pins from the top triple tree; 4. Fasten the base which goes along with the installation kit on the top triple tree with the screws that go along with it; 5. Move the tank away a little bit; 6. Fix the bracket to the frame in two inclined slots on the side of the rubber where the tank is fitted, passing the screws through the slots and placing the 2 nuts underneath this plate; -Fasten the steering damper to the base previously secured to the top triple tree by attaching the bar to the holder opening (it’s not necessary too much fastening) -Replace the risers and secure the handlebar; 9. Tighten the side screw of the bracket attached to the frame.

TIGER EXPLORE 1200 2014 2016

TRANSALP 700

TRANSALP 700 ATUAL

TRANSALP 700 1. Loosen the handlebars to access the stem nut; 2. Remove the table nut and washer; 3. Fix the cup that comes with the kit with the original nut WITHOUT the washer; 4. Fix the shock absorber on the cup without tightening the screws; 5. Position the piece in the shape of an inverted “T” on the frame, fitting the rod to the slot in the tower, aligning it; 6. Use the holes in the inverted “T” piece as a guide to mark the place where 2 holes in the frame should be made; 7. Remove the shock absorber and tower and drill 2 9mm holes in the frame markings; 8. Fit the threaded rivets into the holes; 9. Replace the tower in an inverted “T” and tighten the screws on the threaded pins; 10. Fix the shock absorber on the cup by fitting the rod to the slot in the tower (DO NOT apply excessive tightening); 11. Tighten the tower side screw; 12. Replace the handlebars using the risers that come with the kit.

TRANSALP 700 INGLES

TRANSALP 700 1. Release the handle bar in order to have access to the top triple tree; 2. Remove the screw and the washer; 3. Fasten the cup -shaped part that goes along with the kit with the original screw WITHOUT the washer; 4. Fasten the steer ing damper on the cup-shaped part WITHOUT tightening the screws; 5. Position the inverted “T”-shaped part to the frame fitting the bar to the tower, aligning it; 6. Use the inverted “T”-shaped part holes as a guidance to mark where 2 holes must be made in the frame; 7. Remove the steering dam per and the inverted “T”-shaped part and make 9mm holes in the frame previously marked; 8. Fit the threaded rivets that go along with the kit in the holes; 9. Replace the inverted “T”-shaped part and fasten the threaded rivet screws; 10. Fasten the steering damper on the cup-shaped part fitting the bar to the tower gap (DO NOT apply too much tightening) 11. Fasten the tower side screw ; 12. Replace the handle bar using the risers that go along with the kit.

TRANSALP 700 INGLES 1

TRANSALP 700 1. Release the handle bar in order to have access to the top triple tree; 2. Remove the screw and the washer; 3. Fasten the cup -shaped part that goes along with the kit with the original screw WITHOUT the washer; 4. Fasten the steer ing damper on the cup-shaped part WITHOUT tightening the screws; 5. Position the inverted “T”-shaped part to the frame fitting the bar to the tower, aligning it; 6. Use the inverted “T”-shaped part holes as a guidance to mark where 2 holes must be made in the frame; 7. Remove the steering dam per and the inverted “T”-shaped part and make 9mm holes in the frame previously marked; 8. Fit the threaded rivets that go along with the kit in the holes; 9. Replace the inverted “T”-shaped part and fasten the threaded rivet screws; 10. Fasten the steering damper on the cup-shaped part fitting the bar to the tower gap (DO NOT apply too much tightening) 11. Fasten the tower side screw ; 12. Replace the handle bar using the risers that go along with the kit.

VERSYS 1000 ATE 2015

VERSYS 1000 A PARTIR 2016

ASSEMBLY INSTRUCTIONS VERSYS 1000 – FROM 2016 1. Release the handlebars; 2. Remove the risers and replace them with the risers that come with the kit; 3. Loosen the central nut and remove the washer; 4. Fix the cup to the central screw of the table, without installing the washer, using the original nut; 5. Loosen the screws that fix the tank to the frame; 6. Fix the tower in an inverted T shape; 7. Fix the shock absorber on the cup previously fixed to the table nut (it is not necessary to tighten it too much), fitting the rod to the slot in the tower, and tighten the screw on the side of the tower; 8. Replace the handlebars.

VERSYS 300

VERSYS 300 1. Remove the original table and fix the handlebars with the table that comes with the kit; 2. Move the tank aside to access the panel (it is not necessary to remove the tank); 3. Fix the piece in the shape of an inverted fork (the half-moon must be positioned towards the handlebars) with the cross member that comes with the kit; 4. Fix the shock absorber to the table above the handlebars; 5. Tighten the tower side screw (excessive tightening is not necessary).

VERSYS 650

Versys 650 1. Loosen and remove the handlebars; 2. Loosen the central nut and remove the table; 3. Place the clamp under the bearing cover; 4. Replace the table; 5. Fix the cup to the central nut, without using the washer; 6. Fix the steering damper on the cup (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower; 7. Fix the handlebars;

VERSYS 650 ATUAL

VERSYS 650 1. Release the stem and handlebars; 2. Loosen the central nut and remove the table; 3. Place the clamp under the bearing cover; 4. Replace the table; 5. Replace the original nut with the nut with a square hole that comes with the kit with the washer; 6. Fix the shock absorber on the cup (it is not necessary to tighten too much) and fitting the rod to the slot in the tower; 7. Tighten the tower side screw; 8. Replace the handlebars.

VMAX 1200

V-MAX 1200 1. Release and move the handlebars; 2. Loosen the central nut of the table and remove the washer; 3. Secure the cup with the nut that comes with the kit WITHOUT the original washer; 4. Fix the clamp under the dust cover on the bearing housing, visually aligning it in the center of the motorcycle; 5. Fix the shock absorber in the cup by fitting the rod into the slot in the tower (it is not necessary to tighten too much); 6. Fix the handlebars with the risers that come with the kit using the screws provided; 7. Tighten the tower side screw.

WR 250 WR 450 YZ 450 DEBAIXO DO GUIDA■O

WR 250 / WR 450 / YZ 450 1. Remove the table; 2. Position the clamp on the bearing box without tightening the screws; 3. Replace the table and attach the glass to the central screw without a washer; 4. Attach the tower to the clamp, ensuring that the half-moon shape is directed towards the handlebars; 5. Fix the shock absorber to the cup (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower; 6. Align the clamp visually in the correct and definitive position, tighten the Allen head screw and only then tighten the 4 Allen head screws little by little on each screw until achieving the ideal tightness; 7. Tighten the tower side screw; 8. Replace the handlebar using the handlebar extenders that come with the kit.

XB 12

XB 12X ULISSES

XB 12 R

XB 9

XJ 6

XJ 6 2010 2016

XJ 6 FAT BAR

XJ6 – FAT BAR 1. Soltar o guidão e os riser s, 2. Reafixar os riser s e guidão utilizando o alongador e paraf usos que acompanham o kit, 3. Soltar a porca central da mesa e retirar a arruela, 4. Afixar o copo no parafuso central da mesa utilizando a porca que acompanha o kit SEM a arruela; 5. Remove the screws and washers that fix the tank and place the support in the shape of an inverted “T” with the screws that come with the kit, observing that the inclination of the support must be towards the tank; 6. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (it is not necessary to tighten too much); 7. Tighten the side screw of the tower fixed to the frame; 8. Replace the handlebar using the shims that come with the kit to raise the handlebar.

XRE 300

XRE 300 FAT BAR

XTZ 250 LANDER

XTZ 660 TENERE■

XTZ 660 - TENERÉ 1. Release the handlebars and remove the risers; 2. Drill the head of the security screws that secure the ignition to the frame and remove them; 3. Use the boomerang-shaped screw to secure the ignition; 4. Fix the shock absorber base together with the risers on the table; 5. Fix the shock absorber to the base installed on the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod; 6. Fix the handlebars on the risers that come with the kit, previously installed on the table.

XT 600

XT 600 1. Release the handlebars; 2. Loosen the central nut of the table and remove the washer; 3. Fix the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer; 4. Fix the clamp under the dust cover in the bearing box, aligning the tower in the center of the motorcycle; 5. Fix the shock absorber in the cup by fitting the rod to the slot in the tower (it is not necessary to tighten it too much); 6. Replace the handlebars on the risers and secure using the screws that come with the kit; 7. Tighten the screw on the side of the tower.

XT 660 2005 2016

XT 660 2005 2016 FAT BAR

YZF R1 2000 2002

YZF R1 2003 2006

YZF R1 2007 2008

YZF R1 2009 2014

YZF R3

YZF R6 1999 2002

YZF R6 2006 2011

ZX 10R 2008 2010

ZX 10R 2011 2016

ZX 14

ZX 636 2013 2016

ZX 6 2005 A 2006

ZX 6 2005 TO 2006 1. Loosen the table nut and remove the washer 2. Install the cup that comes with the kit using the original nut WITHOUT the washer; 3. Loosen the screws that fix the tank by removing the washers and fix it again using the base of the tower with the screws that come with the kit; 4. Fix the tower on the base; 5. Fix the shock absorber to the cup by fitting the rod to the slot in the tower (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 8. Tighten the tower side screw

Z 1000 ATE 2014

Z 1000 A PARTIR 2015 VARETA

Z 300

Z 300 1. Release the handlebars; 2. Remove the table by removing the central screw and loosening the clamps that fix the canes; 3. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock); 4. Remove the dust cover from the bearings; 5. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it; 6. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear; 7. Replace the table; 8. Fix the handlebars using the table that comes with the kit; 9. Fix the shock absorber on the table by fitting the rod into the slot (it is not necessary to tighten it too much); 10. Align and position the clamp so that it does not rub against the dust cover and tighten the screws to secure it; 11. Tighten the tower side screw.

Z 400

Z 400 1. Loosen the crescents that fix the handlebars; 2. Fix the handlebars to the table using the screws that come with the kit; 3. Move the tank aside to access the holes in the frame; 4. Fix the base of the tower to the frame and then fix the tower on it. 5. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 6. Tighten the side screw.

Z 400 FAT BAR

Z 400 – FAT BAR 1. Loosen the half-moons that fix the handlebars; 2. Attach the FAT BAR handlebar using the table and handlebar extenders that come with the kit; 3. Move the tank aside to access the holes in the frame; 4. Fix the base of the tower to the frame and then fix the tower on it. 5. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much); 6. Tighten the side screw.

Z 650

Z 650 1. Remove the plastic cover from the tank; 2. Remove the plastic ignition cover; 3. Remove the 2 screws closest to the tank that fix the handlebars; 4. Fix the support arm with the screws that come with the kit; 5. Remove the ignition screws and fix the tower base in place; 6. Center the shock absorber inside the clamp; 7. Tighten the clamp screws; 8. Fix the clamp rod with the M8 screw to the cross member tower; 9. Cut the plastic cover from the ignition key to fit it back onto the motorcycle; 10. Replace the plastic cover on the ignition key and tank.

Z 750

Z 750 1. Remove the table, headlight and panel; 2. Remove the 2 bearing nuts, the spider and the bearing cover; 3. Place the clamp under the bearing cover; 4. Replace the bearing nuts, the table, the headlight and the panel; 5. Fix the “T” piece to the clamp using the screws that come with the kit; 6. Fix the handlebars with the base that comes with the kit using the original screws; 7. Fix the steering damper on the base (it is not necessary to tighten too much) by fitting the rod to the pin; 8. Adjust the height of the pin (the pin is a movable part) until it is flush with the rod, applying light taps to the top of it.

Z 750 FAT BAR

Z 750 – FAT BAR 1. Remove the handlebars, risers and stem; 2. Remove the 2 bearing nuts, the spider and the bearing cover; 3. Place the clamp under the bearing cover, without tightening the screws (leave them loose); 4. Replace the bearing nuts and the table; 5. Fix the cup to the central nut of the table; 6. Place the risers that come with the kit; 7. Fix the shock absorber on the cup (it is not necessary to tighten it too much) by fitting the rod to the slot in the tower; 8. Fix the handlebars with the bushings that come with the kit; 9. Position the clamp so that it is as close as possible to the bearing dust cover without scraping it; 10. Tighten the clamp screws and the tower side screw.

Z 750 S ABS

Z 800 2013 2016

Z 900

Z 900 1. Remove the plastic covers on the sides of the tank (right and left); 2. Remove the plastic ignition cover; 3. Remove the front acrylic visor; 4. Remove the panel to make room to loosen the screws that fix the handlebars; 5. Replace the screws, fixing the cross member, so that the cross member tower is facing the right side; 6. Loosen the screws that fix the tank to the frame; 7. Fix the boomerang-shaped support over the straps that fix the tank to the frame; 8. Position the shock absorber inside the clamp, so that the shock absorber is centered; 9. Tighten the clamp screws; 10. Fix the clamp rod with the M8 screw to the cross member tower; 11. Cut the plastic cover from the ignition key to fit it back onto the motorcycle, as shown in the image below; 12. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

Z 900 2

Z 900 1. Remove the side plastic covers from the tank (right and left); 2. Remove the plastic ignition cover; 3. Remove the front acrylic visor; 4. Remove the panel to make room to loosen the screws that fix the handlebars; 5. Replace the screws fixing the cross member so that the cross member's tower is facing the right side; 6. Loosen the screws that fix the tank to the frame; 7. Fix the boomerang-shaped support over the straps that fix the tank to the frame; 8. Position the shock absorber in the center of the clamp; 9. Tighten the clamp screws; 10. Fix the clamp rod with the M8 screw to the cross member tower; 11. Cut the plastic ignition cover to fit it back onto the motorcycle as shown in the image below; 12. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

Z 900 2020 EM DIANTE

Z 900 FROM 2020 1. Remove the side plastic covers from the tank (right and left); 2. Remove the plastic ignition cover; 3. Attach the “L” shaped piece to the right mirror clamp; 4. Loosen the screws that fix the tank to the frame; 5. Fix the boomerang-shaped support over the straps that fix the tank to the frame; 6. Position the shock absorber in the center of the clamp; 7. Tighten the clamp screws; 8. Fix the shock absorber rod to the “L” shaped piece previously fixed to the rear view mirror; 9. Cut the plastic ignition cover to fit it on the motorcycle as shown in the image below; 10. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

Z 900 RS

Z 900 RS 1. Release the handlebars to access the central nut of the stem; 2. Remove the table’s central nut and washer; 3. Fix the cup with the original nut WITHOUT the washer; 4. Loosen the tank screws and fix the tower at that point, centering the tower; 4. Fix the base of the support to the frame. To do this, remove the screw that fixes the plate and also remove the nut; 5. Replace the tank; 7. Fix the shock absorber to the table fixed over the handlebars and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars; 8. Tighten the tower side screw