MAXRACING

DEALER SUPPORT PORTAL

INSTALLATION MANUALS

TABLE OF CONTENTS

Click any model below to jump directly to its manual.

BUELL 1125 R
KTM 300 SX
KTM 350 EXC F 350 SX F
690 ENDURO
KTM 990 ADVENTURE
SUZUKI BANDIT 1200
SUZUKI BANDIT 1200 E 1250 FAT BAR
SUZUKI BANDIT 1200 FAT BAR
SUZUKI BANDIT 1200 S
SUZUKI BANDIT 1250S
SUZUKI BANDIT 1250 2008 2013
SUZUKI BANDIT 1250 FA 2014 2016
SUZUKI BANDIT 600N
SUZUKI BANDIT 650N
BLT C500
MV AGUSTA BRUTALE 800
SUZUKI B KING
HONDA CBR 1000 RR 2007 A 2016
HONDA CBR 500 R 2014 2016
HONDA CBR 600 F
HONDA CBR 600 F2 F3 F4
HONDA CBR 600 RR 2003 2006
HONDA CBR 600 RR 2007 A 2016
HONDA CBR 650 F 2015 2016
HONDA CBR 650 R
HONDA CBR 900 RR
HONDA CBR 929 RR
HONDA CBR 954 RR
HONDA CBX 250 TWISTER 2002 2014
HONDA CB 1000R 2012 2016
HONDA CB 1000 NEO CAFE■
HONDA CB 1300 SF

HONDA CB 300R 2009 2015
HONDA CB 500F 2014 2016
HONDA CB 500X 2014 2016
HONDA CB 500X ATE■ 2019
HONDA CB 500 1998 2005
HONDA CB 500 2020 EM DIANTE
HONDA CB 600 F HORNET 2005 2007 ATUAL
HONDA CB 600 F HORNET 2005 2007 NOVO FAT BAR
HONDA CB 600 F HORNET 2008 2014
HONDA CB 600 F HORNET 2008 2014 FAT BAR
HONDA CB 650 F 2015 2016
HONDA CB 650 F FAT BAR
HONDA CB 650 R
HONDA CB TWISTER 2015 2016
CG 150
CG 160 START
COMET GTR 250
COMET GTR 650
COMET GT 250 NAKED
COMET GT 650 NAKED
HONDA CRF 1000 L AFRICA TWIN
HONDA CRF 250
HONDA CRF AFRICA TWIN1100
TRIUMPH DAYTONA 675R 2013 2016
TRIUMPH DAYTONA 675 2008 2012
TRIUMPH DAYTONA 955
SUZUKI DL 1000 V STROM 2003 2014
SUZUKI DL 1000 V STROM 2015 2016
SUZUKI DL 650 V STROM 2008 2014
SUZUKI DRZ 400 E
DUCATI 959
DUCATI V4
HARLEY DAVIDSON DYNA GLIDE
ER6N VARETA
KAWASAKI ER 6N 2010 2012
KTM EXC 250 EXC 350 EXC 450
MV AGUSTA F3
YAMAHA FACTOR 125

YAMAHA FACTOR 150
YAMAHA FAZER 1000
YAMAHA FAZER 150
YAMAHA FAZER 250 2018 NORMAL E FAT BAR
YAMAHA FAZER 250 FAT BAR 2008 2016
YAMAHA FAZER 600 2007 2009
HUSQVARNA FC 450
BMW F 650 GS TWIN ATE■ 2010
BMW F 800 GS
SUZUKI GLADIUS
BMW GSR 750 A 2011 2016
BMW GSR 750 A ZA FAT BAR
BMW GSR 750 ZA 2011 2016
SUZUKI GSX 1000 R SRAD 2000 2007
SUZUKI GSX 1000 R SRAD 2008 2010
SUZUKI GSX 1000 R SRAD 2011 2017
SUZUKI GSX 650 F 2011 2013
SUZUKI GSX 750 R SRAD 1998 2007
SUZUKI GSX 750 R SRAD 2011 2014
SUZUKI GSX 750 R SRAD 2015 2016
SUZUKI GSX 750 SRAD 2008 2010
SUZUKI GSX 750 S A PARTIR 2018
SUZUKI GSX 750 S VARETA
SUZUKI GSX S 1000 A F FA
SUZUKI GSX S 750
SUZUKI GSX S 750 2018
BMW GS 500 E 2004 2009
BMW G 310 GS
SUZUKI HAYABUSA 2005
SUZUKI HAYABUSA 2009 2014
HORNET 2005 2007 NOVO
HORNET 2005 2007 NOVO FAT BAR
YAMAHA HYPERMOTARD 1100
YAMAHA HYPERMOTARD 796
YAMAHA HYPERMOTARD 821
DUCATI HYPERSTRADA
KTM 1050 1090 1190 1290
KTM 990 ADVENTURE

YAMAHA KTM SMT 990
YAMAHA LANDER
YAMAHA LANDER FAT BAR
HARLEY DAVIDSON LOW RIDER
KAWASAKI MONSTER 1100
KAWASAKI MONSTER 1200
KAWASAKI MONSTER 696
KAWASAKI MONSTER 796
KAWASAKI MONSTER 797
KAWASAKI MONSTER 821
YAMAHA MT 03
YAMAHA MT 03 660 CC
YAMAHA MT 03 FAT BAR
YAMAHA MT 07
YAMAHA MT 09 2014 2016
YAMAHA MT 09 TRACER
YAMAHA MT 09 TRACER ATUAL
DUCATI MULTISTRADA 2016 2017
DUCATI MULTISTRADA ATE■ 2015
MV AGUSTA RIVALE
HONDA NC 700 NC 750
YAMAHA NEXT 250
KAWASAKI NINJA 1000 2010 20013
KAWASAKI NINJA 250 2008 2012
KAWASAKI NINJA 300 2013 2016
KAWASAKI NINJA 400
KAWASAKI NINJA 650 R 2010 2012
KAWASAKI NINJA 650 VARETA
HONDA NX 400 FALCON
DUCATI PANIGALI 1199
DUCATI PANIGALI 1299
YAMAHA RD 350
BMW R 1200 GS ATE■ 2012
BMW R 1200 GS A PARTIR 2013
TRIUMPH SPEED TRIPLE 1050 2013 2016
KAWASAKI STREER TRIPLE 675 2013 2016
TRIUMPH STREET TRIPLE 675
TRIUMPH STREET TRIPLE 765

YAMAHA SUPER TENERE 1200
YAMAHA SUPER TENERE 1200 2015 EM DIANTE
SUZUKI SV 650
BMW S 1000 RR 2012 2017
BMW S 1000 RR ATE■ 2011
BMW S 1000 R NAKED
BMW S 1000 XR
YAMAHA TENERE 250
YAMAHA TENERE■ 250
YAMAHA TENERE■ 250 FAT BAR
KAWASAKI TIGER 1050 SPORT
KAWASAKI TIGER 1200 ATUAL
KAWASAKI TIGER 800
KAWASAKI TIGER 800XC 2014 2016
KAWASAKI TIGER 800 ATUAL
KAWASAKI TIGER 800 XCX 2014 2016
KAWASAKI TIGER 800 XRX
KAWASAKI TIGER 900
KAWASAKI TIGER EXPLORE 1200 2014 2016
HONDA TRANSALP 700
HONDA TRANSALP 700 ATUAL
KAWASAKI VERSYS 1000 ATE 2015
KAWASAKI VERSYS 1000 A PARTIR 2016
KAWASAKI VERSYS 300
KAWASAKI VERSYS 650
KAWASAKI VERSYS 650 ATUAL
YAMAHA VMAX 1200
KAWASAKI WR 250 WR 450 YZ 450 DEBAIXO DO GUIDA■O
BUELL XB 12
BUELL XB 12X ULISSES
BUELL XB 12 R
BUELL XB 9
YAMAHA XJ 6
YAMAHA XJ 6 2010 2016
YAMAHA XJ 6 FAT BAR
HONDA XRE 300
HONDA XRE 300 FAT BAR
YAMAHA XTZ 250 LANDER

YAMAHA XTZ 660 TENERE■
YAMAHA XT 600
YAMAHA XT 660 2005 2016
YAMAHA XT 660 2005 2016 FAT BAR
YAMAHA YZF R1 2000 2002
YAMAHA YZF R1 2003 2006
YAMAHA YZF R1 2007 2008
YAMAHA YZF R1 2009 2014
YAMAHA YZF R3
YAMAHA YZF R6 1999 2002
YAMAHA YZF R6 2006 2011
KAWASAKI ZX 10R 2008 2010
KAWASAKI ZX 10R 2011 2016
KAWASAKI ZX 14
KAWASAKI ZX 636 2013 2016
KAWASAKI ZX 6 2005 A 2006
KAWASAKI Z 1000 ATE 2014
KAWASAKI Z 1000 A PARTIR 2015 VARETA
KAWASAKI Z 300
KAWASAKI Z 400
KAWASAKI Z 400 FAT BAR
KAWASAKI Z 650
KAWASAKI Z 750
KAWASAKI Z 750 FAT BAR
KAWASAKI Z 750 S ABS
KAWASAKI Z 800 2013 2016
KAWASAKI Z 900
KAWASAKI Z 900 2
KAWASAKI Z 900 2020 EM DIANTE
KAWASAKI Z 900 RS

BUELL 1125 R

1. Loosen the central nut of the table and secure the nut with a square fitting;

2. Position the cup on this central nut and secure it with the nut that comes with the kit;

3. Remove the screw that fixes the tank cover on the right side of the motorcycle;

4. Attach the tower that comes with the kit at this point;

5. Install the shock absorber on the cup previously fixed to the table (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the rod into the slot in the tower;

6. Tighten the tower side screw.

↑ Back to Table of Contents

KTM 300 SX

1. Release the handlebars and remove the risers;

2. Fix the clamp on the bearing box post under the dust cover;

3. Fix the shock absorber base on the table with the screws that come with the kit;

4. Fix the shock absorber on the table (No need to tighten it too much);

5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws;

6. Tighten the tower side screw.

↑ Back to Table of Contents

KTM 350 EXC F 350 SX F

1. Release the handlebars and remove the risers;

2. Fix the clamp on the bearing box post under the dust cover;

3. Fix the shock absorber base on the table with the screws that come with the kit;

4. Fix the shock absorber on the table (No need to tighten it too much);

5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws;

6. Tighten the tower side screw.

↑ Back to Table of Contents

690 ENDURO

1. Remove the original handlebars and risers;

2. Remove the rubber finish that surrounds the ignition;

3. Attach the base (silver) that comes with the kit to the table;

4. Position the boomerang-shaped piece under the frame tubes and use the larger piece to fix it with the screws that come with the kit, fitting its hole into the ignition;

5. Fix the tower with the screws that come with the kit;

6. Fix the shock absorber to the previously fixed base, fitting the rod slot to the tower pin;

7. Adjust the height of the pin with light taps and tighten the 2 screws on the side of the tower;

8. Replace the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

KTM 990 ADVENTURE

1. Remove 2 plastic covers positioned between the tank and the table;

2. Attach the tower in the shape of an inverted “T” at this point with the recess facing the table;

3. Release the handlebars and remove the plastic covers positioned between the handlebars and the headlight;

4. Attach the half-moon-shaped base at this point with the recess facing the handlebars;

5. On the base, fix the steering damper by fitting the slot in the rod to the pin of the tower fixed to the frame (it is not necessary to tighten it too much);

6. Reattach the handlebars.

↑ Back to Table of Contents

SUZUKI BANDIT 1200

1. Remove the 2 upper half-moons from the riser;

2. Fix the base with the screws that come with it;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the nuts under the frame finishing plate;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI BANDIT 1200 E 1250 FAT BAR

1. Loosen the half-moons that fix the handlebars and remove them;

2. Attach the FAT BAR handlebar using the table and handlebar extenders that come with the kit;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the beam that comes with the kit under the frame's finishing plate;

6. Fix the shock absorber on the table by fitting the rod into the slot in the support (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw);

7. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI BANDIT 1200 FAT BAR

1. Remove the 2 upper half-moons from the riser;

2. Install the stretchers;

3. Fix the base with the screws that come with the kit;

4. Position the piece in the shape of an inverted T and mark the positions of the holes;

5. Drill 2 6 mm holes in the frame's finishing plate;

6. Fix the T-piece with the nuts under the frame's finishing plate;

7. Fix the shock absorber to the base fixed to the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod;

8. Level the pin to the rod with light taps;

9. Tighten the side screws to secure the pin.

↑ Back to Table of Contents

SUZUKI BANDIT 1200 S

1. Remove the 2 upper half-moons from the riser;

2. Fix the handlebars using the table that comes with the kit;

3. Remove 2 finishes from the holes on the side of the frame;

4. Release the tank and move it away;

5. Position the aluminum nut inside the frame and fix the tower clips in an inverted “T” shape on both sides, without tightening them definitively;

6. Fix the tower in an inverted “T” shape to the clips;

7. Fix the shock absorber on the table (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower;

8. Align the parts fixed to the frame and tighten the screws;

9. Tighten the side screw I to secure the rod and replace the tank.

↑ Back to Table of Contents

SUZUKI BANDIT 1250S

1. Remove the 2 upper half-moons from the riser;

2. Fix the handlebars using the table that comes with the kit;

3. Remove 2 rubber covers from the holes on the side of the frame;

4. Release the tank and move it away;

5. Position the aluminum nut inside the frame and fix the tower clips in an inverted “T” shape on both sides, without tightening them definitively;

6. Fix the tower in an inverted “T” shape to the clips;

7. Fix the shock absorber on the table (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower;

8. Align the parts fixed to the frame and tighten the screws definitively; Tighten the side screw to secure the rod and replace the tank.

↑ Back to Table of Contents

SUZUKI BANDIT 1250 2008 2013

1. Remove the 2 upper half-moons from the riser;

2. Fix the base with the screws that come with it;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the nuts under the frame finishing plate;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI BANDIT 1250 FA 2014 2016

1. Remove the 2 upper half-moons from the riser;

2. Fix the base with the screws that come with it;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the nuts under the frame finishing plate;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI BANDIT 600N

1. Remove the 2 upper half-moons from the riser;

2. Fix the base with the screws that come with it;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the nuts under the frame finishing plate;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI BANDIT 650N

1. Remove the 2 upper half-moons from the riser;

2. Fix the base with the screws that come with the kit;

3. Position the piece in the shape of an inverted T and mark the positions of the holes;

4. Drill 2 6 mm holes in the frame's finishing plate;

5. Fix the T-piece with the nuts under the frame finishing plate;

6. Fix the shock absorber to the base fixed to the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod;

7. Level the pin to the rod with light taps;

8. Tighten the side screws to secure the pin.

↑ Back to Table of Contents

BLT C500

1. Position the clamp on the seatpost WITHOUT tightening the screws;
2. Remove the 2 upper screws that fix the handlebars;
3. Fix the cup that comes with the kit in this location with the motorcycle screws;
4. Fix the shock absorber on the cup;
5. Align the clamp with the longitudinal axis of the motorcycle so that the shock absorber rod fits into the clamp tower;
6. Tighten all screws.

↑ Back to Table of Contents

MV AGUSTA BRUTALE 800

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the table using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Fix the feet to the frame using the crosspiece for alignment and remove the crosspiece after assembling them;

5. Attach the tower to the feet, ensuring that the recess faces the table;

6. Fix the shock absorber on the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the tower side screw.

↑ Back to Table of Contents

SUZUKI B KING

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Loosen 2 M5 screws that fix the plastic finish to the frame;

5. Attach the tower in the shape of an inverted “T” to the holes in the finish;

6. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

7. Tighten the tower side screw;

8. Attach the handlebars.

↑ Back to Table of Contents

HONDA CBR 1000 RR 2007 A 2016

1. Loosen the table nut and remove the washer;

2. Fix the cup that comes with the kit with the original nut; To do this, the pipe wrench must be turned to reduce the external diameter to fit inside the cup.

3. Remove the plastic cover from the tank;

4. Disconnect and remove the original shock absorber;

5. Attach the support that comes with the kit using the same fixing points as the original shock absorber;

6. Screw the shock absorber onto the cup installed on the table, fitting the support rod attached to the frame (it is not necessary to tighten it too much);

7. Tighten the side screw. NOTE: To eliminate the original steering damper alarm on the panel after removing it, simply connect one wire to the other.

↑ Back to Table of Contents

HONDA CBR 500 R 2014 2016

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

HONDA CBR 600 F

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CBR 600 F2 F3 F4

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CBR 600 RR 2003 2006

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CBR 600 RR 2007 A 2016

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Completely remove the original steering damper;

4. Attach the “U” shaped piece to the frame;

5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

6. Tighten the screws on the sides to avoid loosening of the rod;

7. Replace the fairings. NOTE: To eliminate the original steering damper alarm on the panel after removing it, simply connect one wire to the other.

↑ Back to Table of Contents

HONDA CBR 650 F 2015 2016

1. Loosen the table nut;

2. Remove the table and loosen the bearing nut and remove the bearing cover;

3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

4. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

5. Replace the table and place the cup that comes with the installation kit, securing it with the original nut without the washer;

6. Fix the shock absorber on the cup previously fixed to the table (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the rod into the slot in the tower;

7. Position the clamp definitively and tighten the screws;

8. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CBR 650 R

1. Loosen the table nut and remove the washer;

2. Fix the cup that comes with the kit using the nut WITHOUT the washer;

3. Fix the clamp on the bearing box, aligning the tower;

4. Install the shock absorber to the cup by fitting the rod to the slot in the tower (DO NOT over-tighten the screws);

5. Tighten the tower side screws.

↑ Back to Table of Contents

HONDA CBR 900 RR

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

HONDA CBR 929 RR

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

HONDA CBR 954 RR

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

HONDA CBX 250 TWISTER 2002 2014

1. Loosen the half moons that fix the handlebars;

2. Replace it with the base that comes with the kit using the original screws;

3. Fix the clamp underneath the steering gear bearing cover, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards);

4. Fix the tower to the clamp;

5. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten it too much), fitting the stem into the slot in the tower;

6. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 1000R 2012 2016

1. Remove the table that fixes the handlebars and fix it again with the base that comes with the kit;

2. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

3. Fix the shock absorber to the base by fitting the support pin into the slot in the shock absorber rod (it is not necessary to tighten it too much);

4. Level the pin to the rod with light taps;

5. Tighten the side screws to secure the pin.

↑ Back to Table of Contents

HONDA CB 1000 NEO CAFE

1. Remove the original table on the handlebars and reattach it with the base that comes with the kit;

2. Remove the plastic cover that covers the ignition;

3. Move the tank aside to access the ignition assembly;

4. Position the piece in an inverted “U” shape in the space between the ignition and the table;

5. Fix the inverted “U” with the 2 “L” shaped pieces on the round ignition beam;

6. Fix the shock absorber to the base on the handlebars by fitting the shock absorber rod to the inverted “U” pin;

7. Replace the tank;

8. Make a cut in the plastic ignition cover to fit it into the original space.

↑ Back to Table of Contents

HONDA CB 1300 SF

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Move the tank away;

4. Separate the 3 pieces that make up the inverted fork-shaped support that will be fixed to the frame.

5. Fix each of the side pieces of the support through the holes on the sides of the frame to the front of the tank, positioning the nuts on the internal side, observing the positioning of the support angle in relation to the frame;

6. Fix the third part of the support between the two previously fixed parts of the support;

7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 300R 2009 2015

1. Loosen the half moons that fix the handlebars;

2. Replace it with the base that comes with the kit using the original screws;

3. Fix the clamp underneath the steering gear bearing cover, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards);

4. Fix the tower to the clamp;

5. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten it too much), fitting the stem into the slot in the tower;

6. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 500F 2014 2016

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 500X 2014 2016

1. Release the base that fixes the handlebars;

2. Fix the handlebars with the base that comes with the kit using the included screws;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber on the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw of the tower previously fixed to the frame.

↑ Back to Table of Contents

HONDA CB 500X ATE■ 2019

1. Release the base that fixes the handlebars;

2. Fix the handlebars with the base that comes with the kit using the included screws;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber on the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw of the tower previously fixed to the frame.

↑ Back to Table of Contents

HONDA CB 500 1998 2005

1. Release the handlebars;

2. Attach the table that comes with the kit to the handlebars;

3. Move the tank away;

4. Fix the base of the support to the frame. To do this, remove the screw that fixes the plate and also remove the nut;

5. Attach the tower to the base previously fixed to the frame so that the tower's chamfers face the handlebars;

6. Replace the tank;

7. Fix the shock absorber to the table fixed over the handlebars and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

8. Tighten the tower side screw

↑ Back to Table of Contents

HONDA CB 500 2020 EM DIANTE

1. Release the handlebars;

2. Loosen the central nut and remove the washer;

3. Fix the cup to the central screw of the table using the original nut and washer;

4. Loosen the screws that fix the tank to the frame;

5. Fix the inverted T-shaped tower using the screws that come with the kit;

6. Fix the shock absorber on the cup (it is not necessary to tighten it too much), fitting the rod to the slot in the tower, and tighten the screw on the side of the tower;

7. Replace the handlebar using the shims that come with the handlebar raising kit.

↑ Back to Table of Contents

HONDA CB 600 F HORNET 2005 2007 ATUAL

1. Remove the bushings that fix the handlebars;

2. Fix the handlebars with the table that comes with the kit;

3. Move the tank away to access the panel (it is not necessary to remove the tank);

4. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit;

5. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

↑ Back to Table of Contents

HONDA CB 600 F HORNET 2005 2007 NOVO FAT BAR

1. Remove the bushings that fix the handlebars and remove them;

2. Attach the risers (handlebar extenders)

3. Fix the handlebars over the risers with the table that comes with the kit;

4. Move the tank aside to access the panel (it is not necessary to remove the tank);

5. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit;

6. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

↑ Back to Table of Contents

HONDA CB 600 F HORNET 2008 2014

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 600 F HORNET 2008 2014 FAT BAR

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

HONDA CB 650 F 2015 2016

1. Release the handlebars;

2. Remove the table and loosen the bearing nut and remove the bearing cover;

3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

4. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

5. Replace the table and tighten;

6. Re-attach the handlebars to the base that comes with the kit using the M8x30 screws;

7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

8. Position the clamp definitively and tighten the screws;

9. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CB 650 F FAT BAR

1. Release the handlebars;

2. Remove the original risers;

3. Remove the table, loosen the bearing nut and remove the bearing cover;

4. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

5. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

6. Replace the table and tighten;

7. Place the risers that come with the kit;

8. Reattach the handlebars to the base that comes with the kit using the M8x 30 screws;

9. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

10. Position the clamp definitively and tighten the screws;

11. Tighten the tower side screw.

↑ Back to Table of Contents

HONDA CB 650 R

1. Remove the original table on the handlebars and reattach it with the base that comes with the kit;

2. Remove the plastic cover that covers the ignition;

3. Move the tank aside to access the ignition assembly;

4. Position the piece in an inverted “U” shape in the space between the ignition and the table;

5. Fix the inverted “U” with the 2 “L” shaped pieces on the round ignition beam,

6. Fix the shock absorber to the base on the handlebars by fitting the shock absorber rod to the inverted “U” pin;

7. Replace the tank;

8. Make a cut in the plastic ignition cover to fit it into the original space.

↑ Back to Table of Contents

HONDA CB TWISTER 2015 2016

1. Loosen the half moons that fix the handlebars;

2. Replace it with the base that comes with the kit using the original screws;

3. Fix the clamp underneath the steering gear bearing cover, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards);

4. Fix the tower to the clamp;

5. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten it too much), fitting the stem into the slot in the tower;

6. Tighten the side screw.

↑ Back to Table of Contents

CG 150

1. Loosen the half moons that fix the handlebars;

2. Replace it with the base that comes with the kit using the original screws;

3. Fix the clamp underneath the steering gear bearing cover, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards);

4. Fix the tower to the clamp;

5. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten it too much), fitting the stem into the slot in the tower;

6. Tighten the side screw.

↑ Back to Table of Contents

CG 160 START

1. Release the handlebars;

2. Remove the table and loosen the bearing nut and remove the bearing cover;

3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

4. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

5. Replace the table and tighten;

6. Reattach the handlebars to the base that comes with the kit using the M8x 25 screws;

7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

8. Position the clamp definitively and tighten the screws;

9. Tighten the tower side screw.

↑ Back to Table of Contents

COMET GTR 250

1. Remove the nut and washer from the table;

2. Fix the cup with the original nut without the washer;

3. Fix the tower in the two holes in the clamp with a firm grip;

4. Fix the clamp to the seatpost, preventing it from scraping the bearing dust cover;

5. Fix the shock absorber on the cup using the screws that make up the kit, fitting the rod into the slot;

6. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

COMET GTR 650

1. Remove the nut and washer from the table;

2. Fix the cup with the original nut without the washer;

3. Fix the tower in the two holes in the clamp with a firm grip;

4. Fix the clamp to the seatpost, preventing it from scraping the bearing dust cover;

5. Fix the shock absorber on the cup using the screws that make up the kit, fitting the rod into the slot;

6. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

COMET GT 250 NAKED

1. Remove the table that fixes the handlebars and fix it again with the base that comes with the kit;

2. Fix the cup with the original nut without the washer;

3. Fix the tower in the two holes in the clamp with a firm grip;

4. Fix the clamp to the seatpost, preventing it from scraping the bearing dust cover;

5. Fix the shock absorber on the cup using the screws that make up the kit, fitting the rod into the slot;

6. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

COMET GT 650 NAKED

1. Remove the table that fixes the handlebars and fix it again with the base that comes with the kit;

2. Fix the cup with the original nut without the washer;

3. Fix the tower in the two holes in the clamp with a firm grip;

4. Fix the clamp to the seatpost, preventing it from scraping the bearing dust cover;

5. Fix the shock absorber on the cup using the screws that make up the kit, fitting the rod into the slot;

6. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

HONDA CRF 1000 L AFRICA TWIN

1. Loosen the half moons that fix the handlebars;

2. Remove the handlebars to access the central nut of the table;

3. Remove the central nut;

4. Secure the cup that comes with the kit with the original nut;

5. Remove the screw that fixes the tank to the frame;

6. Fix the tower to the frame in such a way that the slots in the tower fit the plastic tabs on the tank support;

7. Fix the shock absorber to the cup by fitting the rod into the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

8. Tighten the tower side screw; Replace the handlebars.

↑ Back to Table of Contents

HONDA CRF 250

1. Release the handlebars and remove the original risers;

2. Remove the table;

3. Position the clamp WITHOUT final tightening;

4. Replace the table;

5. Fix the base that comes with the kit on the table;

6. Fix the shock absorber on the table by fitting its rod into the previously installed clamp tower (no excessive tightening is necessary);

7. Align the clamp and definitively tighten the screw on the clamp and on the side of the tower;

8. Attach the risers that come with the kit and replace the handlebars.

↑ Back to Table of Contents

HONDA CRF AFRICA TWIN1100

1. Loosen the half-moons that fix the handlebars;

2. Remove the handlebars to access the central nut of the table;

3. Remove the central nut;

4. Secure the cup that comes with the kit with the original nut;

5. Remove the screw that fixes the tank to the frame;

6. Fix the tower to the frame so that the slots in the tower fit into the plastic tabs on the tank support;

7. Attach the shock absorber to the cup by fitting the rod to the tower pin;

8. Adjust the height of the pin until it is flush with the rod (this pin is movable), tapping the top of it lightly.

↑ Back to Table of Contents

TRIUMPH DAYTONA 675R 2013 2016

1. Loosen the table nut and remove the washer;

2. Install the cup, securing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

TRIUMPH DAYTONA 675 2008 2012

1. Loosen the table nut and remove the washer;

2. Install the cup, securing it with the nut from the kit WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

TRIUMPH DAYTONA 955

1. Remove the nut and washer from the table;

2. Fix the cup that comes with the kit to the table with the nut provided;

3. Move the tank aside to access the threaded hole in the frame;

4. Fix the threaded pin in the M6 ■■threaded hole in the frame;

5. Place the M6 ■■nut under the frame to complete the pin fixation;

6. Replace the tank, fixing it using the pin with the M10 washer and nut;

7. Fix the shock absorber on the cup previously installed on the table, fitting the slot in the rod to the pin fixed to the frame.

↑ Back to Table of Contents

SUZUKI DL 1000 V STROM 2003 2014

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the plastic cover from the tank;

4. Remove the screw that fixes the tank to the frame;

5. Install the inverted “T” shaped support in the threaded hole;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

8. Replace the plastic tank cover.

↑ Back to Table of Contents

SUZUKI DL 1000 V STROM 2015 2016

1. Loosen the half-moons that fix the handlebars and remove them;

2. Loosen the table nut and remove the washer;

3. Fix the cup with the original nut without the washer with the recess facing the tank;

4. Loosen and remove the plastic cover from the tank;

5. Remove the screw that fixes the tank to the frame;

6. Install the inverted “T” shaped support in the threaded hole;

7. Fix the shock absorber on the cup previously fixed to the table nut, fitting the rod into the slot in the support (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

8. Tighten the tower side screw in an inverted “T” shape;

9. Replace the plastic tank cover;

10. Fix the handlebars using the handlebar extenders.

↑ Back to Table of Contents

SUZUKI DL 650 V STROM 2008 2014

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the plastic cover from the tank;

4. Remove the screw that fixes the tank to the frame;

5. Install the inverted “T” shaped support in the threaded hole;

6. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the side screw.

8. Replace the plastic tank cover.

↑ Back to Table of Contents

SUZUKI DRZ 400 E

1. Release the handlebars;

2. Attach the cup that comes with the kit to the central nut WITHOUT the washer;

3. Fix the clamp on the steering gear;

4. Place the risers that come with the kit in order to raise the handlebars;

5. Fix the shock absorber on the cup by fitting the pin into the groove in the rod (excessive tightening is not necessary);

6. Adjust the height of the pin until it is flush with the rod (the pin is movable), tapping the top of it lightly.

↑ Back to Table of Contents

DUCATI 959

1. Release the table;

2. Replace the original central nut with the nut that comes with the kit;

3. Fix the cup to the nut by tightening the side screws;

4. Remove the screws that secure the plastic cover around the ignition;

5. Fix the 2 threaded bushings that come with the kit in place;

6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much);

7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot;

8. Tighten the boomerang side screw.

↑ Back to Table of Contents

DUCATI V4

1. Release the table;

2. Replace the original central nut with the nut that comes with the kit;

3. Fix the cup to the nut by tightening the side screws;

4. Remove the screws that secure the plastic cover around the ignition;

5. Fix the 2 threaded bushings that come with the kit in place;

6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much);

7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot;

8. Tighten the boomerang side screw.

↑ Back to Table of Contents

HARLEY DAVIDSON DYNA GLIDE

1. Loosen the central nut of the table and remove the washer;

2. Attach the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

3. Remove the screw and washer that fix the tank and place the support in the shape of an inverted “T” with the screw that comes with the kit, observing that the support's inclination must be towards the table;

4. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (excessive tightening is not necessary);

5. Tighten the side screw of the tower fixed to the frame.

↑ Back to Table of Contents

ER6N VARETA

1. Remove the plastic cover from the tank;

2. Remove the screws that secure the ignition;

3. Attach the boomerang-shaped support to the ignition;

4. Attach the “L” shaped support to the front brake hose;

5. Fix the shock absorber rod on the “L” shaped support;

6. Position the shock absorber inside the clamp in such a way that it does not prevent the handlebars from fully steering on both sides;

7. Tighten the clamp screws;

8. Cut the plastic tank cover to fit it back onto the motorcycle;

9. Replace the plastic tank cover.

↑ Back to Table of Contents

KAWASAKI ER 6N 2010 2012

1. Dismantle the entire table, including removing the headlight;

2. Remove the 2 bearing nuts, the spider and the bearing cover;

3. Place the clamp under the bearing;

4. Put everything back;

5. Fix the “T” piece to the clamp using the screws that come with it;

6. Replace the base on the handlebars with the base that comes with the kit and secure it using the screws on the motorcycle itself;

7. Fix the shock absorber to the base by fitting the rod into the slot in the “T” support.

8. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

KTM EXC 250 EXC 350 EXC 450

1. Release the handlebars and remove the risers;

2. Fix the clamp on the bearing box post under the dust cover;

3. Fix the shock absorber base on the table with the screws that come with the kit;

4. Fix the shock absorber on the table (No need to tighten it too much);

5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws;

6. Tighten the tower side screw.

↑ Back to Table of Contents

MV AGUSTA F3

1. Remove the table and replace the central nut with the nut included in the kit;

2. Replace the table;

3. Remove 2 screws that fix the tank to the frame;

4. Fix the tower to the frame;

5. Fix the cup to the previously replaced nut by tightening the 4 side screws;

6. Fix the shock absorber head on the cup, fitting the rod to the slot in the support fixed to the frame;

7. NOTE: the screws that fix the shock absorber should only be tightened by 1/8 of a turn so as not to dent the internal chamber of the shock absorber;

8. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

YAMAHA FACTOR 125

1. Release the handlebars;

2. Remove the table and loosen the bearing nut and remove the bearing cover;

3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

4. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

5. Replace the table and tighten;

6. Reattach the handlebars to the base that comes with the kit using the M8x 25 screws;

7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

8. Position the clamp definitively and tighten the screws;

9. Tighten the tower side screw.

↑ Back to Table of Contents

YAMAHA FACTOR 150

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Position the half-moon on the frame, leaving the threads in the position closest to the table and fix it with the beam passing through the hole in the frame;

4. Fix the inverted T-shaped tower on the half-moon, observing the inclination, it must be directed towards the tank;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the tower (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA FAZER 1000

1. Release the handlebars;

2. Loosen the table nut;

3. Remove the washer;

4. Fix the glass to the table using the original nut, but WITHOUT the washer;

5. Loosen the tank screw and remove the washer;

6. Fix the fork-shaped support;

7. Fix the shock absorber on the cup with the screws that come with it (it is not necessary to tighten it too much);

8. Tighten the side screw of the fork support 9);

9. Replace the handlebars.

↑ Back to Table of Contents

YAMAHA FAZER 150

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Position the half-moon on the frame, leaving the threads in the position closest to the table and fix it with the beam passing through the hole in the frame;

4. Fix the inverted T-shaped tower on the half-moon, observing the inclination, it must be directed towards the tank;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the tower (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA FAZER 250 2018 NORMAL E FAT BAR

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original nut WITHOUT the washer;

4. Move the tank away;

5. Fix the support to the frame by positioning the cross member through the frame;

6. Replace the tank;

7. Fix the shock absorber to the cup by fitting the rod into the slot in the tower (it is not necessary to tighten it too much);

8. Tighten the tower side screw;

9. Replace the handlebar using the stretchers that come with the kit.

↑ Back to Table of Contents

YAMAHA FAZER 250 FAT BAR 2008 2016

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Attach the clamp to the steering bearing housing;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Attach the handlebars.

↑ Back to Table of Contents

YAMAHA FAZER 600 2007 2009

1. Release the handlebars from the risers;

2. Loosen the central nut of the table and remove the washer;

3. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

4. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit, keeping the clearance angles directed towards the table;

5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

6. Tighten the side screw.

7. Place the half moons that come with the kit on the risers in order to raise the handlebars.

8. Fix the handlebars using the screws that come with the kit.

↑ Back to Table of Contents

HUSQVARNA FC 450

1. Release the handlebars and remove the risers;
2. Fix the clamp on the bearing box post under the dust cover;
3. Fix the shock absorber base on the table with the screws that come with the kit;
4. Fix the shock absorber on the table (No need to tighten it too much);
5. Fix the handlebars using the risers that come with the kit with the M8 X 80 screws;
6. Tighten the tower side screw.

↑ Back to Table of Contents

BMW F 650 GS TWIN ATE■ 2010

1. Release the handlebars by removing the half moons;

2. Remove the risers by loosening the nuts under the table;

3. Remove the plastic cover from the tank;

4. Loosen the 2 ignition screws with a FIVE-point Torx TP 40 wrench with a central hole (not to be confused with the SIX-point Torx key, although similar, the six-point wrench does not fit);

5. Fix the boomerang-shaped support to the ignition assembly with the original screws;

6. Fix the base that comes with the kit on the table using the risers and longer screws sent;

7. Use the plate provided to align the risers in the correct position and remove the plate after alignment;

8. Fix the shock absorber on the base, fitting the slot in the rod to the support pin previously installed on the ignition assembly;

9. Replace the handlebars using the original screws;

10. Replace the plastic cover (ATTENTION: The side screws on the plastic cover will be unusable and should not be replaced).

↑ Back to Table of Contents

BMW F 800 GS

1. Release the handlebars by removing the half moons;

2. Remove the risers by loosening the nuts under the table;

3. Remove the plastic cover from the tank;

4. Loosen the 2 ignition screws with a FIVE-point Torx TP 40 wrench with a central hole (not to be confused with the SIX-point Torx key, although similar, the six-point wrench does not fit);

5. Fix the boomerang-shaped support to the ignition assembly with the original screws;

6. Fix the base that comes with the kit on the table using the risers and longer screws sent;

7. Use the plate provided to align the risers in the correct position and remove the plate after alignment;

8. Fix the shock absorber on the base, fitting the slot in the rod to the support pin previously installed on the ignition assembly;

9. Replace the handlebars using the original screws;

10. Replace the plastic cover (ATTENTION: The side screws on the plastic cover will be unusable and should not be replaced).

↑ Back to Table of Contents

SUZUKI GLADIUS

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient);

6. Tighten the side screw.

↑ Back to Table of Contents

BMW GSR 750 A 2011 2016

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Loosen the longest screw on the inverted fork-shaped support that comes with the kit;

4. Position this support in front of the plastic tank cover above the ignition assembly;

5. Replace the longer screw in its original place, but do not tighten it;

6. Tighten the smaller screw and only then tighten the larger screw;

7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

BMW GSR 750 A ZA FAT BAR

1. Loosen the half moons that fix the handlebars;

2. Attach the risers (handlebar extenders)

3. Fix the handlebars over the risers with the table that comes with the kit;

4. Loosen the longest screw on the inverted fork-shaped support that comes with the kit;

5. Position this support in front of the plastic tank cover above the ignition assembly;

6. Replace the longer screw in its original place, but do not tighten it;

7. Tighten the smaller screw and only then tighten the larger screw;

8. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

9. Tighten the side screw.

↑ Back to Table of Contents

BMW GSR 750 ZA 2011 2016

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Loosen the longest screw on the inverted fork-shaped support that comes with the kit;

4. Position this support in front of the plastic tank cover above the ignition assembly;

5. Replace the longer screw in its original place, but do not tighten it;

6. Tighten the smaller screw and only then tighten the larger screw;

7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 1000 R SRAD 2000 2007

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 1000 R SRAD 2008 2010

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screw that fixes the tank by removing the washer and fix it again using the inverted fork-shaped support with the screw that comes with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 1000 R SRAD 2011 2017

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the horseshoe-shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 650 F 2011 2013

1. Remove the 2 upper half-moons from the riser;

2. Fix the handlebars using the table that comes with the kit;

3. Remove 2 finishes from the holes on the side of the frame;

4. Release the tank and move it away;

5. Position the aluminum nut inside the frame and fix the tower clips in an inverted “T” shape on both sides, without tightening them definitively;

6. Fix the tower in an inverted “T” shape to the clips;

7. Fix the shock absorber on the table (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower;

8. Align the parts fixed to the frame and tighten the screws definitively; Tighten the side screw to secure the rod and replace the tank.

↑ Back to Table of Contents

SUZUKI GSX 750 R SRAD 1998 2007

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 750 R SRAD 2011 2014

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screw that fixes the tank by removing the washer and fix it again using the inverted fork-shaped support with the screw that comes with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 750 R SRAD 2015 2016

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 750 SRAD 2008 2010

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screw that fixes the tank by removing the washer and fix it again using the inverted fork-shaped support with the screw that comes with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX 750 S A PARTIR 2018

1. Loosen the bushings that fix the handlebars;

2. Fix the handlebars with the table that comes with the kit;

3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key;

4. Cut out the plastic ignition cover as shown in the image;

5. Remove the screws and washers that fix the tank to the frame;

6. Reattach the tank, using the boomerang-shaped turret;

7. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the tower side screw;

9. Replace the ignition cover and side fairings

↑ Back to Table of Contents

SUZUKI GSX 750 S VARETA

1. Remove the screws from the bushings on the right side that fix the handlebars and fix the “L” shaped part in place;

2. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key;

3. Cut out the plastic ignition cover as shown in the image;

4. Remove the screws and washers that fix the tank to the frame;

5. Reattach the tank, using the boomerang-shaped tower;

6. Fix the shock absorber rod to the “L” shaped part;

7. Center the shock absorber body so that it does not touch the end of the stroke when steering the handlebars;

8. Tighten the clamp;

9. Replace the ignition cover and side fairings.

↑ Back to Table of Contents

SUZUKI GSX S 1000 A F FA

1. Loosen the bushings that fix the handlebars;

2. Fix the handlebars with the table that comes with the kit using the original screws;

3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key;

4. Position the rectangular bar with M6 threaded holes under the ignition assembly, ensuring that the recess in the bar is facing upwards with the relief chamfer facing the ignition assembly;

5. Attach the inverted T-shaped tower to the previously positioned bar, ensuring that the angle of inclination is directed towards the front of the motorcycle, visually align this tower with the center of the table;

6. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

7. Tighten the tower side screw. Note: cut the ignition switch cover with a utility knife as shown in the image

↑ Back to Table of Contents

SUZUKI GSX S 750

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Loosen the longest screw on the inverted fork-shaped support that comes with the kit;

4. Position this support in front of the plastic tank cover above the ignition assembly;

5. Replace the longer screw in its original place, but do not tighten it;

6. Tighten the smaller screw and only then tighten the larger screw;

7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI GSX S 750 2018

1. Loosen the bushings that fix the handlebars;

2. Fix the handlebars with the table that comes with the kit;

3. Remove the side fairings, remove the plastic cover from the tank and remove the plastic cover from the ignition key;

4. Cut the plastic ignition cover according to the image;

5. Remove the screws and washers that fix the tank to the frame;

6. Reattach the tank, using the boomerang-shaped turret;

7. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the tower side screw;

9. Replace the ignition cover and side fairings.

↑ Back to Table of Contents

BMW GS 500 E 2004 2009

1. Remove the two half-moons from the riser and fix the base;

2. Fix the shock absorber on this base in order to correctly position the support and “T”;

3. Position the “T” support between the tank and the bearing box on the frame, visually centering it and marking the point to be drilled;

4. Remove the shock absorber previously fixed to the base;

5. Drill 1 8 mm hole in the frame's finishing plate at the marked point;

6. Move the tank away and slide the screw that comes with the kit from bottom to top to secure the support;

7. Refix the shock absorber to the base by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

BMW G 310 GS

1. Remove air from the table surrounding the canes;

2. Remove the dust cover from the bearing;

3. Position the clamp on the bearing box WITHOUT tightening the screws;

4. Replace the dust cover and the table that surrounds the canes;

5. Replace the part that fixes the handlebars with the table that comes with the kit;

6. Align the handlebars and fix the shock absorber on the table, fitting the stem into the slot;

7. After aligning all parts, tighten all screws definitively.

↑ Back to Table of Contents

SUZUKI HAYABUSA 2005

1. Remove the plastic finish from the 4 screws that go through the table and remove the screws;

2. Install the base that comes with the kit on the table, fixing it with the screws from the kit;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

SUZUKI HAYABUSA 2009 2014

1. Remove the plastic finish from the 4 screws that go through the table and remove the screws;

2. Install the base that comes with the kit on the table, fixing it with the screws from the kit;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

HORNET 2005 2007 NOVO

1. Remove the bushings that fix the handlebars;

2. Fix the handlebars with the table that comes with the kit;

3. Move the tank away to access the panel (it is not necessary to remove the tank);

4. Attach the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit;

5. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

↑ Back to Table of Contents

HORNET 2005 2007 NOVO FAT BAR

1. Remove the bushings that fix the handlebars and remove them;

2. Attach the risers (handlebar extenders)

3. Fix the handlebars over the risers with the table that comes with the kit;

4. Move the tank aside to access the panel (it is not necessary to remove the tank);

5. Fix the fork-shaped piece to the frame by crossing the beam that comes with the kit through the hole in the kit;

6. Fix the shock absorber on the table, remembering to adjust the height of the pin with small taps so that it remains flush with the rod after fitting (it is not necessary to tighten it too much).

↑ Back to Table of Contents

YAMAHA HYPERMOTARD 1100

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 castle nuts located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws using a screw and locknut to provide the necessary tightness;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table by fitting the rod into the slot previously affixed to the ignition assembly;

7. Tighten the support side screw.

↑ Back to Table of Contents

YAMAHA HYPERMOTARD 796

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 castle nuts located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws using a screw and locknut to provide the necessary tightness;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table by fitting the rod into the slot previously affixed to the ignition assembly;

7. Tighten the support side screw.

↑ Back to Table of Contents

YAMAHA HYPERMOTARD 821

1. Release the handlebars and remove the risers;

2. Fix the base of the kit on the table with the risers, replacing the original screws with the larger screws that come with the kit;

3. Remove the 2 screws located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the support pin previously affixed to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 turn of tightening the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

7. Replace the handlebars.

↑ Back to Table of Contents

DUCATI HYPERSTRADA

1. Release the handlebars and remove the risers;

2. Fix the base of the kit on the table with the risers, replacing the original screws with the larger screws that come with the kit;

3. Remove the 2 screws located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table by fitting the slot in the stem to the support pin previously affixed to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

7. Replace the handlebars.

↑ Back to Table of Contents

KTM 1050 1090 1190 1290

1. Remove the handlebars and risers (risers are the parts that raise the handlebars on the table);

2. Fix the shock absorber base on the table, using the risers that come with the kit;

3. Remove the rubber trim located between the tank and the steering gear;

4. Attach the support to the frame, hugging the frame;

5. Fix the tower on the support;

6. Fix the steering damper on the base of the table, fitting the slot in the rod to the pin of the tower fixed to the frame (it is not necessary to tighten it too much);

7. Reattach the handlebars.

↑ Back to Table of Contents

KTM 990 ADVENTURE

1. Remove 2 plastic covers positioned between the tank and the table;

2. Attach the tower in the shape of an inverted “T” at this point with the recess facing the table;

3. Release the handlebars and remove the plastic covers positioned between the handlebars and the headlight;

4. Attach the crescent-shaped base at this point with the recess facing the handlebars;

5. On the base, fix the steering damper by fitting the slot in the rod to the pin of the tower fixed to the frame (it is not necessary to tighten it too much); Reattach the handlebars.

↑ Back to Table of Contents

YAMAHA KTM SMT 990

1. Remove 2 plastic covers positioned between the tank and the table;

2. Attach the tower in the shape of an inverted “T” at this point;

3. Release and remove the handlebars;

4. Loosen the table screw, it is not necessary to loosen the table side screw;

5. Fix the cup with the screw that comes with it, without using a washer;

6. Remove the risers and replace them using the shims and screws that come with the kit;

7. Fix the steering damper to the cup by fitting the slot in the rod to the pin of the tower fixed to the frame (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 bolts that fix the damper to the cup causes excessive hardness when steering the handlebars;

8. Reattach the handlebars using the screws that come with the kit.

↑ Back to Table of Contents

YAMAHA LANDER

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Fix the tower to the frame using the cylindrical bar that must cross it;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Secure the handlebars using the handlebar riser.

↑ Back to Table of Contents

YAMAHA LANDER FAT BAR

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Fix the tower to the frame using the cylindrical bar that must cross it;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Secure the handlebars using the handlebar riser.

↑ Back to Table of Contents

HARLEY DAVIDSON LOW RIDER

1. Remove the original risers and fix the table in place by positioning the risers on it with the screws that come with the kit;

2. Remove the hub nut and the transverse screw that fixes the tank to the frame;

3. Fix the tower in the shape of an inverted fork using the washers on the internal and external side of each “leg” of the fork;

4. Pass through both “legs” of the fork and the respective washers with the long screw pair that comes with the kit and use the cap nut to tighten it;

5. Fix the shock absorber on the previously installed table by fitting the rod to the slot in the tower (it is not necessary to tighten it too much);

6. Tighten the screw on the side of the tower.

↑ Back to Table of Contents

KAWASAKI MONSTER 1100

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 castle nuts located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws using a screw and locknut to provide the necessary tightness;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the rod to the support pin previously attached to the ignition assembly, leveling the pin so that it is flush with the rod;

7. Tighten the support side screws to secure the pin.

↑ Back to Table of Contents

KAWASAKI MONSTER 1200

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 screws located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the pin of the support previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn of tightening the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

↑ Back to Table of Contents

KAWASAKI MONSTER 696

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 castle nuts located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws using a screw and locknut to provide the necessary tightness;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the rod to the support pin previously attached to the ignition assembly, leveling the pin so that it is flush with the rod;

7. Tighten the support side screws to secure the pin.

↑ Back to Table of Contents

KAWASAKI MONSTER 796

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 castle nuts located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws using a screw and locknut to provide the necessary tightness;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the rod to the support pin previously attached to the ignition assembly, leveling the pin so that it is flush with the rod;

7. Tighten the support side screws to secure the pin.

↑ Back to Table of Contents

KAWASAKI MONSTER 797

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 screws located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the pin of the support previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten too much, just 1/8 of a turn of tightening the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

↑ Back to Table of Contents

KAWASAKI MONSTER 821

1. Remove the original table that fixes the handlebars;

2. Reattach the handlebars using the table that comes with the kit;

3. Remove the 2 screws located next to the ignition key;

4. Attach 2 threaded bushings that come with the kit to the visible screws;

5. Fix the tower that comes with the kit onto the bushings using the screws provided;

6. Fix the shock absorber on the handlebar table, fitting the slot in the stem to the support pin previously attached to the ignition assembly, leveling the pin so that it is flush with the stem (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars.

↑ Back to Table of Contents

YAMAHA MT 03

1. Loosen the half-moons that fix the handlebars;

2. Reattach the handlebars to the table that comes with the kit;

3. Fix the tower base to the frame;

4. Fix the tower (piece shaped like an inverted fork) to the base previously fixed to the frame;

5. Fix the shock absorber on the table by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

6. Tighten the tower side screw.

↑ Back to Table of Contents

YAMAHA MT 03 660 CC

1. Remove the original handlebars and risers;

2. Remove the side screws from the plastic finish and fix the tower in the threaded holes in the frame;

3. Tighten the upper tower screws;

4. Position the table that comes with the kit on the motorcycle table and tighten the screws (no need to overtighten) ç

5. Replace the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

YAMAHA MT 03 FAT BAR

1. Loosen the half-moons that fix the handlebars;

2. Remove the original risers;

3. Fix the tower base to the frame;

4. Fix the tower (piece shaped like an inverted fork) to the base previously fixed to the frame;

5. Attach the risers that come with the kit to the motorcycle table;

6. Fix the handlebars with the table that comes with the kit;

7. Fix the shock absorber on the table by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

8. Tighten the tower side screw.

↑ Back to Table of Contents

YAMAHA MT 07

1. Release the panel;

2. Release the handlebars;

3. Remove the risers from the table, loosening the nuts under the table;

4. Attach the base and risers provided by Maxracing to the table;

5. Fix the tower to the frame, making sure that the screws that fix it are firmly against the plate welded to the frame, even if this requires moving the tank cover backwards;

6. Attach the shock absorber to the base previously fixed to the table by fitting the rod to the slot in the tower, tighten the screw on the side of the tower;

7. Reassemble the handlebars and panel.

↑ Back to Table of Contents

YAMAHA MT 09 2014 2016

1. Remove the tank cover;

2. Loosen the screw that fixes the tank to the frame;

3. Fix the “T” shaped support in this threaded hole with the screw that comes with the kit (without using the washer);

4. Loosen the ½ moons that fix the handlebars;

5. Fix the handlebars with the table that comes with the kit;

6. Fix the shock absorber on the table attached to the handlebars, fitting the rod into the slot in the “T”-shaped support (it is not necessary to tighten it too much);

7. Tighten the side screw;

8. Replace the tank cover.

↑ Back to Table of Contents

YAMAHA MT 09 TRACER

1. Remove the handlebars and risers;

2. Loosen the screw that fixes the tank to the frame;

3. Fix the “T” shaped support in this threaded hole with the screw that comes with the kit (without using the washer);

4. Fix the spare base and the risers that come with the Kit, on the table, tightening them with the M10 screw under the table;

5. Install the steering damper on the base previously fixed to the table (it is not necessary to tighten it too much) by fitting the rod into the slot in the “T”-shaped support;

6. Tighten the side screw of the tower fixed to the frame;

7. Replace the handlebars.

↑ Back to Table of Contents

YAMAHA MT 09 TRACER ATUAL

1. Remove the handlebars to access the central nut of the table;

2. Remove the nut and washer;

3. Fix the bearing to the central screw using the nut that comes with the kit;

4. Fix the boomerang on the bearing;

5. Loosen the screw that fixes the tank;

6. Fix the support in the shape of a “T” in the threaded hole with the screw that comes with the kit (WITHOUT the washer);

7. Install the steering damper onto the boomerang (excessive tightening is not necessary) by fitting the rod into the slot in the “T”-shaped support;

8. Tighten the side screw of the tower fixed to the frame;

9. Replace the handlebars.

↑ Back to Table of Contents

DUCATI MULTISTRADA 2016 2017

1. Release the handlebars, removing the risers;

2. Fix the base with the risers, taking care to position the circular support facing downwards using the original screws, but replacing the round shim with the shim that comes with the kit;

3. Remove the plastic cover from the tank and attach the split clamp to the ignition assembly;

4. Fix the shock absorber to the base by fitting the rod into the slot in the clamp (it is not necessary to tighten it too much);

5. Tighten the screw on the side of the clamp to secure the rod;

6. Replace the plastic cover and handlebars.

↑ Back to Table of Contents

DUCATI MULTISTRADA ATE■ 2015

1. Release the handlebars, removing the risers;

2. Fix the base with the risers, taking care to position the circular support facing downwards using the screws that come with the kit (M10 X 90);

3. Fix the shock absorber on the base (it is not necessary to tighten it too much);

4. Attach the split clamp to the ignition key support by tightening the side screw and fitting the pin to the slot in the shock absorber rod so that it is flush with the rod without touching the lower side of the shock absorber body;

5. Replace the handlebars.

↑ Back to Table of Contents

MV AGUSTA RIVALE

1. Remove the table and replace the central nut with the nut included in the kit;

2. Replace the table;

3. Remove 2 screws that secure the ignition to the frame;

4. Fix the ignition tower;

5. Attach the clamp to the previously replaced nut by tightening the side screw I;

6. Fix the shock absorber head on the clamp, fitting the rod to the slot in the support fixed to the frame; NOTE: the screws that fix the shock absorber should only be tightened by 1/8 of a turn to avoid crushing the internal chamber of the shock absorber;

7. Adjust the height of the tower pin so that it is not higher than the torn rod

8. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

HONDA NC 700 NC 750

1. Remove the table;

2. Remove the 2 bearing nuts, the lock and the bearing cover;

3. Place the clamp under the bearing;

4. Replace the nuts, lock and bearing cover;

5. Replace the table;

6. Replace the base on the handlebars with the base that comes with the kit and secure it using the screws on the motorcycle itself;

7. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA NEXT 250

1. Release the handlebars;

2. Remove the table and loosen the bearing nut and remove the bearing cover;

3. Place the clamp on the steering gear bearing post, observing that the recess in the clamp hole must fit into the bearing dust guard (facing upwards), however, do not tighten it permanently;

4. Replace the bearing cover, adjusting nut and adjust the bearing clearance;

5. Replace the table and tighten;

6. Re-attach the handlebars to the base that comes with the kit using the M8x30 screws;

7. Attach the shock absorber to the base previously attached to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

8. Position the clamp definitively and tighten the screws;

9. Tighten the tower side screw.

↑ Back to Table of Contents

KAWASAKI NINJA 1000 2010 20013

1. Remove the screw and washer from the table;

2. Fix the cup that comes with the kit on the table with the original screw WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup, fitting the rod into the slot (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI NINJA 250 2008 2012

1. Remove the table by removing the central screw and loosening the table clamps that fix the canes;

2. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock);

3. Remove the dust cover from the bearings;

4. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it;

5. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear;

6. Replace the table without the central screw;

7. Place the cup that comes with the kit, fixing it with the central screw;

8. Attach the inverted “T” shaped support to the clamp previously attached to the seatpost;

9. Align and position the clamp so that it does not rub against the dust cover and tighten the screw to secure it;

10. Fix the shock absorber to the cup, fitting the rod into the slot (it is not necessary to tighten it too much);

11. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI NINJA 300 2013 2016

1. Remove the table by removing the central screw and loosening the table clamps that fix the canes;

2. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock);

3. Remove the dust cover from the bearings;

4. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it;

5. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear;

6. Replace the table without the central screw;

7. Place the cup that comes with the kit, fixing it with the central screw;

8. Attach the inverted “T” shaped support to the clamp previously attached to the seatpost;

9. Align and position the clamp so that it does not rub against the dust cover and tighten the screw to secure it;

10. Fix the shock absorber to the cup, fitting the rod into the slot (it is not necessary to tighten it too much);

11. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI NINJA 400

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Move the tank aside to access the holes in the frame;

4. Fix the tower to the frame using the cross member under the frame plate;

5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

6. Tighten the tower side screw;

7. Put the tank back in place.

↑ Back to Table of Contents

KAWASAKI NINJA 650 R 2010 2012

1. Dismantle the entire table, including removing the headlight;

2. Remove the 2 bearing nuts, the spider and the bearing cover;

3. Place the clamp under the bearing;

4. Put everything back;

5. Fix the “T” piece to the clamp using the screws that come with it;

6. Replace the base on the handlebars with the base that comes with the kit and secure it using the screws on the motorcycle itself;

7. Fix the shock absorber to the base by fitting the rod into the slot in the “T” support.

8. Tighten the side screw (it is not necessary to overtighten).

↑ Back to Table of Contents

KAWASAKI NINJA 650 VARETA

1. Remove the plastic cover from the tank;

2. Remove the screws that secure the ignition;

3. Attach the boomerang-shaped support to the ignition;

4. Attach the “L” shaped support to the front brake hose;

5. Fix the shock absorber rod on the “L” shaped support;

6. Position the shock absorber inside the clamp in such a way that it does not prevent the handlebars from fully steering on both sides;

7. Tighten the clamp screws;

8. Cut the plastic tank cover to fit it back onto the motorcycle;

9. Replace the plastic tank cover.

↑ Back to Table of Contents

HONDA NX 400 FALCON

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Attach the clamp to the steering bearing housing;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw. Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Fix the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

DUCATI PANIGALI 1199

1. Release the table;

2. Replace the original central nut with the nut that comes with the kit;

3. Fix the cup to the nut by tightening the side screws;

4. Remove the screws that secure the plastic cover around the ignition;

5. Fix the 2 threaded bushings that come with the kit in place;

6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much);

7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot;

8. Tighten the boomerang side screw.

↑ Back to Table of Contents

DUCATI PANIGALI 1299

1. Release the table;

2. Replace the original central nut with the nut that comes with the kit;

3. Fix the cup to the nut by tightening the side screws;

4. Remove the screws that secure the plastic cover around the ignition;

5. Fix the 2 threaded bushings that come with the kit in place;

6. Fix the shock absorber on the cup using the screws that come with the kit (it is not necessary to tighten too much);

7. Fix the boomerang on the threaded bushings, fitting the shock absorber rod to the slot;

8. Tighten the boomerang side screw.

↑ Back to Table of Contents

YAMAHA RD 350

1. Remove the table by removing the central screw and loosening the table clamps that fix the canes;

2. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock);

3. Remove the dust cover from the bearings;

4. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it;

5. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear;

6. Replace the table without the central screw;

7. Place the cup that comes with the kit, fixing it with the central screw;

8. Attach the inverted “T” shaped support to the clamp previously attached to the seatpost;

9. Align and position the clamp so that it does not rub against the dust cover and tighten the screw to secure it;

10. Fix the shock absorber to the cup, fitting the rod into the slot (it is not necessary to tighten it too much);

11. Tighten the side screw.

↑ Back to Table of Contents

BMW R 1200 GS ATE■ 2012

1. Remove the handlebars, remove the risers and remove the table;
2. Remove the central shaft from the bearing;
3. Position the torn support on the central axis of the bearing;
4. Replace the shaft in the bearing;
5. Replace the table;
6. Fix the base on the table;
7. Fix the shock absorber on the base previously fixed to the table (it is not necessary to tighten it too much);
8. Fit the rod to the slot in the support, and tighten the side screw;
9. Replace the risers;
10. Replace the handlebars.

↑ Back to Table of Contents

BMW R 1200 GS A PARTIR 2013

1. Remove the handlebars, remove the table;

2. Fix the clamp on the steering bearing housing;

3. Replace the table;

4. Replace the handlebars using the base that comes with the kit;

5. Fix the inverted T-shaped tower to the clamp;

6. Fix the shock absorber on the base that holds the handlebars (it is not necessary to tighten it too much);

7. Fit the rod to the slot in the tower, and tighten the screw on the side of the tower.

↑ Back to Table of Contents

TRIUMPH SPEED TRIPLE 1050 2013 2016

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Remove the plastic cover from the tank;

4. Remove the screw that fixes the plastic part;

5. Fix the support to the frame;

6. Replace the plastic tank cover;

7. Fix the shock absorber to the base that holds the handlebars, fitting the stem into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

KAWASAKI STREER TRIPLE 675 2013 2016

1. Release the crescents from the risers that fix the handlebars;

2. Fix the handlebars with the base that makes up the installation kit using the original screws;

3. Remove the screws that fix the tank and fix the “T” support to the frame in place, refixing the tank with the screws that come with the kit;

4. Install the shock absorber on the previously fixed base (it is not necessary to tighten it too much);

5. Fit the shock absorber rod to the slot in the “T” support;

6. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

TRIUMPH STREET TRIPLE 675

1. Release the crescents from the risers that fix the handlebars;

2. Fix the handlebars with the base that makes up the installation kit using the original screws;

3. Remove the screws that fix the tank and fix the “T” support to the frame in place, refixing the tank with the screws that come with the kit;

4. Install the shock absorber on the previously fixed base (it is not necessary to tighten it too much);

5. Fit the shock absorber rod to the slot in the “T” support;

6. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

TRIUMPH STREET TRIPLE 765

1. Release the crescents from the risers that fix the handlebars;

2. Fix the handlebars with the base that makes up the installation kit using the original screws;

3. Remove the screws that fix the tank and fix the “T” support to the frame in place, refixing the tank with the screws that come with the kit;

4. Install the shock absorber on the previously fixed base (it is not necessary to tighten it too much);

5. Fit the shock absorber rod to the slot in the “T” support;

6. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

YAMAHA SUPER TENERE 1200

1. Release the handlebars by removing the half-moons;

2. Remove the table nut and washer;

3. On the table screw, secure the cup using the nut that comes with the kit;

4. Open to ø 8.5mm, 2 pre-existing holes in the frame close to the tank;

5. Open M10 thread pitch 1.5 in these holes (preferably use an individual machine tap);

6. Fix the support that comes with the kit in these threaded holes (it is not necessary to tighten too much, although the screws are reasonably large, pay close attention when tightening so as not to strip the threads);

7. Fix the shock absorber on the cup by fitting its rod into the slot in the support fixed to the frame (it is not necessary to tighten it too much); Replace the handlebars.

↑ Back to Table of Contents

YAMAHA SUPER TENERE 1200 2015 EM DIANTE

1. Release the handlebars by removing the half-moons;

2. Remove the table nut and washer;

3. On the table screw, secure the cup using the nut that comes with the kit;

4. Open 2 pre-existing holes in the frame close to the tank to ø 8.5mm;

5. Open M10 thread pitch 1.5 in these holes (preferably use an individual machine tap);

6. Fix the support that comes with the kit in these threaded holes (it is not necessary to tighten too much, although the screws are reasonably large, pay close attention when tightening so as not to strip the threads);

7. Invert the position of the risers, positioning the left riser on the right side and vice versa;

8. Fix the shock absorber on the cup by fitting its rod into the slot in the support fixed to the frame (it is not necessary to tighten it too much);

9. Replace the handlebars.

↑ Back to Table of Contents

SUZUKI SV 650

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the 2 screws and washers that fix the tank to the frame;

4. Use the inverted “T” shaped support to secure the tank again with the screws that come with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

BMW S 1000 RR 2012 2017

1. Loosen the table nut by removing the washer;

2. Affix the glass by fitting its feet into the slots on the table using the original nut WITHOUT the washer;

3. Loosen the screw that fixes the plastic cover of the tank using the compatible Torx wrench;

4. Fix the inverted fork-shaped support in place with the screw that comes with the kit;

5. Mount the shock absorber on the table cup by fitting the rod into the slot in the support fixed to the tank (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

BMW S 1000 RR ATE■ 2011

1. Loosen the table nut by removing the washer;

2. Affix the glass by fitting its feet into the slots on the table using the original nut WITHOUT the washer;

3. Loosen the screw that fixes the plastic cover of the tank using the compatible Torx wrench;

4. Fix the inverted fork-shaped support in place with the screw that comes with the kit;

5. Mount the shock absorber on the table cup by fitting the rod into the slot in the support fixed to the tank (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

BMW S 1000 R NAKED

1. Loosen the half-moons that fix the handlebars;

2. Fix the handlebars to the base using the screws that come with the kit;

3. Loosen and remove the screw and washer that fixes the tank cover to the frame;

4. Use the inverted “T” shaped support to re-attach the tank cover with the screw that comes with the kit;

5. Fix the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

BMW S 1000 XR

1. Loosen the half-moons that fix the handlebars;

2. Fix the handlebars to the base using the original screws;

3. Remove the plastic cover that surrounds the ignition

4. Fix the base of the Tower to the frame (slanted screws),

5. Replace the ignition cover

6. Fix the Tower to the base previously fixed to the frame

7. Fix the shock absorber to the base fixed to the table, fitting the rod into the slot in the support (it is not necessary to tighten it too much);

8. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA TENERE 250

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Pass the round bar through the hole in the frame;

5. Mount the support on the frame, fixing it to the bar across the frame;

6. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

7. Tighten the tower side screw;

8. Secure the handlebars using the wedge.

↑ Back to Table of Contents

YAMAHA TENERE■ 250

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Fix the tower to the frame using the cylindrical bar that must cross it;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Secure the handlebars using the handlebar riser.

↑ Back to Table of Contents

YAMAHA TENERE■ 250 FAT BAR

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Fix the tower to the frame using the cylindrical bar that must cross it;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Secure the handlebars using the handlebar riser.

↑ Back to Table of Contents

KAWASAKI TIGER 1050 SPORT

1. Release the handlebars and remove the risers from the table;

2. Position the table that comes with the kit on the original table, fixing it with the risers removed previously using the screws from the kit;

3. Remove the screw and washer that secures the tank to the frame;

4. Fix the tower in the shape of an inverted “T”;

5. Adjust the height of the tower pin so that it is 1 mm below the shock absorber;

6. Fix the shock absorber on the previously installed table in such a way that the pin fits into the slot in the rod;

7. Attach the handlebars.

↑ Back to Table of Contents

KAWASAKI TIGER 1200 ATUAL

1. Remove the handlebars;

2. Remove the original nut and central washer from the table

3. Fix the special nut with a square hole on the central screw of the table using a ½'' ratchet wrench extender;

4. Fit the cup onto the special nut and tighten the horizontal screws;

5. Move the tank away;

6. Fix the support to the frame in two inclined slots next to the rubber where the tank is fitted, passing the screws through the slots and placing 2 nuts under this plate;

7. Fix the shock absorber to the cup, fitting the shock absorber rod to the slot in the support (it is not necessary to tighten it too much);

8. Replace the handlebars;

9. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

KAWASAKI TIGER 800

1. Release the handlebars and remove the risers and elastic pins from the table;

2. Mount the silver base on the table, fixing it with the M10X30 screws that come with the kit;

3. Fix the shock absorber on the tower table (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

4. Reassemble the handlebar using the shims that come with the kit;

5. Attach the clamp with tower to the front fairing support tube, positioning the slot in the tower so that the shock absorber rod fits into the slot;

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI TIGER 800XC 2014 2016

1. Release the handlebars and remove the risers and elastic pins from the table;

2. Mount the silver base on the table, fixing it with the M10X30 screws that come with the kit;

3. Fix the shock absorber on the tower table (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

4. Reassemble the handlebars;

5. Attach the clamp with tower to the front fairing support tube, positioning the slot in the tower so that the shock absorber rod fits into the slot;

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI TIGER 800 ATUAL

1. Release the handlebars;

2. Remove the central nut from the table and replace it with the nut with a square hole that comes with the kit and tighten;

3. Fit the cup into the slot with the square hole, aligning it with the table and tighten the horizontal screws tightly;

4. Loosen the 4 screws on the “V” shaped clamp in order to position it on the pipe that holds the front fairing (DO NOT tighten the screws permanently);

5. Position the pin tower with the extensions on the “V”-shaped clamp;

6. Install the shock absorber on the cup, fitting the slot in the rod to the pin and adjusting the height of the pin with light taps (it is not necessary to overtighten the screws);

7. If you consider it necessary to raise the handlebars, install the 2 oval silver-colored shims under the risers;

8. Tighten all screws after making sure that all parts are properly aligned.

↑ Back to Table of Contents

KAWASAKI TIGER 800 XCX 2014 2016

1. Release the handlebars and remove the risers and elastic pins from the table;

2. Mount the silver base on the table, fixing it with the M10X30 screws that come with the kit;

3. Fix the shock absorber on the tower table (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

4. Reassemble the handlebars;

5. Attach the clamp with tower to the front fairing support tube, positioning the slot in the tower so that the shock absorber rod fits into the slot;

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI TIGER 800 XRX

1. Release the handlebars and remove the risers and elastic pins from the table;

2. Mount the silver base on the table, fixing it with the M10X30 screws that come with the kit;

3. Fix the shock absorber on the tower table (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

4. Reassemble the handlebar using the shims that come with the kit;

5. Attach the clamp with tower to the front fairing support tube, positioning the slot in the tower so that the shock absorber rod fits into the slot;

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI TIGER 900

1. Remove the handlebars and risers;

2. Loosen the central nut of the table and remove the washer;

3. Fix the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

4. Move the tank away and remove the plastic cover that surrounds the ignition;

5. Remove the electrical component from the plate that fixes the plastic cover to access 2 hexagonal screws;

6. Remove the hexagonal screws and fix the tower by fitting its hole into the ignition using the screws that come with the kit;

7. Replace the electrical component;

8. Fix the shock absorber on the cup by fitting the rod to the slot in the tower (excessive tightening is not necessary);

9. Attach the risers that come with the kit;

10. Replace the handlebars;

11. Make a cut in the plastic cover that surrounds the ignition with a width of 26 mm, leaving 10 mm in the original height;

12. Reassemble the motorcycle;

13. Tighten the tower side screw.

↑ Back to Table of Contents

KAWASAKI TIGER EXPLORE 1200 2014 2016

1. Remove the handlebars;

2. Release the risers;

3. Remove the two elastic pins from the table;

4. Fix the base that makes up the installation kit on the table with the screws that come with it;

5. Move the tank away;

6. Fix the support to the frame in two inclined slots on the side of the rubber where the tank is fitted, passing the screws through the slots and placing the 2 nuts underneath this plate;

7. Fix the damper to the base previously fixed on the table, fitting the damper rod to the slot in the support (it is not necessary to tighten it too much);

8. Replace the risers and secure the handlebars;

9. Tighten the side screw of the support fixed to the frame.

↑ Back to Table of Contents

HONDA TRANSALP 700

1. Loosen the handlebars, remove the nut from the table, loosen the table screws that fix the cane;

2. Remove the table;

3. Position the clamp on the steering bearing housing, however, do not definitively tighten the screws (check possible excess welding points and remove them)
NOTE: in this model we note that the welding at this point is not standard for all motorcycles, therefore this check is important;

4. Replace the table;

5. Fix the handlebars with the base that comes with the kit;

6. Fix the shock absorber on the base, observing that the pin must fit into the groove in the shock absorber rod;

7. Permanently tighten the clamp screws, taking care to ensure that it is visually aligned.

↑ Back to Table of Contents

HONDA TRANSALP 700 ATUAL

1. Loosen the handlebars to access the table nut;

2. Remove the table nut and washer;

3. Fix the cup that comes with the kit with the original nut WITHOUT the washer;

4. Fix the shock absorber on the cup without tightening the screws;

5. Position the piece in the shape of an inverted “T” on the frame, fitting the rod to the slot in the tower, aligning it;

6. Use the holes in the inverted “T” piece as a guide to mark the place where 2 holes in the frame should be made;

7. Remove the shock absorber and tower and drill 2 9mm holes in the frame markings;

8. Fit the threaded rivets into the holes;

9. Replace the tower in an inverted “T” and tighten the screws on the threaded pins;

10. Fix the shock absorber on the cup by fitting the rod to the slot in the tower (DO NOT apply excessive tightening);

11. Tighten the tower side screw;

12. Replace the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

KAWASAKI VERSYS 1000 ATE 2015

1. Release the handlebars;

2. Release the risers and remove the central beam located between the risers;

3. Loosen the central nut and remove the washer;

4. Fix the cup to the central screw of the table, without installing the washer, using the original nut;

5. Loosen the screws that fix the tank to the frame;

6. Fix the tower in the shape of an inverted T using M6 screws with a domed head (screws are included in the kit);

7. Fix the shock absorber on the cup previously fixed to the table (it is not necessary to tighten it too much), fitting the rod to the slot in the tower, and tighten the screw on the side of the tower;

8. Replace the risers without using the central beam;

9. Replace the handlebars.

↑ Back to Table of Contents

KAWASAKI VERSYS 1000 A PARTIR 2016

1. Release the handlebars;

2. Remove the risers and replace them with the risers that come with the kit;

3. Loosen the central nut and remove the washer;

4. Fix the cup to the central screw of the table, without installing the washer, using the original nut;

5. Loosen the screws that fix the tank to the frame;

6. Fix the tower in an inverted T shape;

7. Fix the shock absorber on the cup previously fixed to the table nut (it is not necessary to tighten it too much), fitting the rod to the slot in the tower, and tighten the screw on the side of the tower;

8. Replace the handlebars.

↑ Back to Table of Contents

KAWASAKI VERSYS 300

1. Remove the original table and fix the handlebars with the table that comes with the kit;

2. Move the tank aside to access the panel (it is not necessary to remove the tank);

3. Fix the piece in the shape of an inverted fork (the half-moon must be positioned towards the handlebars) with the cross member that comes with the kit;

4. Fix the shock absorber to the table above the handlebars;

5. Tighten the tower side screw (excessive tightening is not necessary).

↑ Back to Table of Contents

KAWASAKI VERSYS 650

1. Release and remove the handlebars;

2. Loosen the central nut and remove the table;

3. Place the clamp under the bearing cover;

4. Replace the table;

5. Fix the cup to the central nut, without using the washer;

6. Fix the steering damper on the cup (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower;

7. Fix the handlebars;

↑ Back to Table of Contents

KAWASAKI VERSYS 650 ATUAL

1. Release the table and handlebars;

2. Loosen the central nut and remove the table;

3. Place the clamp under the bearing cover;

4. Replace the table;

5. Replace the original nut with the nut with a square hole that comes with the kit with the washer;

6. Fix the shock absorber on the cup (it is not necessary to tighten too much) and fitting the rod to the slot in the tower;

7. Tighten the tower side screw;

8. Replace the handlebars.

↑ Back to Table of Contents

YAMAHA VMAX 1200

1. Release and move the handlebars;

2. Loosen the central nut of the table and remove the washer;

3. Secure the cup with the nut that comes with the kit WITHOUT the original washer;

4. Fix the clamp under the dust cover on the bearing housing, visually aligning it in the center of the motorcycle;

5. Fix the shock absorber in the cup by fitting the rod into the slot in the tower (it is not necessary to tighten too much);

6. Fix the handlebars with the risers that come with the kit using the screws provided;

7. Tighten the tower side screw.

↑ Back to Table of Contents

KAWASAKI WR 250 WR 450 YZ 450 DEBAIXO DO GUIDA■O

1. Remove the table;

2. Position the clamp on the bearing box without tightening the screws;

3. Replace the table and attach the glass to the central screw without a washer;

4. Attach the tower to the clamp, ensuring that the half-moon shape is directed towards the handlebars;

5. Fix the shock absorber to the cup (it is not necessary to tighten it too much) by fitting the rod into the slot in the tower;

6. Align the clamp visually in the correct and definitive position, tighten the Allen head screw and only then tighten the 4 Allen head screws little by little on each screw until achieving the ideal tightness;

7. Tighten the tower side screw;

8. Replace the handlebar using the handlebar extenders that come with the kit.

↑ Back to Table of Contents

BUELL XB 12

1. Release the handlebars and secure them again using the table that comes with the installation kit;

2. Remove the screw that fixes the tank cover on the right side of the motorcycle;

3. Attach the tower that comes with the kit at this point;

4. Install the shock absorber on the table previously fixed to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

5. Tighten the tower side screw.

↑ Back to Table of Contents

BUELL XB 12X ULISSES

1. Release the handlebars and secure them again using the table that comes with the installation kit;

2. Remove the screw that fixes the tank cover on the right side of the motorcycle;

3. Attach the tower that comes with the kit at this point;

4. Install the shock absorber on the table previously fixed to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

5. Tighten the tower side screw.

↑ Back to Table of Contents

BUELL XB 12 R

1. Loosen the central nut of the table and secure the nut with a square fitting;

2. Position the cup on this central nut and secure it with the nut that comes with the kit;

3. Remove the screw that fixes the tank cover on the right side of the motorcycle;

4. Attach the tower that comes with the kit at this point;

5. Install the shock absorber on the cup previously fixed to the table (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the rod into the slot in the tower;

6. Tighten the tower side screw.

↑ Back to Table of Contents

BUELL XB 9

1. Release the handlebars and secure them again using the table that comes with the installation kit;

2. Remove the screw that fixes the tank cover on the right side of the motorcycle;

3. Attach the tower that comes with the kit at this point;

4. Install the shock absorber on the table previously fixed to the handlebars (it is not necessary to tighten too much, tightening 1/8 of a turn is sufficient), fitting the stem into the slot in the tower;

5. Tighten the tower side screw.

↑ Back to Table of Contents

YAMAHA XJ 6

1. Release the handlebars by removing the crescents,

2. Loosen the central nut of the table and remove the washer,

3. Attach the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

4. Remove the screws and washers that fix the tank and place the support in the shape of an inverted “T” with the screws that come with the kit, observing that the inclination of the support must be towards the tank;

5. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (it is not necessary to tighten it too much);

6. Tighten the side screw of the tower fixed to the frame;

7. Replace the handlebar using the shims that come with the kit to raise the handlebar.

↑ Back to Table of Contents

YAMAHA XJ 6 2010 2016

1. Release the handlebars by removing the crescents,

2. Loosen the central nut of the table and remove the washer,

3. Attach the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

4. Remove the screws and washers that fix the tank and place the support in the shape of an inverted “T” with the screws that come with the kit, observing that the inclination of the support must be towards the tank;

5. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (it is not necessary to tighten it too much);

6. Tighten the side screw of the tower fixed to the frame;

7. Replace the handlebar using the shims that come with the kit to raise the handlebar.

↑ Back to Table of Contents

YAMAHA XJ 6 FAT BAR

1. Release the handlebars and risers,

2. Reattach the risers and handlebars using the lengthener and screws that come with the kit,

3. Loosen the central nut of the table and remove the washer,

4. Attach the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

5. Remove the screws and washers that fix the tank and place the support in the shape of an inverted “T” with the screws that come with the kit, observing that the inclination of the support must be towards the tank;

6. Fix the shock absorber on the cup by fitting its rod into the slot in the “T” support (it is not necessary to tighten too much);

7. Tighten the side screw of the tower fixed to the frame;

8. Replace the handlebar using the shims that come with the kit to raise the handlebar.

↑ Back to Table of Contents

HONDA XRE 300

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Attach the clamp to the steering bearing housing;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Fix the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

HONDA XRE 300 FAT BAR

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Attach the clamp to the steering bearing housing;

5. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

6. Tighten the tower side screw;

7. Fix the handlebars using the risers that come with the kit.

↑ Back to Table of Contents

YAMAHA XTZ 250 LANDER

1. Release the handlebars;

2. Loosen the table nut and remove the washer;

3. Fix the cup to the central screw of the table using the original table nut WITHOUT the washer;

4. Pass the round bar through the hole in the frame;

5. Mount the support on the frame, fixing it to the bar across the frame;

6. Mount the shock absorber on the cup and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw, excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars);

7. Tighten the tower side screw;

8. Secure the handlebars using the wedge.

↑ Back to Table of Contents

YAMAHA XTZ 660 TENERE■

1. Release the handlebars and remove the risers;

2. Drill the head of the security screws that secure the ignition to the frame and remove them;

3. Use the boomerang-shaped screw to secure the ignition;

4. Fix the shock absorber base together with the risers on the table;

5. Fix the shock absorber to the base installed on the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod;

6. Fix the handlebars on the risers that come with the kit, previously installed on the table.

↑ Back to Table of Contents

YAMAHA XT 600

1. Release the handlebars;

2. Loosen the central nut of the table and remove the washer;

3. Fix the cup to the central screw of the table using the nut that comes with the kit WITHOUT the washer;

4. Fix the clamp under the dust cover in the bearing box, aligning the tower in the center of the motorcycle;

5. Fix the shock absorber in the cup by fitting the rod to the slot in the tower (it is not necessary to tighten it too much);

6. Replace the handlebars on the risers and secure using the screws that come with the kit;

7. Tighten the screw on the side of the tower.

↑ Back to Table of Contents

YAMAHA XT 660 2005 2016

1. Replace the handlebar with one that does not have reinforcement or remove this reinforcement;

2. Remove the 2 upper half-moons from the riser;

3. Fix the base with the screws that come with the kit;

4. Move the tank away;

5. Install the “L” shaped support in the holes in the finishing plate, fixing the nuts underneath this plate;

6. Fix the shock absorber to the base fixed to the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod;

7. Replace the tank.

↑ Back to Table of Contents

YAMAHA XT 660 2005 2016 FAT BAR

1. Fix the base together with the risers on the table;

2. Move the tank away;

3. Install the “L” shaped support in the holes in the finishing plate, fixing the nuts underneath this plate;

4. Fix the shock absorber to the base fixed to the table (it is not necessary to tighten it too much) by fitting the pin into the slot in the rod;

5. Replace the tank.

↑ Back to Table of Contents

YAMAHA YZF R1 2000 2002

1. Remove the plastic finish from the 2 screws that fix the semi-handlebar and remove the screws;

2. Fix the base on the table with the screws that come with the kit;

3. Replace the plastic finishes;

4. Loosen the central screw that fixes the tank and remove the washer;

5. Temporarily attach the support to the tank and mark two holes to be made in the frame with a diameter of 5.2 for M6 thread with a punch;

6. Remove the support, open the holes using a drill and insert a tap M¨;

7. Replace the support;

8. Attach the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

9. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA YZF R1 2003 2006

1. Remove the plastic finish from the 2 screws that fix the semi-handlebar and remove the screws;

2. Fix the base on the table with the screws that come with the kit;

3. Replace the plastic finishes;

4. Loosen the central screw that fixes the tank and remove the washer;

5. Temporarily attach the support to the tank and mark two holes to be made in the frame with a diameter of 5.2 for M6 thread with a punch;

6. Remove the support, open the holes using a drill and insert a tap M¨;

7. Replace the support;

8. Attach the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

9. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA YZF R1 2007 2008

1. Remove the plastic finish from the 2 screws that fix the semi-handlebar and remove the screws;

2. Fix the base on the table with the screws that come with the kit;

3. Replace the plastic finishes;

4. Loosen the central screw that fixes the tank and remove the washer;

5. Temporarily attach the support to the tank and mark two holes to be made in the frame with a diameter of 5.2 for M6 thread with a punch;

6. Remove the support, open the holes using a drill and insert a tap M¨;

7. Replace the support;

8. Attach the shock absorber to the base fixed to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

9. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA YZF R1 2009 2014

1. Use a 5 mm Allen key;

2. Remove the plastic and loosen the 2 table screws;

3. Place the base and secure it with the screws provided;

4. Loosen the screw on the tank that fixes the cover and remove the washer;

5. Place the support and secure it with the screw that comes with it;

6. Fix the damper to the table base and tighten the side screw that fixes the rod to the damper (it is not necessary to overtighten).

↑ Back to Table of Contents

YAMAHA YZF R3

1. Loosen the table screw and remove the washer;

2. Install the cup that comes with the kit, fixing it with the hexagonal screw that comes with the kit with the washer;

3. Fix the base of the tower to the frame;

4. Attach the tower (piece shaped like an inverted fork) to the base previously fixed to the frame;

5. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

6. Tighten the tower side screw.

↑ Back to Table of Contents

YAMAHA YZF R6 1999 2002

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the inverted “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

YAMAHA YZF R6 2006 2011

1. Remove the plastic finish from the screws that fix the semi-handlebars and remove the screws;

2. Fix the base on the table with the screws that come with the kit;

3. Replace the plastic finishes;

4. Loosen the central screw that fixes the tank to the frame and remove the washer;

5. Fix the support in the form of an inverted fork using the screw that comes with the kit WITHOUT the washer;

6. Fix the shock absorber on the table base by fitting the rod into the slot in the support fixed to the frame (it is not necessary to tighten it too much);

7. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI ZX 10R 2008 2010

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI ZX 10R 2011 2016

1. Remove the original shock absorber and remove the support attached to the frame;

2. Attach the support that makes up the Maxracing kit to the frame;

3. Fix the glass to the table using the original nut WITHOUT using the washer;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the frame (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI ZX 14

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screw that fixes the tank by removing the washer and fix it again using the inverted “T” shaped support with the screw that comes with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much, tighten it by 1/8 of a turn);

5. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI ZX 636 2013 2016

1. Loosen the table nut and remove the washer;

2. Install the cup that comes with the kit, fixing it with the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the “T” shaped support with the screws that come with the kit;

4. Fix the shock absorber to the cup by fitting the rod into the slot in the support previously fixed to the tank (it is not necessary to tighten it too much);

5. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI ZX 6 2005 A 2006

1. Loosen the table nut and remove the washer

2. Install the cup that comes with the kit using the original nut WITHOUT the washer;

3. Loosen the screws that fix the tank by removing the washers and fix it again using the base of the tower with the screws that come with the kit;

4. Fix the tower on the base;

5. Fix the shock absorber to the cup by fitting the rod to the slot in the tower (NOTE: it is not necessary to tighten it too much, just 1/8 of a turn on the screw). Excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

8. Tighten the tower side screw

↑ Back to Table of Contents

KAWASAKI Z 1000 ATE 2014

1. Remove the two M8 screws that fix the handlebars;

2. Install the boomerang-shaped base by placing the black bushings in the head housing of the removed screws;

3. Remove the tank cover and the plastic cover from the ignition key;

4. Loosen the two screws that fix the tank to the frame;

5. Fix the horseshoe-shaped support to the frame under the tank handles using the original screws;

6. Fix the shock absorber on the handlebar table using the screws that come with the kit, fitting the stem into the slot in the horseshoe-shaped support (it is not necessary to tighten too much);

7. Replace the plastic tank cover; NOTE: To reinstall the plastic ignition cover, it is necessary to make a cut in it to fit the support affixed to the frame.

↑ Back to Table of Contents

KAWASAKI Z 1000 A PARTIR 2015 VARETA

1. Remove the plastic cover from the tank and ignition key cover;

2. Loosen the 2 screws that fix the tank to the frame;

3. Fix the boomerang-shaped support over the straps that fix the tank to the frame;

4. Attach the “L” shaped support to the front brake hose;

5. Fix the shock absorber rod on the “L” shaped support;

6. Position the shock absorber inside the clamp in such a way that it does not prevent the handlebars from fully steering on both sides;

7. Tighten the clamp screws;

8. Cut the plastic cover from the ignition key to fit it back onto the motorcycle;

9. Replace the plastic cover on the ignition key and replace the plastic cover on the tank. NOTE: To reinstall the plastic ignition cover, it is necessary to make a cut in it to fit the support attached to the frame.

↑ Back to Table of Contents

KAWASAKI Z 300

1. Release the handlebars;

2. Remove the table by removing the central screw and loosening the clamps that fix the canes;

3. Remove the nuts that adjust the steering box bearings (observe the existence of the nut lock);

4. Remove the dust cover from the bearings;

5. Position the clamp that comes with the kit on the seatpost with the recess facing upwards WITHOUT tightening it;

6. Replace the dust cover, nut and counter nut without forgetting the lock and adjusting the tightness of the steering gear;

7. Replace the table;

8. Fix the handlebars using the table that comes with the kit;

9. Fix the shock absorber on the table by fitting the rod into the slot (it is not necessary to tighten it too much);

10. Align and position the clamp so that it does not rub against the dust cover and tighten the screws to secure it;

11. Tighten the tower side screw.

↑ Back to Table of Contents

KAWASAKI Z 400

1. Loosen the half moons that fix the handlebars;

2. Fix the handlebars to the table using the screws that come with the kit;

3. Move the tank aside to access the holes in the frame;

4. Fix the base of the tower to the frame and then fix the tower on it.

5. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI Z 400 FAT BAR

1. Loosen the half moons that fix the handlebars;

2. Attach the FAT BAR handlebar using the table and handlebar extenders that come with the kit;

3. Move the tank aside to access the holes in the frame;

4. Fix the base of the tower to the frame and then fix the tower on it.

5. Fix the shock absorber to the table by fitting the rod into the slot in the support (it is not necessary to tighten it too much);

6. Tighten the side screw.

↑ Back to Table of Contents

KAWASAKI Z 650

1. Remove the plastic cover from the tank;
2. Remove the plastic ignition cover;
3. Remove the 2 screws closest to the tank that fix the handlebars;
4. Fix the support arm with the screws that come with the kit;
5. Remove the ignition screws and fix the tower base in place;
6. Center the shock absorber inside the clamp;
7. Tighten the clamp screws;
8. Fix the clamp rod with the M8 screw to the cross member tower;
9. Cut the plastic cover from the ignition key to fit it back onto the motorcycle;
10. Replace the plastic cover on the ignition key and tank.

↑ Back to Table of Contents

KAWASAKI Z 750

1. Remove the table, headlight and panel;

2. Remove the 2 bearing nuts, the spider and the bearing cover;

3. Place the clamp under the bearing cover;

4. Replace the bearing nuts, the table, the headlight and the panel;

5. Fix the “T” piece to the clamp using the screws that come with the kit;

6. Fix the handlebars with the base that comes with the kit using the original screws;

7. Fix the steering damper on the base (it is not necessary to tighten too much) by fitting the rod to the pin;

8. Adjust the height of the pin (the pin is a movable part) until it is flush with the rod, applying light taps to the top of it.

↑ Back to Table of Contents

KAWASAKI Z 750 FAT BAR

1. Remove the handlebars, risers and stem;

2. Remove the 2 bearing nuts, the spider and the bearing cover;

3. Place the clamp under the bearing cover, without tightening the screws (leave them loose);

4. Replace the bearing nuts and the table;

5. Fix the cup to the central nut of the table;

6. Place the risers that come with the kit;

7. Fix the shock absorber on the cup (it is not necessary to tighten it too much) by fitting the rod to the slot in the tower;

8. Fix the handlebars with the bushings that come with the kit;

9. Position the clamp so that it is as close as possible to the bearing dust cover without scraping it;

10. Tighten the clamp screws and the tower side screw.

↑ Back to Table of Contents

KAWASAKI Z 750 S ABS

1. Replace the base that fixes the handlebars with the base that comes with the kit and re-attach the handlebars using the screws from the motorcycle itself;

2. Attach the inverted “T” shaped support to the frame, tightening it with the bar with threaded holes;

3. Fix the steering damper on the base previously fixed on the handlebars (it is not necessary to tighten it too much) by fitting the rod to the pin;

4. Adjust the height of the pin until it is flush with the rod, this pin is movable, just tap the top of it lightly.

↑ Back to Table of Contents

KAWASAKI Z 800 2013 2016

1. Remove the table that fixes the handlebars and fix it again with the table that comes with the kit;

2. Remove the plastic cover from the tank;

3. Fix the support to the threaded holes in the ignition key, avoiding excessive tightening as there is a risk of stripping the threads;

4. Fix the shock absorber on the handlebar table by fitting the stem into the slot in the support fixed to the frame (it is not necessary to tighten it too much);

5. Tighten the side screw;

6. Replace the plastic tank cover.

↑ Back to Table of Contents

KAWASAKI Z 900

1. Remove the plastic covers on the sides of the tank (right and left);

2. Remove the plastic ignition cover;

3. Remove the front acrylic visor;

4. Remove the panel to make room to loosen the screws that fix the handlebars;

5. Replace the screws, fixing the cross member, so that the cross member tower is facing the right side;

6. Loosen the screws that fix the tank to the frame;

7. Fix the boomerang-shaped support over the straps that fix the tank to the frame;

8. Position the shock absorber inside the clamp, so that the shock absorber is centered;

9. Tighten the clamp screws;

10. Fix the clamp rod with the M8 screw to the cross member tower;

11. Cut the plastic cover from the ignition key to fit it back onto the motorcycle, as shown in the image below;

12. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

↑ Back to Table of Contents

KAWASAKI Z 900 2

1. Remove the side plastic covers from the tank (right and left);

2. Remove the plastic ignition cover;

3. Remove the front acrylic visor;

4. Remove the panel to make room to loosen the screws that fix the handlebars;

5. Replace the screws fixing the cross member so that the cross member's tower is facing the right side;

6. Loosen the screws that fix the tank to the frame;

7. Fix the boomerang-shaped support over the straps that fix the tank to the frame;

8. Position the shock absorber in the center of the clamp;

9. Tighten the clamp screws;

10. Fix the clamp rod with the M8 screw to the cross member tower;

11. Cut the plastic ignition cover to fit it back onto the motorcycle as shown in the image below;

12. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

↑ Back to Table of Contents

KAWASAKI Z 900 2020 EM DIANTE

1. Remove the side plastic covers from the tank (right and left);

2. Remove the plastic ignition cover;

3. Attach the “L” shaped piece to the right mirror clamp;

4. Loosen the screws that fix the tank to the frame;

5. Fix the boomerang-shaped support over the straps that fix the tank to the frame;

6. Position the shock absorber in the center of the clamp;

7. Tighten the clamp screws;

8. Fix the shock absorber rod to the “L” shaped piece previously fixed to the rear view mirror;

9. Cut the plastic ignition cover to fit it on the motorcycle as shown in the image below;

10. Replace the plastic cover on the ignition key and replace the plastic covers on the tank (right and left).

↑ Back to Table of Contents

KAWASAKI Z 900 RS

1. Release the handlebars to access the central nut of the table;

2. Remove the table's central nut and washer;

3. Fix the cup with the original nut WITHOUT the washer;

4. Loosen the tank screws and fix the tower at that point, centering the tower;

4. Fix the base of the support to the frame. To do this, remove the screw that fixes the plate and also remove the nut;

5. Replace the tank;

7. Fix the shock absorber to the table fixed over the handlebars and fit the stem to the slot in the tower (NOTE: it is not necessary to tighten too much, just 1/8 of a turn on the screw) excessive tightening of the 2 screws that fix the shock absorber to the cup causes excessive hardness when steering the handlebars;

8. Tighten the tower side screw

↑ Back to Table of Contents