


## Assembling the Automatic Cat feeder


1. Get the two legs, the base, and 4 screws. Screw in the legs to the base.



2. Next, attach the roller bearing to the dispensing disc. Mount the dispensing disc onto the base.



3. Then, place the motor in the motor house and screw it in using 4 M3 10 inch screws. Once it is screwed in, insert the spur gear (31 teeth) onto the shaft of the motor.



4. Place the lid onto the motor house



5. Insert the food holder on top of the dispensing disc.



6. Place the lid on the food holder.

