WSJT Keyboard Shortcuts

F1	List keyboard shortcuts
Shift+F1	List special mouse commands
Ctrl+F1	About WSJT
F2	Options
F3	Tx Mute
F4	Clear "To Radio"
F5	What message to send?
F6	Open next file in directory
Shift+F6	Decode all wave files in directory
F7	Set FSK441 mode
Shift+F7	Set JT6M mode
F8	Set JT65A mode
Shift+F8	Set JT65B mode
Ctrl+F8	Set JT65C mode
Shift+Ctrl+F8	Set CW mode
F10	Show SpecJT
Shift+F10	Show astronomical data
F11	Decrement Freeze DF
F12	Increment Freeze DF
Alt+1 to Alt+6	Tx1 to Tx6
Alt+A	Toggle Auto On/Off
Alt+D	Decode
Ctrl+D	Force Decode
Shift+Ctrl+D	Force Decode, no JT65 shorthands
Alt+E	Erase
Alt+F	Toggle Freeze
Alt+G	Generate Standard Messages
Ctrl+G	Generate Alternate JT65 Messages
Alt+I	Include
Alt+L	Lookup
Ctrl+L	Lookup, then Generate Standard Messages
Alt+M	Monitor
Alt+O	Tx Stop
Alt+Q	Log QSO
Alt+S	Stop Monitoring or Decoding
Alt+V	Save Last

Exclude

Toggle Zap

Alt+X

Alt+Z

Special Mouse Commands

Click on	Action	
Waterfall	FSK441/JT6M: Click to decode ping JT65: Click to set DF for Freeze Double-click to Freeze and Decode	
Main screen, graphics area	FSK441/JT6M: Click to decode ping JT65: Click to set DF for Freeze Double-click to Freeze and Decode	
Main screen, text area	Double-click on callsign sets Tx messages with shorthands, and sets Auto On Right-double-click on callsign sets Tx messages with dB signal reports, and sets Auto On	
Sync, Clip, Tol,	<pre>Left/Right click to increase/decrease values</pre>	

Examples of minimal JT65 QSOs

Station #1	Station #2		
CQ K1JT FN20	1 0		
DL3XYZ K1JT FN20 OOO	K1JT DL3XYZ J061		
223112 1121 11120 000	RO		
RRR	72		
	73		
CO K1JT FN20			
	K1JT VK7ABC QE37		
VK7ABC K1JT -22	K1JT VK7ABC R-23		
VK7ABC K1JT RRR	THE TOTAL VIEW IN THE STATE OF		
	TNX JOE 73		