

Encoder				Z motor				X motor				AUX1			AUX2				
GND	5V	ENCB	ENCA	5V	ENA	DIR	STEP	5V	ENA	DIR	STEP	5V	A11	A12	A13	5V	A21	A22	A23
Encoder				Z motor				X motor				AUX1			AUX2				
GND	5V	ENCB	ENCA	5V	ENA	DIR	STEP	5V	ENA	DIR	STEP	5V	A11	A12	A13	5V	A21	A22	A23