Installation Guideline


Literature Part#: MNL442: Recorder Mounting & VHB Tape Installation


Related Parts:

Hardware Kit (Temporary & Permanent VHB Tapes with Primer Pen, Allen Wrench, 2 Keys & 4 screws for PDC Mounting) - DV443

Windshield Mount Bracket - DV402

IMPORTANT: VHB Tape should only be applied when windshield temperature is within 50°F-100°F (10°C-38°C) to allow proper curing of mounting adhesive pads.





- Clean the windshield with 70% Isopropyl Alcohol on a clean disposable towel or single use alcohol prep pad.
- If using Alcohol Prep Pads USE AT LEAST ONE PER VEHICLE.
- After the Alcohol is completely dry, proceed to the mounting instructions on the next page.

Do not use any other cleaning product on the windshield- Commercial glass cleaners contain surfactants and denatured alcohol which can reduce the effectiveness of the adhesive.

Make sure the windshield is at the correct temperature and the mounting area is clean and dry before proceeding to the next step

Use the Temporary adhesive pad to test mount the recorder.

DO NOT USE THE
PRIMER TO ATTACH THE
TEMPORARY PAD



ONLY INSTALL THE
PRIMER & PERMANENT
TAPE WHEN YOU ARE
SURE OF YOUR
MOUNTING LOCATION



Installation Guideline







Apply Primer 94 to the mounting area on the windshield, it will leave a film when dry

Apply Primer 94 to the bracket. Leave the bracket on the dash away from contaminants

Firmly ROLL the permanent VHB tape onto the windshield to prevent air pockets

Do not mount the bracket to the windshield for at least 30 minutes after the VHB tape is applied. This will give the VHB tape time to cure without the weight of the bracket and the recorder.




VERY IMPORTANT STEP

Apply firm pressure to the VHB

tape especially around all edges for 30 seconds. Allow to cure for

30 minutes

After 30 minutes, remove the clear liner and mount the bracket to the VHB Tape. Once mounted apply pressure for 30 seconds



Attach the Recorder to the bracket and Verify no air pockets

Mount the bracket in a location that allows the lens to be inside the wiper swipe line (Photo A) Make sure the sun visors are not blocking the recorder when mounted (B)

