Installation Guideline

Literature Part #INS5003

PDC & Modem Mounting

Related Parts:

Modem – USA DV405, North America DV425, Europe DV426

DV404 - PDC

Always secure the PDC and modem with a zip tie or self-tapping screw.

A securely mounted PDC and modem will keep the components clear of moving parts and not cause interference with the driver.

Do not secure components to airbag plugs or harnesses



Failure to secure the PDC & modem can result in:

Interference due to EMI.

The modems USB port can come loose or break.

Unsecure cables can rip or disconnect if left loose.

Securely mounted cables and components will keep all installations professional.



When mounting the PDC, always secure extra cables with a zip tie (Photo B).
Loose cables will fall over time and can interfere with the driver

Always make sure panels fit properly when mounting components (Photo C) The blue arrow represents panel placement



Not only will the heat shrink protect the connection but will prevent driver tampering







