

This guide will show the proper way to install a Dual-Vision XC4 Camera in a 2012-2016 Hino 268. Please review the Service Bulletins for grounding and making connections prior to installing. In this guide you will find dash removal, wire locations, & mounting locations.

After testing and verifying power wires, disconnect the negative battery terminal to prevent any accidental shorts or blown fuses

Verify no vehicle service lights are on prior to installation. Contact a Fleet Manager immediately if the vehicle has any damage

UPDATED October 15th, 2018

NEW PART

Harness DV457 is needed if trigger wires are being connected

For Technical Support please contact our support team at:

Techsupport@Roscovision.com



Gray – Caution

Red - Warning

Blue – Extra Installation Parts Needed

Purple - New Installation






IMPORTANT: Windshield Mounting should only be performed when windshield temperature is within 50°F-100°F (10°C-38°C) to allow proper curing of adhesive.

Run the defrost on high heat or use a heat gun in colder temperatures

This assumes you have already performed one temporary install to determine proper Recorder location

Before starting your install, Clean the windshield with 70% Isopropyl Alcohol & allow time to dry

Giving the VHB tape time to cure before mounting the Recorder will give you a permanent bond and prevent recorders from falling off the windshield



Do not use any other cleaning product on the windshield!





VERY IMPORTANT

cleaners contain surfactants & denatured alcohol which can reduce the effectiveness of the adhesive

Commercial glass

- A- Apply Primer to the mounting location on the windshield. It will leave a film when dry.
- B- Apply Primer to the bracket. Leave the bracket on the dash away from contaminants.
- C- After the primer is dry and the windshield is the correct temperature, apply the VHB tape marked PERMANENT by ROLLING the tape onto the glass to avoid air bubbles.
- D- VERY IMPORTANT Push firmly around all edges of the VHB tape. Apply pressure for 30 seconds

Proceed to the next page for Step 1 of the installation. Apply the bracket to the windshield during the last step of the install





Mount the bracket in a location that allows the lens to be inside the wiper swipe line (Photo A)











For passenger vehicles, mount the Recorder behind the rear-view mirror towards the passenger side (Photo B).


For larger trucks or buses, mount the Recorder as shown (Photo C) and make sure the lens is INSIDE the wiper swipe.

When working on emergency vehicles use extreme caution when routing wires around emergency lights and equipment (Photo D)

Always pull down the vehicle sun visors to make sure they don't block or interfere with the Recorder or the video (Photo E).



Installation Layout



Before starting your installation please take note of component mounting locations.



Step 1 - Dash Removal:

Power connections & Mounting location can be accessed on the passenger side of the truck

- Pry the dash starting at the bottom (Photo A)
- This will give you access to mounting location of the PDC & the Modem
- Remove the four 10MM bolts securing the top panel (Photo B) and center console. Pull the top panel off, and pull the side panel enough to reach the power connections.



Α




В



Step 2 - Power Connections:

- Locate the white 15 pin plug located under the support brace (Photo C)
- Connect the RED Constant wire to the vehicle white wire & the YELLOW ignition wire to the
 vehicles blue wire. These wires will have clear factory butt connectors already attached to
 them.
- Make your ground connection on the support brace above the plug. Be sure to follow the "Installation Technique" before making your connections.

C





Step 3 - Antenna Mounting:

It's important to mount the antenna on the windshield, with a clear view of the sky

Mount the antenna on the same side of the vehicle as the PDC

Front of Antenna (Flat part needs a clear view of the sky). Bottom of Antenna (Curved part) facing inside the vehicle

Antenna Front "FLAT" side with oval 3M tape applied



Notice the angled part of the antenna is facing down (Photo A & B). Make sure the FLAT SIDE of the antenna has a CLEAR VIEW OF THE SKY and is facing OUTSIDE (Photo C)



After all connections are made, coil up all the extra antenna cable (Photo A)

Never bend the cable. This will cause signal loss and damage to the antenna (Photo B)

Please refer to the Antenna Installation Guideline for complete details





Step 4 - PDC & Modem Connections:

- Connect the USB cable from the modem to the PDC and secure with a zip tie (Photo A)
- Connect the Antenna cable to the modem (Photo B)
- Make these connections prior to mounting the modem & PDC
- Make sure the screw on the modem cover is secured and doesn't move or bend (Photo C)





Connect the MIMO 1 antenna wire to the Modems PRI connector




Connect the MIMO 2 antenna wire to the Modems DIV connector



Step 5 – PDC & Modem Mounting Location:

- The PDC & the Modem are located under the dash panel on the passenger side of the vehicle, on top of the fuse panel.
- Using self-tapping screws, mount the PDC & the Modem to the support bracket





You can now mount the recorder to the VHB tape on the windshield PLEASE READ THE RECORDER MOUNTING & VHB TAPE INSTALLATION GUIDELINE BEFORE PROCEDING TO THE NEXT STEP




Step 6 - Camera Mounting and wire Routing:

IMPORTANT: Windshield Mounting should only be performed when windshield temperature is within 50°F-100°F (10°C-38°C) to allow proper curing of adhesive

At this point you can now mount the Recorder bracket to the VHB tape applied to the windshield on Step 1

Mount the bracket to the VHB tape and apply pressure for 30 seconds (A)

With the vehicle off, hook the Recorder to the bracket from the top (1), then swing down (2)







To verify proper angle & correct mounting, press the driver activity button. Logon to your Rosco account and view activity to confirm proper angle

