# ImperialViolet

# RISC-V assembly (31 Dec 2016)

RISC-V is a new, open instruction set. Fabrice Bellard wrote a Javascript emulator for it that boots Linux <u>here</u> (<u>more info</u>). I happen to have just gotten a physical chip that implements it too (one of <u>these</u>) and what's cool is that you can get the source code to the chip <u>on GitHub</u>.

The full, user-level instruction set is <u>documented</u> but there's a lot of information in there. I wanted a brief summary of things that I could keep in mind when reading disassembly. This blog post is just a dump of my notes; it's probably not very useful for most people! It also leaves out a lot of things that come up less frequently. There's also an unofficial <u>reference card</u> which is good, but still aimed a little low for me.

RISC-V is little-endian and comes in 32 and 64 bit flavours. In keeping with the RISC-V documents, the flavour (either 32 or 64) is called XLEN below in the few places where it matters.

For both, int is 32 bits. Pointers and long are the native register size. Signed values are always sign extended in a larger register and unsigned 8- and 16-bit values are zero extended. But unsigned 32-bit values are sign-extended. Everything has natural alignment in structs and the like, but alignment isn't required by the hardware.

The stack grows downwards and is 16-byte aligned upon entry to a function.

Instructions are all 32 bits and 32-bit aligned. There is a compressed-instruction extension that adds 16-bit instructions and changes the required alignment of all instructions to just 16 bits. Unlike Thumb on ARM, RISC-V compressed instructions are just a short-hand for some 32-bit instruction and 16- and 32-bit instructions can be mixed freely.

There are 31 general purpose registers called x1–x31. Register x0 drops all writes and always reads as zero. Each register is given an alias too, which describes their conventional use:

Register	Alias	Description	Saved by
x0	zero	Zero	
<b>x</b> 1	ra	Return address	Caller
x2	sp	Stack pointer	Callee
<b>x</b> 3	gp	Global pointer	
x4	tp	Thread pointer	
x5-7	t0-2	Temporary	Caller
x8	s0/fp	Saved register / frame pointer	Callee
x9	s1	Saved register	Callee
x10-17	a1–a7	Arguments and return values	Caller
x18-27	s2-11	Saved registers	Callee
x28-31	t3-6	Temporary	Caller

There are two types of immediates, which will be written as 'I' and 'J'. Type 'I' intermediates are 12-bit, signed values and type 'J' are 20-bit, signed values. They are always sign-extended to the width of a register before use.

# **Arithmetic**

There's no carry flag, instead one has to use a comparison instruction on the result in order to get the carry in a register.

A U suffix indicates an unsigned operation. Note that the multiplication and division instructions are part of the 'M' extension, but I expect most chips to have them.

Instruction	Effect	Notes	
ADD dest,src1,src2	dest = src1 + src2		
SUB dest,src1,src2	dest = src1 - src2		
ADDI dest,src1,I	dest = src1 + I		
MUL dest,src1,src2	$dest = src1 \times src2$		
MULH[ U SH] dest,src1,src2	$dest = (src1 \times src2)$	This returns	the
	>> XLEN	high word of	the
		multiplication	
		result	for
		signed×signed,	
		unsigned×unsig	ned
		or	

signed×unsigned,

respectively

DIV[U] dest,src1,src2

dest = src1/src2

There's no trap on

divide-by-zero,

rather special

values are

returned. (See

documentation.)

REM[U] dest,src1,src2

dest = src1%src2

# **Bitwise**

These should all be obvious:

# Instruction

AND dest, src1, src2

OR dest, src1, src2

XOR dest,src1,src2

ANDI dest, src1, I

ORI dest, src1, I

XORI dest, src1, I

# **Shifts**

Instructions here are Shift [Left|Right] [Logical|Arithmetic].

Note that only the minimal number of bits are read from the shift count. So shifting by the width of the register doesn't zero it, it does nothing.

Instruction	Effect	Notes
SLL dest,src1,src2	dest = src1 << src2%XLEN	
SRL dest,src1,src2	dest = src1 >> src2%XLEN	
SRA dest,src1,src2	dest = src1 >> src2%XLEN	
SLLI dest, src1,031/63	$s dest = src1 \ll I$	
SRLI dest, src1,031/63	s dest = src1 >> I	
SRAI dest,src1,031/63	s dest = src1 >> I	

# **Comparisons**

These instructions set the destination register to one or zero depending on whether the relation is true or not.

Instruction	Effect	Notes		
SLT dest,src1,src2	dest = src1 < src2	(signed com	pare)	
SLTU dest,src1,src2	dest = src1 < src2	(unsigned co	ompare)	
SLTI dest,src1,I	dest = src1 < I	(signed com	pare)	
SLTIU dest,src1,I	dest = src1 < I	(unsigned	compare,	but
		remember	that	the

immediate is sign-extended first)

#### **Control flow**

The JAL[R] instructions write the address of the next instruction to the destination register for the subsequent return. This can be x0 if you don't care.

Many instructions here take an immediate that is doubled before use. That's because no instruction (even with compressed instructions) can ever start on an odd address. However, when you write the value in assembly you write the actual value; the assembler will halve it when encoding.

Instruction	Effect	Notes
JAL dest,J	dest = pc+2/4	
	pc+=2*J	
JALR dest,src,I	dest = pc+2/4	Note that the least-significant
	pc=src1+(I&~1)	bit of the address is ignored
BEQ src1,src2,I	if src1==src2,	
	pc+=2*I	
BNE src1,src2,I	if src1!=src2,	
	pc+=2*I	
BLT src1,src2,I	if src1 <src2,< td=""><td>signed compare</td></src2,<>	signed compare

pc+=2\*I

# Memory

The suffix on these instructions denotes the size of the value read or written: 'D' = double-word (64 bits), 'W' = word (32 bits), 'H' = halfword (16 bits), 'B' = byte. Reading and writing 64-bit values only works on 64-bit systems, and LWU only exists on 64-bit systems because it's the same as LW otherwise.

Alignment is not required, but might be faster. Also note that there's no consistent direction of data flow in the textual form of the assembly: the register always comes first.

Instruction Effect Notes L[D|W|H|B] dest,I(src) dest = \*(src + I) result is sign extended L[D|W|H|B]U dest,I(src) dest = \*(src + I) result is zero extended S[D|W|H|B] src1,I(src2) \*(src2 + I) = src1

# **Other**

# **Instruction Effect Notes**

LUI dest, J dest = J << 12 "Load Upper Immediate". The result is sign extended on 64-bit.

AUIPC dest, J dest = pc + "Add Upper Immediate to PC". The result of the shift is sign-extended on 64-bit before the addition.

# W instructions

These instructions only exist on 64-bit and are copies of the same instruction without the 'W' suffix, except that they operate only on the lower 32 bits of the registers and, when writing the result, sign-extend to 64 bits. They are ADDW, SUBW, ADDIW, DIV[U]W, REM[U]W, S[L|R]LW, SRAW, S[L|R]LIW and SRAIW

# **Pseudo-instructions**

For clarity, there are also a number of pseudo-instructions defined. These are just syntactic sugar for one of the primitive instructions, above. Here's a handful of the more useful ones:

Pseudo-	Tuonglation		
instruction	Translation		
nop	addi x0,x0,0		
mv dest,src	addi dest,src,0		
not dest,src	xor dest,src,-1		

seqz dest,src sltiu dest,src,1

snez dest,src sltu dest,x0,src

j J jal x0,J

ret jalr x0,x1,0

call offset auipc x6, offset >> 12; jalr x1,x6,offset & 0xfff

li dest, value (possibly several instructions to load arbitrary

value)

& 0xfff

l[d|w|h|b] auipc dest, symbol >> 12; lx dest, offset &

dest, symbol 0xfff(dest)

s[d|w|h|b] auipc dest, symbol >> 12; sx dest, offset &

src,symbol 0xfff(dest)

Note that the instructions that expand to two instructions where the first is AUIPC aren't quite as simple as they appear. Since the 12-bit immediate in the second instruction is sign extended, it could end up negative. If that happens, the J immediate for AUIPC needs to be one greater and then you can reach the value by subtracting from there.