PLI			PLI
8	M1 SKT8/A	M1 54/AF	4
C	M2 SkT8/C	5 4 /AC	3
K	M3 SKYB/E	M3 54/AD	9
1	M4 Skt8#G	M4 54/AB	8
N	M5 SKT@/J	M5 54/X	13
•	M6 SKTB/L	M6 54/V	14
W	M7 SKT 6/N	M7 547R	19
V	M 8 SKTB/R	M8 54/M	18
Z	M9 SK18/Y	M9 54/L	22
M	M10 SK78±V	M10. 54/F	23
A D	M11 SKT6/X	M11 54/K	27
A C	M12 SKT8/2	M12 54/7	26
E	м13 SKT8/ <u>Б</u>	M13	5
F	M14 SKT 8/4	M14 54/U	6
-	M15 ŠĶT8/ <u>f</u>	M15 54/5	10
S	MI6 SKT8/ <u>h</u>	M16 54/AH	17
AH	M17 SKT17/A	M17 54/21	11
Ų	M18 SKT17/C	M18 54/Z	21
8 2	+6V		
32 AL	T6-8		
AL AKI	BOARD ATHX. LINK BOARD. BOARD POSITION 51,	B8	

a. a.