

M0FXB HamTech Dashboard

ASL3 Share Package - Installation Guide

Install the shared web-dashboard package on an AllStarLink ASL3 node while keeping the included dashboard set and configuring HamTech for the destination node.

Package	M0FXB-HamTech-ASL3-Share.zip
Transfer	Windows PowerShell - SCP/SSH
Node number	Entered during installation
Web login	Created during installation

Before you start

Have the ZIP on your Windows PC, the ASL3 node IP address, and an SSH account that can use sudo. Keep both devices on a reachable network.

Security: the source node's `.htpasswd` is not included. A fresh dashboard password is created during installation. Use HTTP Basic Auth only on a trusted LAN or through a VPN.

1. Copy the ZIP to ASL3

Open PowerShell where the ZIP is stored. Replace the example username/IP when needed.

```
scp "M0FXB-HamTech-ASL3-Share.zip" allstar3@192.168.0.205:/tmp/
```

Enter the SSH password when prompted. Password characters are not displayed.

2. Connect and extract

```
ssh allstar3@192.168.0.205
```

Then, on the ASL3 terminal:

```
cd /tmp
unzip M0FXB-HamTech-ASL3-Share.zip
cd M0FXB-HamTech-ASL3-Share
```

If unzip is missing: `sudo apt-get install -y unzip`

3. Run the installer

```
sudo bash install.sh
```

Enter the destination AllStar node number, dashboard title, web username, and a new dashboard password. The default username offered is `admin`.

What the installer changes

It installs Apache/PHP requirements, backs up the existing `/var/www/html`, copies the included dashboards, writes HamTech's node configuration, updates its AllStar stats links, creates the web login, configures Apache, and validates the sudoers rule used for Asterisk controls.

If the stock commented `*806 = ilink,6` mapping exists, it backs up `rpt.conf`, enables that mapping, and restarts Asterisk.

4. Open and test

The installer prints the web address. Open it from a browser on the trusted network, for example:

```
http://192.168.0.205/
```

Log in with the web username/password created during installation. Test a normal link tile, then Parrot On: key the radio, speak, release PTT, and confirm the audio repeats. Click Parrot Off when finished.

If Asterisk reports Unknown node number, verify the active numeric node section in `/etc/asterisk/rpt.conf` and check `/var/www/html/config.ini`.

Editing HamTech tiles

```
sudo nano /var/www/html/buttons.ini
```

Save with Ctrl+O, Enter, then Ctrl+X. Refresh the browser. The file controls tile titles, colours, links, and configured AllStar/Asterisk commands.

Useful checks

```
sudo apache2ctl configtest
systemctl --no-pager status apache2
systemctl --no-pager status asterisk
```

Backup

The installer prints a timestamped backup path under `/var/backups/m0fxb-webroot - . . .`. Keep that path if you may need to restore the previous web root.