


Lab 4

The Intuition Behind FIR Filters

FIR filter computational structure

CU Boulder

- ▶ The FIR Filter Structure is the following
 - This computes the convolution of $x(n)$ with $c(n)$



The roadmap to intuitive insight

CU Boulder


► We will ask and answer:

- What is the sum of multiple sinusoids, all at the same frequency but with different amplitudes and phases?
 - ✓ Answer: a sinusoid of the same frequency with an amplitude and phase we can compute
- What is the output of an FIR filter when a sinusoid is input?
 - ✓ Answer: the sum of N sinusoids, all at the same frequency but with different amplitudes and phases—hence: a sinusoid of the same frequency as the input!
- How can we use the above to design a filter with an arbitrary frequency response?

The projection of a rotating vector is a cosine

CU Boulder

- ▶ The projection of any vector rotating around the origin is a sinusoid at the rotation frequency



As the red vector rotates counterclockwise at the frequency f , its projection onto the x-axis at time t is:

$$A_1 \cos(2\pi ft + \theta_1)$$


The vector is drawn for $t = 0$

Summing sinusoids at the same frequency

CU Boulder

- ▶ Any sum of two sinusoids, both at the same frequency, yields a sinusoid at that frequency

- As the red and blue vectors rotate, their vector sum (green arrow) rotates at the same rate. Its projection is therefore a sinusoid at the same frequency



Extension to arbitrary sum of sinusoids

CU Boulder

- ▶ **Any sum of sinusoids all at the same frequency is a sinusoid at that frequency**
 - Proof: suppose you are adding up 4 sinusoids
 - ✓ Add the first 2 sinusoids; then add that sum to the third sinusoid; then add that sum to the last sinusoid
 - At each step you are adding two sinusoids at the same frequency, so you get another sinusoid at that same frequency

Formula for adding multiple sinusoids at the same frequency


CU Boulder

► Determine the final vector with vector addition

- The x component of the final vector is the sum of the x components of the individual sinusoids
- The y component of the final vector is the sum of the y components of the individual sinusoids

$$S_x = \sum_{n=1}^N A_n \cos \theta_n$$

$$S_y = \sum_{n=1}^N A_n \sin \theta_n$$



Magnitude and angle of final vector

CU Boulder


- ▶ The magnitude and angle of the final rotating vector

$$| \underline{S} | = \sqrt{(S_x, S_y) \cdot (S_x, S_y)}$$

$$\theta_S = \tan^{-1} \frac{S_y}{S_x}$$

The projection of \underline{S} onto the x-axis as a function of t


$$s(t) = | \underline{S} | \cos(2\pi ft + \theta_S)$$



Decomposing an FIR filter

CU Boulder


- ▶ Consider a two-tap FIR



Decomposing an FIR filter cont.

CU Boulder

- ▶ We can decompose it into two FIRs as follows



If a sinusoid is input, both the top and bottom paths produce a sinusoid at the same frequency (the bottom path has a different amplitude and is phase shifted by one sample). The output is therefore a sinusoid!

Extension to more taps

CU Boulder

- ▶ The preceding argument obviously extends to an arbitrary number of taps

A sinusoid applied to an FIR's input produces a sinusoid of the same frequency at its output. The magnitude and phase may be changed.

FIR's output for a sinusoidal input

CU Boulder

- ▶ **Assume a sinusoid of magnitude 1 is input to an FIR filter**

- Let F_s be the sampling frequency and f be the sinusoid's frequency. The sampling period is $T = 1 / F_s$
 - The input to the correlator is

$$x(n) = \cos(2\pi f n T)$$

- ▶ **The m 'th correlator “tap” produces a scaled and delayed version of $x(n)$**

$$\psi_m(n) = c_m \cos(2\pi f n T - \theta_m)$$

The delay angle

CU Boulder

- ▶ **The delay angle of the m 'th tap's sinusoid depends on T , f , and m**
 - A delay of m samples is a delay of mT seconds
 - ✓ The angle corresponding to this time delay depends on f

$$\theta_m = 2\pi f T m$$

We can compute the filter's response to any cosine input!

CU Boulder

- ▶ The following steps can be used to compute the response of a correlator to a magnitude 1 cosine of frequency f
 - Compute the delay angle for each tap m

$$\theta_m = 2\pi f T m$$

- Then compute the “final” vector

$$\underline{S} = \left(\sum_{m=0}^{N-1} c_m \cos \theta_m, - \sum_{m=0}^{N-1} c_m \sin \theta_m \right)$$

Note: a minus sign is needed because the sinusoid is delayed, not advanced. (An advance was used in the derivation)

FIR frequency response

CU Boulder

- ▶ **We can plot the magnitude of the correlator's output as a function of f**
 - This is the magnitude of the vector \underline{S}
 - ✓ We call this plot the “magnitude frequency response”
- ▶ **We can plot the angle of the correlator's output as a function of f**
 - This is the angle of the vector \underline{S}
 - ✓ We call this plot the “phase response”

Example: The Moving Average (MA)

CU Boulder

- ▶ **One of the most common operations for processing a series of data is the “moving average”**
 - It smooths out fluctuations
- ▶ **Assume you have a series of data of some sort**
 - The price of milk each day, the rainfall each month, the number of widgets produced each hour, etc.
- ▶ **Compute an average inside a window of some width**
- ▶ **Slide the window over 1 data point and repeat**

This is an FIR Filter!

The MA FIR filter


CU Boulder

- ▶ Assume the average is computed over a window of length N
- ▶ Let each tap have a value of $1/N$
- ▶ We can compute the response of the moving average filter with N taps as a function of frequency

The MA FIR filter cont.

CU Boulder


- ▶ For 10 taps we have



The MA FIR filter cont.

CU Boulder


- ▶ For 5 taps we have



The MA FIR filter cont.

CU Boulder



- ▶ For 50 taps we have



The MA is a Lowpass Filter (LPF)

CU Boulder

- ▶ It preferentially allows lower frequencies to pass
 - The frequency response depends on the number of taps



What have we learned about taps?

CU Boulder

- ▶ **Different taps give different frequency responses**



Natural questions:

Can we choose taps to get a desired frequency response?

If so, how?

Frequency response of sinusoidal taps


CU Boulder



Sinusoidal taps are a bandpass filter

CU Boulder

The more taps, the narrower the filter's bandwidth



One way to think about filters

CU Boulder


- ▶ **Intuitively, a filter should “let through what we want and stop everything else”**
 - A correlator with sinusoidal taps lets only a desired sinusoid through
 - All other sinusoids are very strongly attenuated as the tap length increases

What if we want more than one sinusoid?

CU Boulder

▶ Use multiple FIR filters in parallel

- Set each to let through a frequency we want
- Sum the outputs of the correlators



A more efficient solution

CU Boulder

▶ **Collapse multiple correlators into 1**

- Add the taps for each desired frequency to get a single set of taps



- This is a digital filter
 - ✓ By choosing the taps the right way, we let through the frequencies we want and suppress the others
 - ✓ Another way of saying this: by choosing the right taps, we can tailor the frequency response

Building a LPF


CU Boulder

- ▶ Choose a number of taps to use
- ▶ Choose a “cutoff” frequency
- ▶ Generate taps for a series of sinusoids that span the desired frequency range
- ▶ Add the taps together
- ▶ Normalize to have energy 1

Example: A LPF







CU Boulder

- ▶ Ideal frequency response



Letting progressively more sinusoids through

CU Boulder




An optional Hann windows was applied to the taps before summing

A more complex frequency response (51 taps)

CU Boulder


Desired frequency response is 1 for $f \leq 0.2$ and $0.4 \leq f \leq 0.45$



And for 101 taps...

CU Boulder


Desired frequency response is 1 for $f \leq 0.2$ and $0.4 \leq f \leq 0.45$



And for 301 taps...

CU Boulder

Desired frequency response is 1 for $f \leq 0.2$ and $0.4 \leq f \leq 0.45$



Designing an FIR filter

CU Boulder

- ▶ Define the ideal frequency response
- ▶ Choose a number of taps and a windowing function
- ▶ Pick a small frequency increment and move from $f = 0$ to $f = \frac{1}{2}$ by this increment. For each frequency, if it is within a passband, generate sinusoidal taps at that frequency
 - Optional: Window the taps (e.g. with a Hann Window)
 - Normalize the taps to have energy 1
 - Accumulate the taps in a final tap vector
- ▶ Normalize the final tap vector to have energy 1


Windowing function example

CU Boulder

- ▶ If we multiply a filter's taps by a tapered “window” the frequency response is changed

Hann Window

$$w(n) = \sin^2\left(\frac{\pi n}{N - 1}\right)$$



Hann windowed frequency response of a sinusoid

CU Boulder

The main lobe is broader but the first side-lobe is smaller

