7. Level 2 Repair

7-1. Disassembly

1) Unscrew the 6 points.



1) Seperate lower part of rear using a decomposition tool.




Caution

- 1) Be care of scratch and molding damage.
- 1) Separate the LCD and Sub key Connectors from PBA.
 - 2) Disassemble the Cam and 3.5phi Earjack.



Caution

- 1) Be care of scratch and molding damage.
- 1) Separate the PBA ASS'Y from the FRONT ASS'Y.




Caution

1) Be care of damage to Connectors, Cam and 3. 1) Be care of scratch and molding damage. 5phi Earjack

Caution

- 2) Be care of damage to FPCB.



7-2. Assembly

1 1) Solder the Receiver.



- 2 1) Insert the 3.5phi earjack FPCB then lock the actuator.
 - 2) Insert the Cam FPCB then lock the actuator.



Caution

- 1) Be care of damage the FPCB.
- 1) Insert the TSP FPCB into the hole of front.
 2) Put the TSP on the upper of the front.





Caution

- 1) Be care of damage the FPCB.
- 4 1 1) Put the LCD on the front matching 4points.
 - 2) Insert the TSP FPCB. then attatch TSP IC.
 - 3) Put the keypad on the front.






Caution

1) Be care of damage the FPCB.

Caution

- 1) Be care of damage to F-CPB and LCD.
- 2) Be care of scratch and molding damage.

- 1) Put the LCD FPCB though the hole of the bracket.
 - 2) Assemble the Sub Cam





- **6** 1) Put the PBA ass'y on the front ass'y.
 - 2) Connect the LCD and Sub key connectors.
 - 3) Push the Cam and 3.5phi earjack.






Caution

- 1) Be care of damage the FPCB.
- 2) Be care of scratch and molding damage.
- Caution
- 1) Be care of damage the FPCB.
- 2) Be care of scratch and molding damage.
- 7 1) Assemble the REAR upper side first.



1) Screw 6 points.(1.2 kg/force)





Caution

1) Be care of scratch and molding damage.

Caution

1) Be care of scratch and molding damage.