## List of Default Router Passwords and Default Router IP Addresses

## Lost your **router password**?

Would like to know the **default password for your router** (sometimes called the *router admin password* or *router password*), or the **default IP address for your router?** 

Forgot your NAS box default login password, your network printer default login username and password, your wireless access point default IP address and login details, your router password and default router login?

Look no further – this document lists the default router passwords, default router logins, default router IP address for all the routers we have come across, whether LAN & WAN routers, wireless routers, DSL/ADSL modem routers, or Cable Modem routers. It also lists the default NAS devices and printer login and passwords. The default settings listed below are those which these routers have by default out of the box, or which they revert to when you manually reset a router (usually with a paperclip through a pinhole on the router). When there are multiple choices for a manufacturer, we highlight the most probable default in Blue.

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
<b>2Wire</b> (As supplied by AT&T, Bell, BT, and many	192.168.1.254	admin	2wire
others)			Wireless
<b>3Com</b> (3CRWDR100A-72, 3CRWDR101A-75, etc)	192.168.1.1	n/a	admin
3Com		adminttd	adminttd
3Com		admin	n/a
3Com		n/a	PASSWORD
3Com		root	!root
ACC		netman	netman
ACCTON	192.168.2.1	n/a	0
Aceex	192.168.8.1	admin	n/a
Aceex	10.0.0.2	admin	epicrouter
Actiontec		n/a	n/a

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
ADC Kentrox		n/a	secret
Adtran		n/a	n/a
AirLink+	192.168.1.1	admin	admin
Aiway		0	n/a
Allied Telesyn		root	n/a
Allied Telesyn		Manager	Friend
Allnet		admin	admin
Ambit	192.168.100.1	user	user
Ambit	192.168.100.1	admin	password
Ambit		root	n/a
AMD RAID Xpert software		admin	admin
Amitech		admin	admin
Apple	10.0.1.1	n/a	n/a
Arescom		n/a	atc123
Arescom	192.168.1.1	dsladmin	n/a
Ascend		admin	ascend
Ascend		n/a	ascend
Ascom			
Asmack		admin	epicrouter
ASUS	192.168.1.1	admin	admin
Avaya		root	root
Barracuda Message Archiver	<b>192.168.200.200</b> (Hold Reset for 5 seconds)	admin	admin
Barracuda Spam Firewall	192.168.1.200		
Barracuda SSL VPN	(Hold Reset for 8 seconds)		
Barracuda Web Filter	<b>10.1.1.200</b> (Hold Reset for 12 seconds)		
Bausch Datacom	10.0.0.2	admin	epicrouter
Bay Networks		User	n/a

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
Bay Networks		Manager	n/a
Bay Networks		Manager	Manager
BE Internet router (BE Box) (usually a rebadged Thomson Telecom SpeedTouch router)	192.168.1.254	Administrator	<blank></blank>
BE Internet router (BEBox) (From 2011 onwards)	192.168.1.254	Administrator	Serial Number of the router
Belkin	192.168.2.1	n/a	n/a
Belkin		admin	n/a
Benq		Admin	admin
Bintec		admin	bintec
Boson		n/a	n/a
Broadlogic		admin	admin
Broadlogic		installer	installer
Broadlogic		webadmin	webadmin
Buffalo	192.168.11.1	root	<blank></blank>
Cable & Wireless		Admin	1234
Cabletron		netman	n/a
Cabletron		n/a	n/a
Canyon		Administrator	admin
Canyon	192.168.62.1	admin	1234
Cayman		Any	n/a
Cisco		cisco	cisco
Cisco		n/a	san-fran
Conexant		n/a	admin
Conexant		n/a	epicrouter
Dell	192.168.1.1	admin	admin
Digicorp		n/a	BRIDGE
Digicorp		n/a	password

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
D-Link	192.168.0.1	n/a	n/a
	192.168.0.30		
	192.168.0.50		
D-Link	192.168.0.1 or	Admin	Admin
	192.168.1.1		
D-Link		n/a	admin
D-Link		admin	n/a
D-Link		user	n/a
D-Link		n/a	1234
D-Link		n/a	year2000
<b>D-Link print server</b> (e.g. DPR-1020)	Picks it up from the network's DHCP server	Admin	<black></black>
	Alternatively, enter into your browser dlink-XXXXXX where XXXXXX are the last 6 digits on the MAC code on the underside of the print server.		
E-Con		admin	epicrouter
Edimax		admin	1234
Efficient		login	admin
Efficient		admin	admin
Efficient Networks		n/a	hs7mwxkk
Elsa		n/a	cisco
Ericsson (Formerly ACC)		netman	netman
E-Tech		n/a	admin
E-Tech	10.0.0.2	admin	epicrouter
Flowpoint	192.168.254.254	n/a	admin
Flowpoint		n/a	password
Fujitsu Siemens		n/a	connect
Gateway		admin	admin
IBM		n/a	ascend

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
Infosmart		admin	0000
Intel		admin	hello
Intel		NICONEX	NICONEX
Intel		n/a	babbit
Ipstar		admin	operator
JAHT	10.0.0.2	Admin	epicrouter
Linksys		Administrator	admin
Linksys	192.168.0.1	n/a	admin
	192.168.1.1		
	192.168.1.225		
	192.168.1.226		
	192.168.1.245		
	192.168.1.246		
Linksys	192.168.1.1	admin	admin
	192.168.1.251		
Livingston		!root	n/a
MacSense		admin	admin
Medion		n/a	medion
Microsoft Broadband Networking Routers also known as "Base Station" routers	192.168.2.1	admin	admin
Microsoft Broadband Networking Routers also known as "Base Station" routers		n/a	admin
Mikrotik		admin	n/a
Motorola		cablecom	router
Motorola		admin	motorola
Motorola		admin	password
Netgear  (All DSL modem routers, cable modem routers, and LAN routers from 2005 onwards)	192.168.0.1	admin	password
Netgear	192.168.0.227	admin	password

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
Netgear		n/a	1234
Netgear		Admin	1234
Netgear ReadyNAS Duo	<assigned by="" network="" your=""></assigned>	admin	netgear1
Nortel Telephone System (Works on a BCM 50, but likely to work on all BCM systems)	<ip integrated="" network="" with="" your=""></ip>	nnadmin	PlsChgMe!
Nokia		m1122	m1122
Olitec		admin	admin
Olitec		admin	adslolitec
Pentagram		admin	password
Pentagram		n/a	pento
Pirelli		admin	mu
Pirelli		admin	microbusiness
Pirelli		user	password
Samsung network printers		admin	sec00000
Sharp photocopiers		Admin	sharp
Siemens		superuser	admin
Sitecom	192.168.0.254	admin	admin
Sitecom	192.168.0.1	n/a	sitecom
SmartSwitch		admin	n/a
SMC	192.168.2.1	n/a	n/a
SMC		admin	admin
SMC	192.168.2.25	admin	smcadmin
SMC		n/a	smcadmin
SMC		admin	barricade
SMC		cusadmin	highspeed
SMC		n/a	0000
SMC	192.168.2.1	n/a	n/a
Speed Touch (Alcatel)	10.0.0.138	Administrator	n/a
Speedstream		admin	admin

Router Name	Default Router IP Address	Default Router Login User Name	Default Router Password
T-Comfort		Administrator	n/a
Teledat		admin	1234
Telekom Malaysia		ZXDSL	ZXDSL
Telekom Malaysia		ADSL	expert03
Teletronics	192.168.1.1	admin	1234
Telnet	192.168.1.1	n/a	n/a
TP-Link	192.168.1.1	admin	admin
UNEX		n/a	password
US Robotic	192.168.123.254	admin	admin
US Robotic		admin	n/a
US Robotic		root	12345
US Robotic		n/a	12345
Westell		admin	sysadmin
X-Micro		super	super
X-Micro		1502	1502
Xyplex		n/a	access
Xyplex		n/a	system
Yakumo		admin	admin
Zyxel		admin	admin
Zyxel	192.168.1.1	admin	1234
Zyxel		n/a	1234
Zyxel		n/a	n/a