
## Stepper motor driver DRV8825 board

solde.red/333000



Potentiometer - Reference voltage for winding current set



VIN: 8.2-45V

- Power LED





