CHAPTER

38

WATER/WASTE



CHAPTER 38 WATER/WASTE

| Subject/Page | Date | Subject/Pa | ge Date | Subject/Page | Date |
|--------------|---------------|------------|---------------|--------------|------|
| 38-EFFECTIV | /E PAGES | 38-30-07 | (cont) | | |
| 1 | Feb 05/2016 | 2 | Aug 05/2014 | | |
| 2 | BLANK | 38-30-08 | | | |
| 38-CONTENT | S | 1 | Aug 05/2014 | | |
| 0 1 | Feb 05/2016 | 2 | Aug 05/2014 | | |
| 2 | BLANK | 38-30-09 | 3 | | |
| 38-10-01 | | 1 | Aug 05/2015 | | |
| R 1 | Feb 05/2016 | 2 | Aug 05/2015 | | |
| 2 | Aug 05/2014 | 38-30-10 | 7 tag 00/2010 | | |
| 3 | Aug 05/2014 | | A 05/2015 | | |
| 4 | BLANK | 1 | Aug 05/2015 | | |
| 38-30-01 | | 2 | Aug 05/2015 | | |
| 1 | Aug 05/2014 | 3 | Aug 05/2015 | | |
| 2 | Aug 05/2014 | 4 | Aug 05/2015 | | |
| 3 | Aug 05/2014 | 5 | Aug 05/2015 | | |
| 4 | Aug 05/2014 | 6 | Aug 05/2015 | | |
| 38-30-02 | 7 tag 00/2011 | 7 | Aug 05/2015 | | |
| 1 | Aug 05/2014 | 8 | Aug 05/2015 | | |
| 2 | • | 38-30-11 | | | |
| 38-30-03 | Aug 05/2014 | 1 | Aug 05/2014 | | |
| | F-b 05/2010 | 2 | Aug 05/2014 | | |
| R 1 | Feb 05/2016 | 3 | Aug 05/2014 | | |
| 2 | Aug 05/2014 | 4 | BLANK | | |
| 38-30-04 | | 38-30-15 | | | |
| 1 | Aug 05/2015 | R 1 | Feb 05/2016 | | |
| 2 | Aug 05/2015 | | | | |
| 3 | Aug 05/2015 | R 2 | Feb 05/2016 | | |
| 4 | Aug 05/2015 | 3 | Aug 05/2015 | | |
| 5 | Aug 05/2015 | 4 | Aug 05/2015 | | |
| 6 | BLANK | R 5 | Feb 05/2016 | | |
| 38-30-05 | | R 6 | Feb 05/2016 | | |
| 1 | Aug 05/2014 | 7 | Aug 05/2015 | | |
| 2 | Aug 05/2014 | 8 | BLANK | | |
| 38-30-06 | | | | | |
| 1 | Aug 05/2014 | | | | |
| 2 | Aug 05/2014 | | | | |
| 38-30-07 | | | | | |
| 1 | Aug 05/2014 | | | | |

A = Added, R = Revised, D = Deleted, O = Overflow

38-EFFECTIVE PAGES



CHAPTER 38 WATER/WASTE

| SUBJECT | TITLE | PART NO. |
|----------------|--|-----------------------------------|
| 38 | WATER/WASTE | |
| 38-10-01 | TEST CABLE - POTABLE WATER QUANTITY TRANSMITTER | A38010-11, -45 |
| 38-30-01 | BLOCKAGE REMOVAL TOOL - VACUUM LAVATORY SYSTEM | G38004-10, -13 |
| 38-30-02 | BLOCKAGE REMOVER - VACUUM TOILET | A38003-20, -30 |
| 38-30-03 | PLUG - VACUUM WASTE SYSTEM | A38007-9 |
| 38-30-04 | VACUUM TEST EQUIPMENT - VACUUM WASTE SYSTEM | A38001-16, -22, -68 |
| 38-30-05 | CLEANER - LAVATORY WASTE TANK | A38009-11 |
| 38-30-06 | BLOCKAGE REMOVAL EQUIPMENT - VACUUM WASTE SYSTEM | G38006-1 |
| 38-30-07 | DRAIN MAST PLUG - WASTE WATER | C38001-23, -29 |
| 38-30-08 | TESTER - TOILET VACUUM | A38006-1, -19 |
| 38-30-09 | PLUG EQUIPMENT - SKIN FITTING, DOOR SILL DRAIN | C38002-1 |
| 38-30-10 | PUMP EQUIPMENT - VACUUM LAVATORY SYSTEM | A38012-1, -18, -31, -32, -39, -40 |
| 38-30-11 | INSTALLATION ASSEMBLY - SLEEVE, WASTE TANK | C38003-1 |
| 38-30-15 | PUMP EQUIPMENT - VACUUM LAVATORY SYSTEM | J38004-232, -247 |

38-CONTENTS



PART NUMBER: A38010-11, -45

NAME: TEST CABLE - POTABLE WATER QUANTITY TRANSMITTER

AIRPLANE MAINTENANCE: YES

AMM 38-14-01

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38010-11 (option) and A38010-45 (preferred) potable water quantity

transmitters are used on 737-600 thru -900 airplanes.

A38010 is used to provide electrical access to the water tank quantity transmitter for calibration, using a customer furnished voltmeter.

Refer to the current A38010 tool drawing and AMM 38-14-01 for complete

usage instructions,

The A38010-11 and -45 potable water quantity transmitter consist of:

| A38010-11 | | | |
|-----------|----------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | CABLE ASSEMBLY | A38010-14 | |
| 1 | STORAGE BOX | | |


| A38010-45 | | | |
|-----------|----------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | CABLE ASSEMBLY | A38010-14 | |
| 1 | STORAGE BOX | | |


WEIGHT: 10 lbs (5 kg)

DIMENSIONS: 16 x 13 x 7 inches (406 x 330 x 178 mm)

NOTE: A38010-45 replaces A38010-11 for future procurement.







AFT CARGO COMPARTMENT




H60290 S0006831961_V2

Water Quantity Transmitter Location Figure 1

38-10-01

Page 2 Aug 05/2014





Water Quantity Transmitter Test Cable Figure 2

38-10-01

Page 3 Aug 05/2014



PART NUMBER: G38004-10, -13

NAME: BLOCKAGE REMOVAL TOOL - VACUUM LAVATORY SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The G38004-10 or -13 (preferred) blockage removal tool is used on

737-600 thru -900 airplanes.

G38004 is used to clear blockages in the 2-inch plumbing of the vacuum lavatory system. G38004 is used by clamping it to the end of a waste line and pressurized either by hand or shop air. The pressure is then released against the water and blockage filling the waste line. G38004 is not for use

on the toilets or the 4-inch lavatory service plumbing.

Refer to the current G38004 drawing and AMM 38-32-00 for complete

usage instructions.

G38004-10 and -13 consist of:

| G38004-10 | | | |
|-----------|--------------------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | BLOCKAGE REMOVAL TOOL ASSEMBLY | G38004-11 | |
| 1 | STORAGE BOX | | |

| G38004-13 | | | |
|-----------|--------------------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | BLOCKAGE REMOVAL TOOL ASSEMBLY | G38004-14 | |
| 1 | STORAGE BOX | | |

WEIGHT: G38004-10 - 12 lbs (5.4 kg)

G38004-13 - 14 lbs (6.4 kg)


DIMENSIONS: G38004-10 - 33 x 10 x 16 inches (838 x 254 x 406 mm)


G38004-13 - 33 x 17 x 16 inches (838 x 432 x 406 mm)

NOTE: G38004-13 replaces G38004-10 for future procurement.

G38004-10 supersedes G38004-6.







FORWARD CARGO COMPARTMENT




1342860 S0000238846_V2

Vacuum Lavatory System Blockage Removal Tool Figure 1 (Sheet 1 of 3)

38-30-01

Page 2 Aug 05/2014






Vacuum Lavatory System Blockage Removal Tool Figure 1 (Sheet 2 of 3)

38-30-01

Page 3 Aug 05/2014





VACUUM WASTE LINE CONNECTION



1342869 S0000238849_V2

Vacuum Lavatory System Blockage Removal Tool Figure 1 (Sheet 3 of 3)

38-30-01

Page 4 Aug 05/2014



PART NUMBER: A38003-20, -30

NAME: BLOCKAGE REMOVER - VACUUM TOILET

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38003-20 or -30 (preferred) blockage remover is used on all

737-600 thru -900 airplanes.

A38003 is used for removing an obstruction between the toilet bowl and

the diaphragm valve.

Refer to the current A38003 drawing and AMM 38-32-00 for complete

usage instructions.

A38003-20 and -30 consist of:

| A38003-20 | | | |
|-----------|------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | REMOVAL ASSEMBLY | A38003-21 | |
| 1 | STORAGE BOX | | |

| A38003-30 | | | |
|-----------|------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | REMOVAL ASSEMBLY | A38003-31 | |
| 1 | STORAGE BOX | | |


WEIGHT: A38003-20 or -30 - 4 lbs (2 kg)

DIMENSIONS: A38003-20 or -30 - 27 x 5 x 3 inches (686 x 127 x 76 mm)

NOTE: A38003-30 replaces A38003-20 for future procurement.

A38003-20 supersedes A38003-14.





F89569 S0006831967_V4

Vacuum Toilet Blockage Remover Figure 1

38-30-02

Page 2 Aug 05/2014



PART NUMBER: A38007-9

NAME: PLUG - VACUUM WASTE SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-01

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38007-9 plug is used on all 737-600 thru -900 airplanes.

A38007 is used to plug the vacuum waste line when a toilet is removed for

repairs.

Refer to the current A38007 drawing and AMM 38-32-01 for complete

usage instructions.

A38007-9 consists of:


| A38007-9 | | | |
|----------|---------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | PLUG ASSEMBLY | A38007-10 | |
| 1 | STORAGE BOX | | |

WEIGHT: 1 lb (0.45 kg)


DIMENSIONS: 3 x 3 x 2 inches (76 x 76 x 51 mm)

NOTE: A38007-9 supersedes A38007-1.





TOILET ASSEMBLY



M53291 S0006831969_V6

Vacuum Waste System Plug Usage Figure 1



PART NUMBER: A38001-16, -22, -68

NAME: VACUUM TEST EQUIPMENT - VACUUM WASTE SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38001-16 (option) or A38001-22 (preferred) plug equipment and the

A38001-68 vacuum source are used on all 737 airplanes except 737-100

thru -500 airplanes.

The A38001-16 or -22 plug equipment consists of plugs for the vacuum waste lines that connect to the inlet and outlet of the vacuum blower and vent nozzle plug assembly. A38001-16 or -22 plugs the vacuum waste system and provides a connection for leak detection equipment.

The A38001-68 vacuum source provides the vacuum required for the leak

detection.

Refer to AMM 38-32-00 and the current A38001 drawing for complete

usage instructions.

A38001-16, -22 and -68 consist of:

| A38001-16 PLUG EQUIPMENT | | | |
|--------------------------|--------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | OUTLET PLUG | A38001-2 | |
| 1 | PLUG | A38001-3 | |
| 1 | VENT PLUG ASSEMBLY | A38001-4 | |
| 1 | STORAGE BOX | | |

| A38001-22 PLUG EQUIPMENT | | | |
|--------------------------|--------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | OUTLET PLUG | A38001-2 | |
| 1 | PLUG | A38001-3 | |
| 1 | VENT PLUG ASSEMBLY | A38001-4 | |
| 1 | STORAGE BOX | | |

| A38001-68 VACUUM SOURCE | | | |
|-------------------------|----------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | HOSE ASSEMBLY | A38001-26 | |
| 1 | CONTROL BOX ASSEMBLY | A38001-69 | |
| 1 | STORAGE BOX | | |

WEIGHT: A38001-16 or -22 - 11 lbs (5 kg)

A38001-68 - 25 lbs (11 kg)




DIMENSIONS: A38001-16 or -22 - 15 x 9 x 5 inches (381 x 229 x 127 mm)

A38001-68 - 14 x 14 x 19 inches (356 x 356 x 483 mm)


NOTE: A38001-22 replaces A38001-16 for future procurement.


A38001-68 supersedes A38001-25.



Vacuum Waste System Vent Plugs Figure 1








M51507 S0006831972_V5


Vacuum Waste System Vent Plug Components Figure 2 (Sheet 1 of 2)

38-30-04

Page 3 Aug 05/2015







1342912 S0000238834_V3

Vacuum Waste System Vent Plug Components Figure 2 (Sheet 2 of 2)

38-30-04

Page 4 Aug 05/2015



| REPAIRABLE/REPLACEABLE PARTS | | | |
|------------------------------|--------------|----------------|-------------|
| ITEM NUMBER | PART NUMBER | NOMENCLATURE | VENDOR CODE |
| [1] | A38001-3 | INLET PLUG | |
| [2] | A38001-2 | OUTLET PLUG | |
| [3] | A38001-15 | STOP | |
| [4] | MS16562-234 | SPRING PIN | |
| [5] | VEAC6-6M | VALVED COUPLER | 78357 |
| [6] | VEAN6-6M | VALVED NIPPLE | 78357 |
| [7] | 301030A-8-32 | BLIND NUT | 51506 |



PART NUMBER: A38009-11

NAME: CLEANER - LAVATORY WASTE TANK

AIRPLANE MAINTENANCE: YES

AMM 38-32-07

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38009-11 cleaner is used on 737-600 thru -900 airplanes.

A38009 is mounted on the vacuum waste tank in place of one of the waste tank rinse nozzles and delivers cleaning water to the inside of the waste tank. The part of A38009 located inside of the waste tank contains a rotating nozzle, the other end attaches to the service truck rinse hose.

Refer to the current A38009 drawing and AMM 38-32-07 for complete

usage instructions.


A38009-11 consists of:


| A38009-11 | | | |
|-----------|---------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | HOSE ASSEMBLY | A38009-12 | |
| 1 | STORAGE BOX | | |

WEIGHT: 20 lbs (9 kg)

DIMENSIONS: 16 x 14 x 5 inches (406 x 356 x 127 mm)







F91771 S0006831974_V3

Lavatory Waste Tank Cleaner Figure 1

38-30-05

Page 2 Aug 05/2014



PART NUMBER: G38006-1

NAME: BLOCKAGE REMOVAL EQUIPMENT - VACUUM WASTE SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The G38006-1 vacuum waste blockage removal tool is used on 737-600

thru -900 airplanes.

G38006 is used to clear blockages between the service panel and the waste tank in the vacuum waste system. The discharge hose attaches to the service panel at one end and the lavatory service truck at the other end. The discharge hose is clamped off and air is supplied to the hose to

dislodge the blockage.

Refer to the current G38006 drawing and AMM 38-32-00 for complete

usage instructions.

G38006-1 consists of:


| | G38006-1 | | | |
|----------|-----------------------------|-------------|--|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | | |
| 1 | HOSE ADAPTER ASSEMBLY | G38006-2 | | |
| 1 | PRESSURE REGULATOR ASSEMBLY | G38006-3 | | |
| 1 | AIR HOSE ASSEMBLY | G38006-4 | | |
| 1 | STORAGE BOX | | | |

WEIGHT: 10 lbs (4.5 kg)

DIMENSIONS: 12 x 24 x 33 inches (305 x 607 x 838 mm)







G84778 S0006831976_V3

Vacuum Waste System Blockage Removal Equipment Figure 1



PART NUMBER: C38001-23, -29

NAME: DRAIN MAST PLUG - WASTE WATER

AIRPLANE MAINTENANCE: YES

AMM 38-10-00, AMM 38-31-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The C38001-23 or -29 (preferred) waste water drain mast plug is used on

all 737 airplanes.

C38001 is not used on 737-100 thru -500 airplanes with the

60B50000-3/-5 forward drain masts. 737-100 thru -500 airplanes with

forward drain masts 60B50000-3/-5, refer to tool part number

TE65B50041.

C38001 is used to plug the forward and aft waste water drain masts during

gray water drain system cleaning procedures.

Refer to the current C38001 drawing, AMM 38-10-00 and AMM 38-31-00

for complete usage instructions.

C38001-23 and -29 consists of:

| C38001-23 | | |
|-----------|--------------------|-------------|
| QUANTITY | NOMENCLATURE | PART NUMBER |
| 1 | MAST PLUG ASSEMBLY | C38001-24 |
| 1 | STORAGE BOX | |

| C38001-29 | | |
|-----------|-----------------------------------|-----------|
| QUANTITY | QUANTITY NOMENCLATURE PART NUMBER | |
| 1 | MAST PLUG ASSEMBLY | C38001-30 |
| 1 | STORAGE BOX | |


WEIGHT: 5 lbs (2.3 kg)

DIMENSIONS: 12 x 12 x 8 inches (305 x 305 x 203 mm)

NOTE: C38001-29 replaces C38001-23 for future procurement.

C38001-23 supersedes C38001-1.





G83262 S0006831978_V5

Waste Water Drain Mast Plug Figure 1

38-30-07

Page 2 Aug 05/2014



PART NUMBER: A38006-1, -19

NAME: TESTER - TOILET VACUUM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The A38006-1 and -19 testers are used on 737-600 thru -900 airplanes.

A38006-1 is used on airplanes equipped with Yokohama Rubber

Company (YRC) lavatories.

A38006-19 is used on airplanes equipped with B/E Aerospace lavatories.

A38006 is used to determine the number of inches of vacuum in the toilet

vacuum lines for vacuum line troubleshooting.

Refer to the current A38006 drawing and AMM 38-32-00 for complete

usage instructions.

A38006-1 and -19 consist of:

| A38006-1 | | |
|----------|-----------------|-------------|
| QUANTITY | NOMENCLATURE | PART NUMBER |
| 1 | TESTER ASSEMBLY | A38006-2 |
| 1 | STORAGE BOX | |

| A38006-19 | | |
|-----------|--------------------------|-----------|
| QUANTITY | NOMENCLATURE PART NUMBER | |
| 1 | TESTER ASSEMBLY | A38006-20 |
| 1 | STORAGE BOX | |


WEIGHT: A38006-1 - 3 lbs (1.4 kg)

A38006-19 - 4 lbs (1.8 kg)

DIMENSIONS: A38006-1 - 6 x 6 x 17 inches (152 x 152 x 432 mm)

A38006-19 - 12 x 6 x 17 inches (305 x 152 x 432 mm)





1342872 S0000238839_V2

Toilet Vacuum Tester Figure 1

38-30-08

Page 2 Aug 05/2014



PART NUMBER: C38002-1

NAME: PLUG EQUIPMENT - SKIN FITTING, DOOR SILL DRAIN

AIRPLANE MAINTENANCE: YES

AMM 38-31-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The C38002-1 plug equipment is used on all 737 airplanes, except

737-100 thru -500 airplanes.

C38002 is used to plug the door sill drains at Sta 300.0, 307.00, 953.8 and

972.0 for cleaning.

Refer to AMM 38-31-00 and the current C38002 drawing for complete

usage instructions.


C38002-1 consists of:


| C38002-1 | | |
|----------|--------------------|-------------|
| QUANTITY | NOMENCLATURE | PART NUMBER |
| 1 | PLUG ASSEMBLY | C38002-2 |
| 3 | PIPE PLUG ASSEMBLY | C38002-11 |
| 1 | STORAGE BOX | |


WEIGHT: 5 lbs (2.3 kg)


DIMENSIONS: 1 x 2 x 4 inches (25 x 51 x 102 mm)














H64500 S0006831981_V4

Door Sill Drain Skin Fitting Plug Equipment Figure 1



PART NUMBER: A38012-1, -18, -31, -32, -39, -40

PUMP EQUIPMENT - VACUUM LAVATORY SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

> **USAGE & DESCRIPTION:** The A38012-1 (option), -31 (option) or -39 (preferred) pump equipment is

> > used on all 737 airplanes, except 737-100 thru -500 airplanes, for

chemical static soaking waste lines.

The A38012-18 (option), -32 (option) or -40 (preferred) pump equipment is

used on all 737 airplanes, except 737-100 thru -500 airplanes, for

recirculating chemical soaking of waste lines.

A38012-1, -18, -31, -32, -39 or -40 is used for the removal of waste buildup on the inner surfaces of the vacuum lavatory system waste lines. A38012-1, -31 or -39 is used for unheated, static, chemical soaking only. A38012-18, -32 or -40 is used for unheated, recirculating, chemical

soaking only.

The J38004 pump equipment is an alternate to the A38012 pump equipment. J38004 cleans airplane vacuum lavatory system waste lines

with heated, circulating, cleaning fluid.

Refer to AMM 38-32-00 and the current A38012 drawing for complete

usage instructions.

A38012-1, -18, -31, -32, -39 and -40 consist of:

| A38012-1 | | |
|----------|-----------------------|-------------|
| QUANTITY | NOMENCLATURE | PART NUMBER |
| 1 | DRUM PUMP ASSEMBLY | A38012-4 |
| 1 | DRAIN HOSE ASSEMBLY | A38012-5 |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-7 |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 |
| 1 | DRAIN END ASSEMBLY | A38012-9 |
| 1 | AIR ASSEMBLY | A38012-10 |
| *[1] | PLUG ASSEMBLY | A38012-11 |
| *[1] | VENT ASSEMBLY | A38012-12 |
| 1 | STORAGE BOX | |

QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.



| | A38012-18 | | |
|----------|---|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 | |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 | |
| 1 | AIR ASSEMBLY | A38012-10 | |
| 1 | DRUM PUMP ASSEMBLY | A38012-21 | |
| 2 | DRAIN HOSE ASSEMBLY | A38012-22 | |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-23 | |
| 1 | DRAIN END ASSEMBLY | A38012-24 | |
| *[1] | PLUG ASSEMBLY | A38012-25 | |
| *[1] | REPLACEMENT JUMPER MALE/MALE ASSEMBLY | A38012-29 | |
| *[1] | REPLACEMENT JUMPER MALE/FEMALE ASSEMBLY | A38012-30 | |
| 1 | STORAGE BOX | | |

^{*[1]} QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.

| A38012-31 | | |
|-----------|-----------------------|-------------|
| QUANTITY | NOMENCLATURE | PART NUMBER |
| 1 | DRUM PUMP ASSEMBLY | A38012-35 |
| 1 | DRAIN HOSE ASSEMBLY | A38012-5 |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-7 |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 |
| 1 | DRAIN END ASSEMBLY | A38012-9 |
| 1 | AIR ASSEMBLY | A38012-10 |
| *[1] | PLUG ASSEMBLY | A38012-11 |
| *[1] | VENT ASSEMBLY | A38012-12 |
| 1 | STORAGE BOX | |

^{*[1]} QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.

| | A38012-32 | | |
|----------|-----------------------|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 | |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 | |
| 1 | AIR ASSEMBLY | A38012-10 | |
| 1 | DRUM PUMP ASSEMBLY | A38012-36 | |
| 2 | DRAIN HOSE ASSEMBLY | A38012-22 | |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-23 | |
| 1 | DRAIN END ASSEMBLY | A38012-24 | |



(Continued)

| A38012-32 | | | | | |
|-----------|---|-----------|--|--|--|
| QUANTITY | QUANTITY NOMENCLATURE | | | | |
| *[1] | PLUG ASSEMBLY | A38012-25 | | | |
| *[1] | JUMPER ASSEMBLY | A38012-26 | | | |
| *[1] | REPLACEMENT JUMPER MALE/MALE ASSEMBLY | A38012-29 | | | |
| *[1] | REPLACEMENT JUMPER MALE/FEMALE ASSEMBLY | A38012-30 | | | |
| 1 | STORAGE BOX | | | | |

^{*[1]} QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.

| A38012-39 | | | |
|-----------|------------------------------|-----------|--|
| QUANTITY | PART NUMBER | | |
| 1 | DRAIN HOSE ASSEMBLY | A38012-5 | |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 | |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-7 | |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 | |
| 1 | DRAIN END ASSEMBLY | A38012-9 | |
| 1 | AIR ASSEMBLY | A38012-10 | |
| *[1] | PLUG ASSEMBLY | A38012-11 | |
| *[1] | VENT ASSEMBLY | A38012-12 | |
| 1 | DRUM PUMP ASSEMBLY | A38012-35 | |
| *[1] | CONNECTION SLEEVE (OPTIONAL) | A38012-82 | |
| 1 | STORAGE BOX | | |

^{*[1]} QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.

| A38012-40 | | | |
|-----------|---|-------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| *[1] | FLUSH PLUG ASSEMBLY | A38012-6 | |
| 1 | WATER SUPPLY ASSEMBLY | A38012-8 | |
| 1 | AIR ASSEMBLY | A38012-10 | |
| 1 | DRUM PUMP ASSEMBLY | A38012-36 | |
| 2 | DRAIN HOSE ASSEMBLY | A38012-22 | |
| *[1] | DRAIN VALVE ASSEMBLY | A38012-23 | |
| 1 | DRAIN END ASSEMBLY | A38012-24 | |
| *[1] | PLUG ASSEMBLY | A38012-25 | |
| *[1] | JUMPER ASSEMBLY | A38012-26 | |
| *[1] | REPLACEMENT MALE/MALE JUMPER ASSEMBLY | A38012-29 | |
| *[1] | REPLACEMENT MALE/FEMALE JUMPER ASSEMBLY | A38012-30 | |



(Continued)

| A38012-40 | | | |
|-----------|------------------------------|-----------|--|
| QUANTITY | PART NUMBER | | |
| *[1] | CONNECTION SLEEVE (OPTIONAL) | A38012-82 | |
| 1 | STORAGE BOX | | |

^{*[1]} QUANTITY BASED ON TABULATION PLACARD INFORMATION, THE AIRPLANE OWNER'S MAINTENANCE PROCESSES AND AIRPLANE CONFIGURATION.

WEIGHT: 300 lbs (136 kg)

DIMENSIONS: 36 x 24 x 24 inches (914 x 610 x 610 mm)


NOTE: A38012-31 and -32 replace A38012-1 and -18 respectively for future

procurement.

A38012-39 and -40 replace A38012-31 and -32 respectively for future

procurement.






A38012-39 SHOWN A38012-1,-31 SIMILAR PUMP EQUIPMENT

1342881 S0000238840_V2

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 1 of 4)





A38012-40 SHOWN A38012-18,-32 SIMILAR PUMP EQUIPMENT


1342888 S0000238841_V2

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 2 of 4)

38-30-10

Page 6 Aug 05/2015





A38012-39 PUMP EQUIPMENT SHOWN A38012-1,-31 SIMILAR


1342889 S0000238842_V3

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 3 of 4)

38-30-10

Page 7 Aug 05/2015





1342890 S0000238843 V3

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 4 of 4)

38-30-10

Page 8 Aug 05/2015



PART NUMBER: C38003-1

NAME: INSTALLATION ASSEMBLY - SLEEVE, WASTE TANK

AIRPLANE MAINTENANCE: YES

AMM 38-32-03, AMM 38-32-07

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The C38003-1 installation assembly is used on all 737-600 thru -900

airplanes.

C38003 is used to push the sleeve over the waste tank joint to reduce the

risk of damaging the sleeve.

Refer to the current C38003 tool drawing, AMM 38-32-03 and AMM

38-32-07 for complete usage instructions.


C38003-1 consists of:

| C38003-1 | | | |
|-----------------------|----------------|-------------|--|
| QUANTITY NOMENCLATURE | | PART NUMBER | |
| 1 | CLAMP ASSEMBLY | C38003-2 | |
| 1 | STORAGE BOX | | |

WEIGHT: 1 lb (0.5 kg)

DIMENSIONS: 2 x 5 x 5 inches (51 x 127 x 127 mm)






2001542 S0000391828_V1


Waste Tank Sleeve Installation Assembly Figure 1 (Sheet 1 of 2)

38-30-11

Page 2 Aug 05/2014







C38003-2 CLAMP ASSEMBLY



2001534 S0000391829_V1

Waste Tank Sleeve Installation Assembly Figure 1 (Sheet 2 of 2)

38-30-11

Page 3 Aug 05/2014



PART NUMBER: J38004-232, -247

NAME: PUMP EQUIPMENT - VACUUM LAVATORY SYSTEM

AIRPLANE MAINTENANCE: YES

AMM 38-32-00

COMPONENT MAINTENANCE: NO

USAGE & DESCRIPTION: The J38004-232 (option) and J38004-247 (preferred) pump equipment is

used on all 737 airplanes (except -100 thru -500) equipped with vacuum

waste systems.

J38004 is used for the removal of waste buildup on the inner surfaces of the waste lines. J38004 recirculates heated cleaning fluid in the waste

lines.

J38004 is an alternate to the A38012 pump equipment. A38012-39 cleans waste lines with unheated, static, cleaning fluid. A38012-40 cleans waste

lines with unheated, recirculating cleaning fluid.

Refer to AMM 38-32-00 and the current J38004 drawing for complete

usage instructions.

J38004-232 and -247 consist of:

| J38004-232 | | | |
|------------|-----------------------------|----------------------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | SUPPLY HOSE ASSEMBLY | J38004-3 | |
| 1 | RECIRCULATION HOSE ASSEMBLY | J38004-4 | |
| 1 | PLUG | J38004-5 | |
| 1 | CLEAN FLUID HOSE ASSEMBLY | J38004-6 | |
| 1 | ADAPTER ASSEMBLY | J38004-7 | |
| 1 | VENT PLUG ASSEMBLY | J38004-8 | |
| 1 | FLUSH PLUG ASSEMBLY | J38004-10 | |
| 1 | PLUG ASSEMBLY | J38004-11 | |
| 1 | GRAY WATER PLUG ASSEMBLY | J38004-12 | |
| 1 | DRAIN HOSE ASSEMBLY | J38004-13 | |
| 1 | HOSE ASSEMBLY | J38004-14 | |
| 1 | OUTLET PLUG | J38004-225 | |
| 1 | DOLLY ASSEMBLY | J38004-233 ^{*[1]} | |
| 1 | STORAGE BOX | | |

*[1] NO STORAGE BOX FOR J38004-233.

| ı | J38004-247 | | |
|---|------------|----------------------|-------------|
| | QUANTITY | NOMENCLATURE | PART NUMBER |
| ı | 1 | SUPPLY HOSE ASSEMBLY | J38004-3 |



(Continued)

I

| J38004-247 | | | |
|------------|-----------------------------|----------------------------|--|
| QUANTITY | NOMENCLATURE | PART NUMBER | |
| 1 | RECIRCULATION HOSE ASSEMBLY | J38004-4 | |
| 1 | PLUG | J38004-5 | |
| 1 | CLEAN FLUID HOSE ASSEMBLY | J38004-6 | |
| 1 | ADAPTER ASSEMBLY | J38004-7 | |
| 1 | VENT PLUG ASSEMBLY | J38004-8 | |
| 1 | FLUSH PLUG ASSEMBLY | J38004-10 | |
| 1 | PLUG ASSEMBLY | J38004-11 | |
| 1 | GRAY WATER PLUG ASSEMBLY | J38004-12 | |
| 1 | DRAIN HOSE ASSEMBLY | J38004-13 | |
| 1 | HOSE ASSEMBLY | J38004-14 | |
| 1 | OUTLET PLUG | J38004-225 | |
| 1 | DOLLY ASSEMBLY | J38004-252 ^{*[1]} | |
| 1 | STORAGE BOX | | |

*[1] J38004-252 DOLLY ASSEMBLY IS STORED SEPARATELY.


WEIGHT: 730 lbs (331 kg)

DIMENSIONS: 38 x 75 x 58 inches (965 x 1905 x 1473 mm)

NOTE: J38004-247 replaces J38004-232 for future procurement.

J38004-232 supersedes J38004-1.






Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 1 of 4)

38-30-15

Page 3 Aug 05/2015






2164954 S0000474696_V2

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 2 of 4)

38-30-15

Page 4 Aug 05/2015





RECIRCULATION CONFIGURATION


2164970 S0000474699 V3

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 3 of 4)

38-30-15

Page 5 Feb 05/2016





QUICK CLEAN CONFIGURATION

2164980 S0000474701_V3

Vacuum Lavatory System Pump Equipment Figure 1 (Sheet 4 of 4)

38-30-15

Page 6 Feb 05/2016



| REPAIRABLE/REPLACEABLE PARTS | | | |
|------------------------------|-------------|--------------|-------------|
| ITEM NUMBER | PART NUMBER | NOMENCLATURE | VENDOR CODE |
| [1] | J38004-225 | OUTLET PLUG | |
| [2] | J38004-5 | PLUG | |