

Training by Airbus OLB Installation Guide

This document must be used for training purposes only.

No part of this manual may be reproduced in any form, by any means, without the prior written permission of Airbus SAS.



1, rond-point Maurice Bellonte 31707 Blagnac Cedex FRANCE

© AIRBUS S.A.S 2017. All rights reserved.



« Please consider your environmental responsibility before printing this document »



Training by Airbus OLB Installation Guide

REVISION STATUS

ISSUE	ISSUER	DATE	REASON FOR REVISION
01	G.Izars/S.Sennegon	24/07/2017	Document creation



1.

2.

Training by Airbus OLB Installation Guide

Launch the application4



Training by Airbus OLB Installation Guide

1. Installation



Before installing **OLB**, check that **LPC-NG** is installed in **C:\Airbus\LPC-NGxxxx**


Remark: This OLB version works with the LPC-NG XWB and SA/LR.

From the installation media Unzip the file OLB.zip under C:\Airbus\

2. Launch the application

To run the application launch ClickMeToStart_Manuals.bat in C:\Airbus\OLB

At First launch you will get the following window:



Press any key

