
RANGER 1200 MANUAL ANTENNA Quick Start Guide




Note: Antenna color may differ from that shown here.

Rev. B




RANGER 1200 MANUAL ANTENNA Quick Start Guide



Note: Antenna color may differ from that shown here.



RANGER 1200 MANUAL ANTENNA Quick Start Guide




Note: Antenna color may differ from that shown here.



RANGER 1200 MANUAL ANTENNA Quick Start Guide

Tighten inner panel latches first, then tighten the outer latches.





Issue	Date	Changes	Ву:
А	2017/10/27	EC2017-292	DA
В	2020/03/02	EWO2020- 0091	ТМ

CONTACT INFORMATION

AIRBUS DS GOVERNMENT SOLUTIONS, INC. 3801 EAST PLANO PARKWAY **SUITE 200 PLANO, TX 75074**

MAIN: +1.214.231.3400

CUSTOMERSERVICE@AIRBUS-DS-GS.COM

SERVICE: +1.214.231.3406

CAGE CODE:



Proprietary Statement:

This document contains proprietary information and may not be reproduced in any form whatsoever, nor may be used by or its contents divulged to third parties without written permission of owner.

