CHAPTER 7 SINE INDICATING



WIRING DIAGRAM MANUAL

CHAPTER 77 ENGINE INDICATING

	CH-SC-SU	Schem	Page	Sheet	Date		CH-SC-SI	J Schei	n Page	Sheet	Date	
77-	-EFFECTIVE	PAGES										
			1		n 21/2016							
	CONTENTS		2	BL	ANK							
77- R	-CONTENTS		1	l	n 21/2016							
n			2		ANK							
77-	-ALPHABET											
			1		g 15/2013							
			2	BL	ANK							
_	77-12-11		1	1	- 01/0016							
R	77-12-21		ı	Ju	n 21/2016							
R	11 12 21		1	Ju	n 21/2016							
	77-21-11											
R			1	Ju	n 21/2016							
	77-31-11				45/0015							
_			1 2	Au	g 15/2013							
R	77-31-21		2	Ju	n 21/2016							
	77-01-21		1	Αι	g 15/2013							
				Ma	ar 14/2016							
			2 3 4	Ma	ar 14/2016							
R			4	Ju	n 21/2016							
1												
1												
1												
1												
1												
1												
1												
1												
1												
1												
1												

A = Added, R = Revised, D = Deleted, O = Overflow



WIRING DIAGRAM MANUAL

CHAPTER 77 ENGINE INDICATING

Title	CH-SC-SU	Schem Page	Sheet	Date	Effectivity
ENGINE TACHOMETER SYST	<u>EM</u>				
ENGINE N1 SPEED INDICATION	77-12-11	1		Jun 21/2016	ALL
ENGINE N2 SPEED INDICATION	77-12-21	1		Jun 21/2016	ALL
EXHAUST GAS TEMPERATUR	RE (EGT) INDI	CATING SYSTI	<u> </u>		
ENGINE EXHAUST GAS TEMPERATURE INDICATION	77-21-11	1		Jun 21/2016	ALL
AIRBORNE VIBRATION MONI	TORING (AVI	M) SYSTEM			
ENGINE 1 VIBRATION MONITORING SYSTEM	77-31-11	1		Aug 15/2013	YT101-YT103
		2		Jun 21/2016	YT104-YT133
ENGINE 2 VIBRATION MONITORING SYSTEM	77-31-21	1		Aug 15/2013	YT101-YT103
		2		Mar 14/2016	YT104-YT105
		3		Mar 14/2016	YT106-YT120
		4		Jun 21/2016	YT126-YT133




CHAPTER 77 ENGINE INDICATING

ENGINE INDICATING							
CH-SC-SU	Title						
77-31-11	ENGINE 1 VIBRATION MONITORING SYSTEM						
77-31-21	ENGINE 2 VIBRATION MONITORING SYSTEM						
77-21-11	ENGINE EXHAUST GAS TEMPERATURE INDICATION						
77-12-11	ENGINE N1 SPEED INDICATION						
77-12-21	ENGINE N2 SPEED INDICATION						



737-800 WIRING DIAGRAM MANUAL



ENGINE N1 SPEED INDICATION


D280A351

77-12-11


Page 1
Jun 21/2016

77-12-11

Page 1
Jun 21/2016



737-800 WIRING DIAGRAM MANUAL



Page 1


Jun 21/2016

D280A351

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.


Page 1

Jun 21/2016










YT104-YT133 **ENGINE 1 VIBRATION MONITORING SYSTEM** 77-31-11 Page 2 D280A351 Jun 21/2016

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

77-31-11

Jun 21/2016

Page 2



PT101-YT103

ENGINE 2 VIBRATION MONITORING SYSTEM

D280A351

77-31-21

Page 1
Aug 15/2013


77-31-21

ENGINE 2

Page 1

Aug 15/2013





ENGINE 2 VIBRATION YT104-YT105 MONITORING SYSTEM D280A351


77-31-21

Page 2 Mar 14/2016 77-31-21

Mar 14/2016

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 2



YT106-YT120

ENGINE 2 VIBRATION MONITORING SYSTEM

D280A351

E5-2 SHELF

E3-2 SHELF

77-31-21

Page 3 Mar 14/2016 77-31-21


Page 3

BOEING PROPRIETARY - Copyright (*) - Unpublished Work - See title page for details.

L

Mar 14/2016





ENGINE 2 VIBRATION YT126-YT133 MONITORING SYSTEM D280A351

77-31-21

Page 4 Jun 21/2016 77-31-21

Page 4

Jun 21/2016 BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.